

TECHNICAL INFORMATION FOR NSM-PHONOGRAPH

CD HIDE-AWAY

ES IV-CD TECHNOLOGY



NSM
APPARATEBAU
GmbH & Co. KG
6530 Bingen
Saarlandstraße 240
Telefon 067 21/4070

PART-№
209 900 A

1	TECHNICAL INSTRUCTIONS OPERATING SCHEME
2	OPERATING INSTRUCTIONS
3	STATISTIC- AND SERVICE PROGRAMS
4	CONTROL UNIT WIRING DIAGRAM
5	DISPLAY/ KEY BOARD
6	CENTRAL UNIT WIRING DIAGRAM
7	OUTPUT STAGE
8	CD CHANGER OPERATING SCHEME PICK UP DRIVER
9	./.
10	./.
11	REMOTE CONTROL
12	./.
13	OUTPUT TRANSFORMER
14	TROUBLE SHOOTING
15	ACCESSORIES
16	
17	
18	
19	
20	

GENERAL

The modern technology of this new NSM phonograph ***CD HIDE-AWAY*** with CD changer assures the highest functional reliability. A practical diagnostic system is available for maintenance and service.

In order to assure satisfactory operation at all times we recommend reading the technical descriptions carefully so that you are familiar with all service operations.

The following technical documents include:

- 1 The **TECHNICAL INSTRUCTIONS** with important information regarding set-up of the phonograph, technical data, location of the components, the "cabinet" parts list as well as the electrical plan and various wiring diagrams.
- 2 The **"OPERATING INSTRUCTIONS"** with explanations regarding play and settings as well as short instructions for statistics and service programs.
- 3 The **"STATISTICS and SERVICE PROGRAMS"** as well as test programs and error displays. The convenient service programs help the user in maintenance and control and permit the transfer of bookkeeping and technical data into the new NSM recording device and the printer "NSM DATA PRINT".
- 4-13 The **"UNIT DESCRIPTIONS"** for control unit, display/keyboard, central unit, output stage, CD changer, remote control and output transformer with their functions and, where applicable, wiring diagram and parts list.
- 14 **"TROUBLE-SHOOTING CHART"**, a description of errors, error displays as well as flow chart to determine errors.
- 15 **"ACCESSORIES"**, information on genuine NSM accessories with instructions for installation and exercising options.

The information and illustrations contained in these technical documents are up to date at the time of publication.

SUBJECT TO TECHNICAL MODIFICATION WITHOUT OBLIGATION TO MODIFY EQUIPMENT ALREADY DELIVERED!

Copyright by

NSM Apparatebau GmbH & Co. KG, D-6530 Bingen/Rhein 1, Germany

No reprint in full or part unless approved.



"Caution: Replace With Same Typ Fuses"

"Attention: Utiliser Un Fusible De Rechange de Même Typ".

The CD-Player with Laser pick-up used in this phonograph is in compliance with the regulations of the F.D.A.

Accession number 8 320 425

Supplement 15

This equipment complies with the requirements in Part 15 of FCC Rules for a Class A Computing Device. Operation of this equipment in a residential area may cause unacceptable interference to radio and TV reception requiring the Operator to take whatever steps are necessary to correct the interference.

*TECHNICAL INSTRUCTIONS
FOR NSM-PHONOGRAPHS*

CD HIDE-AWAY

ES IV-CD TECHNOLOGY



INDEX

- | | | | |
|------|--------------------------|-------|------------------------|
| 1. | PLEASE READ INSTRUCTIONS | 3.3. | Fuses |
| 1.1. | Transport damages | 3.4. | Lighting |
| 1.2. | Key | 3.5. | Keyboard |
| 1.3. | Transport devices | 3.6. | Displays |
| 1.4. | Power Connection | 3.7. | CD changer |
| 1.5. | CD's | 3.8. | Control-Loudspeaker |
| 2. | LAYOUT OF UNITS | 3.9. | Special Features |
| 2.1. | Display/Keyboard | 3.10. | Dimensions |
| 3. | SPECIFICATIONS | 4. | LOUDSPEAKER CONNECTION |
| 3.1. | Electrical data | | |
| 3.2. | Music power | | |





Fig. 1



1. PLEASE READ INSTRUCTIONS

1.1. Transport Damages

If external damage due to transport is noticed, this should at once be recorded on the delivery slip and endorsed by the person making the delivery.

The manufacturer is not liable for damages caused during transport!

1.2. Key

The key for the key switch "free credit and background" is included in the accessory pack of the phonograph.

1.3. Transport Devices

Before operating the phonograph all devices for safety and protection during transport have to be removed.

Prior to any further transit the safety and protection devices have to be replaced.

- Take off securing screws (2) and holding bracket (1).
- After loosening the fastening screw (14), remove cardboard strip (13) which prevents accidental opening of the magazine locks.
If the PCB holding plate (12) is to be flipped down, the fastening screw is to be removed.
- Push the bar locker (15) to the center and swing out left and right magazine (5).
- Take out magazine by moving the respective button (15) to the outside and take out unit.
- Take out red marked security screws (8), (9) so that the changer can swing freely.
- Remove slotted plastic pipe from the lift axle (11), grip the lift close to lift close to lift axle (10) and pull up.
- Remove cover from playing mechanism.
Remove foam padding (A) or rubber ring (B), if applicable, which protect the radial motor.
Do not insert foam padding on the cable side if safety devices have to be installed for further transport.

Keep transport devices in a suitable location in cabinet for later transport!

Information for return transport of CD changer:

When exchanging the changer, it may only be transported in the original packaging!

- Remove magazine, push the proper button (15) outwards and remove the unit.
Inserted CD's can be kept from falling out when the plastic pipe from the lift axle as well as a second one from the enclosed package is put through the opening (4) and all CD's in the magazines.
- Remove design parts: Take out front glass (7).
- Put in safety and protection devices in proper sequence.

1.4. Power Connection

The label on the power cord shows the voltage setting by the factory. For other voltages set voltages required on transformers.

Green-yellow of the three-wire power cord must be connected to the ground according to the international safety code. The line cord is located in a box on the rear of cabinet. To pull out the line cord the steel cover has to be removed (4 screws). Put the cable through the respective hole in the cover and put the cover back afterwards.

Check main voltage before connecting!

After plugging in the phonograph turn on the switch located at the rear of the cabinet.

1.5. CD's

Push service buttons (Fig. 1/15) each to the center, swing open magazine and equip with CD's. Observe the sequence of the magazine and title strip numbers of Wallbox.


Information: To take out the opened magazines push the service keys (Fig. 1/15) to the outside; take out magazines one after the other!

The CD's can be protected against falling out when transporting equipped magazines. For that put the plastic pipe of the lift axle as well as a second one from the enclosed package (Fig. 1/4) through the magazines and all CD's.

2. LAYOUT OF UNITS (see illustration on right-hand side)


- 1 Receiver for remote control (out of the phonograph)
- 2 Display/Keyboard
- 3 Output transformer
- 4 Control unit
- 5 Central unit
- 6 CD changer
- 7 Connection unit
- 8 Junction plate
- 9 Output stage

2.1. Display/Keyboard



Display panel with displays 1, 2 and 3 as well as 12 button selector

Fig. 2



3. SPECIFICATIONS

3.1. Electrical Data

Main volatge: 100-260 V (variable), 50/60 Hz

Power consumption

at standaby 170 watts

at play 450 watts

3.2. Music Power

2 x 200 watts music power at 2 ohms

3.3. Fuses

Replace fuses only with those of same value!

3.4. Lighting

1 Lamp 230-240 V 25 W E14

3.5. Keyboard

10 numbers keys 0-9

1 correction key "C"

1 hit-step key "H"

3.6. Displays

Display 1 with 4 seven-segment LED's

Display 2 with 2 seven-segment LED's

Display 3 with 4 seven-segment LED's

1 lamp display "10 top hits"

1 lamp display "background"

1 lamp display "credit"

1 lamp display "your selection"

1 lamp display "error, press key C"

3.7. CD Changer

NSM CD changer for maximum 100 CD's, 5- or 3 inch disc player:

Philips CD-2-system with CDM-3-playing unit; servo panel for control of CDM-3.

3.8. Control-Loudspeaker

1 loudspeaker SP-3R 8 ohms

3.9. Special Features

Integrated microphone preamplifier and connection socket for microphone with paging switch.

Computer-controlled amplifier protection for overload (mismatch).

3.10. Dimensions

Height 21 inches

Width 25 1/2 inches

Depth 18 inches

4. LOUDSPEAKER CONNECTION

The hide-away is equipped with a control loudspeaker. For service or repair it can be connected to the terminals of one of the outputs (left or right channel) of the output stage.

The connection wires of the external loudspeakers are led through an opening in the rear wall (left rear) to the inside, and then to the connection terminals of the output stage.

Watch the ▼ = polarity when connecting the loudspeakers!

The ES-IV amplifier serves an output of 2 x 200 watts music power at 2 ohms per channel.

If the loudspeaker impedance is 4 ohms, the loudspeaker will use 2 x 100 watts music power (Fig. 1) from the amplifier.

In that case, the additional loudspeakers connected cannot have an impedance of less than 4 ohms since the amplifier otherwise would be "mismatched" and the overload protection would operate.

If loudspeakers with a higher impedance are connected (Fig. 2), a number of speakers can be connected parallel. In that case, a loudspeaker with a higher impedance would naturally be lower in volume.

The polarity must be maintained because otherwise bass reproduction would nullify itself!




Fig. 1




Fig. 2

Mono mode; sound system for separate rooms; see Fig. 3.

If the volume is to be controlled independently from 2 rooms, both cabinet speakers can be connected to one channel. The loudspeaker for the other room can then be connected to the free channel. For that a jumper has to be soldered at DR 202 (see cut-out PCB central unit).




Fig. 3

Additional Loudspeakers and Separate Control

Speakers I and II in serial connection result in lower volume (Fig. 4)!






Fig. 4

If even more speakers are to be connected whereby the total impedance drops below 2 ohms, an output transformer has to be used (see schematics "Loudspeaker Connection" and unit description "OUTPUT TRANSFORMER").



Anschlußschema für Ausgangsübertrager
CONNECTION DIAGRAM FOR OUTPUT TRANSFORMER



Klemme TERMINAL POSITION	Lautsprecher SPEAKER			
	2,5 Ω	4 Ω	8 Ω	16 Ω
0 - 5	100 W	70 W	45 W	22 W
0 - 1	18 W	30 W	16 W	8 W
0 - 2	24 W	15 W	8 W	4 W
0 - 2	12 W	7,5 W	4 W	2 W
0 - 1	3 W	1,8 W	1 W	0,5 W

ÄNDERUNGEN IM SINNE DES TECHN. FORTSCHRANES VORBEHALTEN.
KEINER KEINE NACHHILFEPFLICHT!
SUBJECT TO TECHNICAL MODIFICATION WITHOUT OBLIGATION
TO MODIFY EQUIPMENT ALREADY DELIVERED!



MUSIKAUTOMATEN
PHONOGRAPHS

ES IV - CD TECHNOLOGY

Lautsprecheranschluß
SPEAKER CONNECTION

Anschluß für max. Ausgangsleistung
CONNECTION FOR MAX. POWER OUTPUT


26.07.89	Braun
----------	-------	-----	-----

SPARE PARTS LIST

CD HIDE-AWAY

POS.	PART-No	DESCRIPTION	DATA	QTY
		CABLE HARNESS		
	174 239	CONTROL UNIT -- CB DISPLAY	10 PRONGS	2
	172 804	CENTRALE -- OUTPUT STAGE	10 PRONGS	2
	171 782	CENTRALE -- CONTROL UNIT	15 PRONGS	1
	171 783	CENTRALE -- CONTROL UNIT	12 PRONGS	1
	173 998	WALLBOX ADAPTER		1
	174 242	KEY SWITCH -- CABINET SWITCH		1
	174 243	CENTRALE -- MAINS TRANSF.		1
	174 244	TRANSFORMER -- WALLBOX ADAP.		1
	174 245	CONTROL UNIT -- CD PLAYER	8 PRONGS	1
	174 246	TRANSFORMER -- CD PLAYER		1
	174 247	CD AUDIO		1

SPARE PARTS LIST



SPARE PARTS LIST

CD HIDE-AWAY

POS.	PART-No	DESCRIPTION	DATA	QTY
100	203 795	<u>CABINET</u>	<u>CD HIDE-AWAY</u>	
101	173 689	HOLDING PLATE		2
102	170 113	LOCK PLATE		1
103	172 637	SUPPORT, RIVETED		1
104	170 628	SUPPORT, RIVETED		1
105	217 604	LIFT-O-MAT		1
106	222 516	LAMP SOCKET	E14 2A 250 V/25 W	1
	226 081	LAMP	230-240 V 25 W E14	1
107	170 852	HANDLE		2
108	223 401	TRANSFORMER Remote Selection		1
	211 609	INSULATION PLATE		1
109	223 418	TRANSFORMER Mains Transformer		1
	211 609	INSULATION PLATE		1
110	171 725	JUNCTION PLATE, ASSY	50 Hz	1
	171 726	JUNCTION PLATE, ASSY	60 Hz	1
111	173 722	BRACKET, ASSY	RIGHT	1
112	173 723	BRACKET, ASSY	LEFT	1
113	107 617	CONTROL SPEAKER, ASSY		1
114	222 505	KEY SWITCH		1
	174 252	HOLDING PLATE		1
115	222 509	PUSH BUTTON SWITCH		1
	172 724	SWITCH PLATE		1
116	223 417	LINE TRANSFORMER	CD-PLAYER	1
	173 721	INSULATION PLATE		1
117	173 687	TRANSFO PLATE		1
118	174 206	SCREENING BOX		1
119	174 233	DISPLAY FRAME, RIVETED		1
	217 479	RUBBER PROFILE	100 mm long	1
120	174 229	BRACKET, RIVETED		1
121	173 794	GLASS, PRINTED	ENGLISH	1
	174 014	GLASS, PRINTED	GERMANY	1
122	173 900	KEY BOARD		1
123	173 664	CB-DISPLAY CD		1
124	173 667	CB-CENTRAL UNIT CD, ASSY	50/60 Hz	1
125	173 663	CB-CONTROL UNIT CD, ASSY		1
126	173 701	OUTPUT STAGE	50 Hz	1
	171 702	OUTPUT STAGE	60 Hz	1
127	173 470	CD-CHANGER 100, ASSY	without Design Parts	1

OPERATING INSTRUCTIONS

FOR NSM-PHONOGRAPHS

ES IV-CD TECHNOLOGY




NSM
APPARATEBAU
GmbH & Co. KG
6530 Bingen
Saarlandstraße 240
Telefon 067 21 / 40 70

PART-No
209 819 B

INDEX

1. PLAYING SEQUENCE
 - 1.1. Operation after switching on
 - 1.2. Standby
 - 1.3. Credits
 - 1.4. Selection
 - 1.5. Play mode
2. ADJUSTMENTS WITH REMOTE CONTROL
 - 2.1. Volume controls
 - 2.2. Muting
 - 2.3. Free credits
 - 2.4. Background music
 - 2.5. Key switch
3. SERVICE OPERATION - short program for price settings
4. CD change / cash collection

SELECTOR and DISPLAY PANEL



Display panel with displays 1, 2 and 3 as well as 12 button selector

1. PLAYING SEQUENCE

The functional sequence, starting with "power on," standby credit, selection and playing of selected title to the rest position is described below.

The technical assembly and the working together of the components can be seen in the "electronic schematics." Compare the descriptions with the illustration of the display/keyboard above.

1.1. Operation after Switching on

Immediately after switch-on the memory components - on the CONTROL UNIT - and all preprogrammed values are checked.

Display 1 shows then for 2 sec. the program index.

If an error is found during checking, error display Er xx is then shown for 2 sec.

With Er 31 (unverified memory contents) and Er 40 (price settings incorrect) Display 1 with Pxx shows the correct program step which needs to be reprogrammed. See description of service programs.

With other Er-displays, even during operation, proceed according to the instructions in "Trouble Shooting."

1.2. Standby

Hit display:

The microprocessor of the CONTROL UNIT figures out of the 30 titles just played before the ones played most.

On Display 3 the title numbers of the 10 most popular titles, whose rankings (1-10) are shown on Display 2, are changed in intervals of 2 sec. Also "10 top hits" lights up.

When pushing "H," the hit display can be stopped for 16 sec.; every press of the key causes an advance to the next hit.

Note: When the popularity counters are erased (program step P 10), the hit parade is erased, too. In that case "0" appears for ranking until records are played again.

Random Play:

In program step P24 a time interval can be set for random tune playing.

After expiration of set time the flip chart is advanced by 9 pages; then a random title is played.

Conditions for a random title to be played:

- Phonograph in standby mode
- No credit available
- Microphone switch not being used
- No muting
- Set time is expired

1.3. Credits (not for HIDE-AWAY)

See unit description "Coin and Bill Validation."

After insertion of a coin the "hit display" is interrupted, lamp "10 top hits" goes off and "credit" and "your selection" light up. Display 2 shows the number of credits.

For every selection credit is deducted.

If not enough credits are available for the selection, "credit" lamp flashes.

If no more coins are inserted within 16 sec. or no selector key is pressed, the mode changes to "hit display."

Free-credit switch (add. key), below the mechanical coin acceptor or on the adapter PCB with electronic coin validators, is only possible when the cabinet lid is open and the cabinet interlock switch is in service position (press add. button once = 1 credit). These credits are not registered statistically.

Starting with program index 0003 selections can be made without credits after pulling out the cabinet switch and going back to the regular program (2 x "C" key).

Attention! The machine is furnished with an interlock switch which must be manually set in service position (pull out). The switch resets automatically when closing the lid.

Note: Credits remain stored during "power off/on."

If the computer detects no activity on the phonograph within 1 hour, the stored credit is cancelled.

1.4. Selection

Title Selection: The four-digit number of the desired title has to be entered (2 digits each for disc and track). "Credit" and "your selection" light up. The selection can be corrected by pressing "C" up to 2 sec. after pressing the 4th digit.

Album Selection: When entering Track 00, all titles of a CD are automatically played (i.e. 0100 = all titles of Disc 01).

The number of credits which are deducted when selecting an album can be programmed in step P46.

When programming "0," album selection is blocked.

With open cabinet switch (interlock lever pulled out) no credit is deducted when selecting.

If the entry is incorrect, e.g. higher than the programmed number of CD tracks which can be selected or an unallowed selection of albums, "error" flashes. In that case, press "C" and repeat the selection.

One credit is deducted for each selection of a title. With album selections credits are deducted as per the programming in program step P46. If there is not enough credit available, "credit" lamp flashes.

16 sec. after selection "hit display" is switched on automatically again.

Note: If a background or random title is playing during selection, the volume is fading and the selected tune is being played.

When selecting a higher title number than recorded on the CD, the first title (track) of the CD will be played automatically.

1.5. Play Mode

After selection the microprocessor of the CONTROL UNIT moves the pickup of the CD changer to the selected CD and pulls it with its holder out of the magazine into the pickup. The pickup brings the CD to the disc player where it is then played.

Just before play the number of the title is shown on Display 1 ("selection now playing"). After the disc is played, the display is erased and the CD is transported back to its magazine space.

Note: If a error occurs with the CD changer or the player, "Er 7x" or "Er 6x" appears for 2 sec. In that case proceed according to the description in "Trouble Shooting".

Limiting Playing Time for a Title (Track)

In Service Program P30 the time that a title is to be played maximum can be set in minutes.

After expiration of this time the volume for that title is fading and then muted.

When setting "0" (default), there is no limit in playing time.

Sequence of Tunes Playing

In Service Program P31 one can set in which sequence the selected titles are played.

Settings: 0 = in sequence of selection (FIFO)
1 = in numerically increasing sequence
2 = random sequence

Limit of Playing Titles on the Same CD

One can set in Service Program P32 how many titles can be played consecutively on the same CD.

With 0 (default) there is no limit.

Attention!

When playing a test compact disc, the description that comes with the test disc is to be exactly adhered to. By any means, it is to be avoided to give sine signals with peak signal "0dB" at full volume level to the loudspeakers for more than 1 sec.

But also other unfiltered noises and high-frequency signals (which are only used for measuring purposes) can damage the amplifier and loudspeakers at full volume.

When checking channel separation, this test can only be done with a frequency of 1 KHz.

2. ADJUSTMENTS WITH REMOTE CONTROL

The phonograph can optionally be equipped with cable-type remote control or infra-red remote control. All functions and the operation of both models are identical. Therefore, this description is valid for both of them.

The button-control box attached to the rear of the cabinet allows common control of both channels "+" or "-" and "REJECT".

Information about the functions of different controls is presented in the unit description "Remote Control".

Note: The button volume control is not present with wallboxes such as the "CD FIRE" or the "CD HIDE AWAY".

2.1. Volume Controls

We differentiate between two volumes:

- 1.) The normal volume of selected titles and random play titles
- 2.) The background volume of background titles

For selected titles and random titles or with microphone and tape mode the corresponding volume is adjustable; background volume only with background mode:

Key "I" for the left channel; Key "II" for the right channel; "+" = louder, "-" = quieter. When pushing center key (I+II), the channels are regulated together. If they were differently set, they are first "balanced" and regulated together.

When no selection is taking place, the volumes for the channels are shown in Display 3 during the adjustment in steps of "1" to "31".

At "muting" function "OFF" appears in Display 1; no more titles will be played until MUTING is cancelled.

The volume set at the end is stored during "power off".

The maximum possible volume for normal and background mode can be limited in service program P28 in steps of "1" to "31".

Note: To protect the amplifiers a check is made whether an overload occurs due to mismatching in 250 ms cycles.

Upon recognition of an error the volume of the corresponding channel is reduced step by step automatically by the computer until a non-critical point is reached.

2.2. Muting

The volume of both channels can be set at "0" by pressing the MUTING key; "OFF" appears on Display 1. Re-pressing of the MUTING key or a VOLUME "+" key causes the system to switch back to the previously set volume for both channels.

Note: With display "OFF" no more records are played until MUTING is switched off.

2.3. Free Credits

With an "open" key switch free credits programmed in program step P23 can be called up. The following free credits are possible depending upon the settings in step P23:

- 1.) Number of set free credits can be called up individually step by step.
- 2.) Unlimited free credits can be called up individually step by step.
- 3.) Permanent credit when pressing key "FREE CREDIT" for the first time (credit display "99"). When key "FREE CREDIT" is pressed again, permanent credit is blocked.

2.4. Background Music


With an "open" key switch the background mode can be switched on with the BACKGROUND key. "Background playing" lights up. When pressing this key again, the background mode is switched off. In the background mode "random" records are played from the upper area of the magazine. The area can be set in program step P25.

The records are played at a "specific" background volume which can be changed as desired during playing cycle from "0" up to maximum volume set in program step P28.

A "normal record," selected while background music is playing, interrupts the background disc and the selected tune is played at "normal volume."

2.5. Key Switch

A key switch at the side wall serves as protection against unauthorized calling up of free credits and switching on the background mode. When the key switch is "locked," settings from the remote control are disregarded. Key switch "open" permits programmed free credits to be called up and the background mode to be switched on.



REMOTE CONTROL

3. Service Operation -Short Program for Price Settings-

This description is a summary of a section of the service program.
A detailed description and the corresponding tables are contained in chapter 1.3. "Price Settings" and 1.4. "Monetary Value Settings".

Practical example for setting the "plays per monetary unit" and the "monetary unit settings":
 1 play = 30 p
 2 plays = 50 p
 5 plays = 1 £

Setting the price table (plays/monetary unit):

Programming information	Operation	Displays		
		1	2	3
Switch-over from play mode to service mode	pull out plunger	P01		xxx
Select a program step	Press key(s)		SP:	GW:
	"C"	P		
Direct selection of program step, Display of previous setting in P41.	"41", "H".	P41	xx	xxx
New setting in P41 "1 play/30p".	"01", "02", "H".	P41	01	030
Advance to next program step, Display of previous setting in P42.	"H"	P42	xx	xxx
New setting in P42 "2 plays/50p".	"02", "050", "H".	P42	02	050
Advance to next program step, Display of previous setting in P43.	"H"	P43	xx	xxx
New setting in P43 "5 plays/1 £".	"05", "100", "H".	P43	05	100
Advance to next program step, Display of previous setting in P44.	"H"	P44	xx	xxx
For only 3 classes setting "00 000".	"00", "000", "H".	P44	00	000
Advance to next program step, Display of previous setting in P45.	"H"	P45	xx	xxx
For only 3 price classes setting "00 000"	"00", "000", "H".	P45	00	000

Caution! Press "C" key in the event of incorrect programming or when display flashes.

Press "C" key twice or close hood to return to standard program (play mode).

Monetary Value Settings:

The individual coin channels must be programmed for the associated monetary values in the corresponding program steps: Channel 1 for 20 pence in program step P51, channel 2 for 50 pence in program step P52, channel 3 for 10 pence in program step P53. Channel 4 (P54) and channel 5 (P55) are not used; both must be programmed with the monetary value "0".

Checking the monetary value settings: Select a program step between P50 and P55 (see description under "setting price table"). After inserting a certain coin the channel associated with the coin is displayed, e.g. 50 pence in channel 2: Display P52 050.

Changing the monetary value settings: As an example, the 20 pence slot (channel 1) is not to be used: First enter program step P51 as described in point 1. In the coin acceptor or on the adapter PCB of electronic coin validators the respective channel has to be blocked also so that these coins drop into the coin return.

Programming information	Press keys	Displays		
		1	2	3
Direct selection of program step, Display of previous setting in P51.	See text.	P51	xx	xxx
New setting; no coin conversion	"000", "H".	P51		xxx

If the standard setting according to the table is to be used thereafter, first switch on program step P50 (as described previously).

Ready for standard setting P50 through P55.	See text.	P50		
Program standard table 1.	"1", "H".	P50		1

Press "C" key twice or close cabinet hood and return to standard program (play mode).

4. CD CHANGE/CASH COLLECTION

- Open machine and activate cabinet switch (pull out plunger) to enter into service mode. Display 3 automatically shows the least played CD.
- By pressing "1" successively, the next best CD is shown each time.
- Unlock magazine, swing out; pull out the corresponding CD holders to change CD's. After changing push back CD holders until they lock in.
- Change corresponding title cards, unlock flip-chart unit and flap down. Get desired program tables in position with the button on the PCB of the right-hand side of the unit.
- Read counters: P03 = Cash total
P04 = Counter for plays
P05 = Number of selected titles
P06 = Number of selected albums
P07 = Number of free credits provided
P08 = Number of background CD's played
- Erase counters: P10, Code "1", counters P01 to P08 are erased.
- For more information see "Statistics and Service Programs", Section 1.1., Statistics Program, P01 to P12!

P01	Popularity beginning with least played CD upwards			P02	Pop. beginning with most played CD downwards			BUTTON
	No. of least played CD				No. of most played CD			0
	No. of next least played CD				No. of next most played CD			1
	Rank of CD displayed				Rank of CD displayed			2
	Times played				Times played			3
	Information about a certain CD				Information about a certain CD			4
P03	Total cash in monetary units			P04	Counter of played titles			0
	Total cash cumulative in monetary units/100.				Counter of played titles accumulated			1
P05	Number of selected title			P06	Counter of album selections			
P07	Number of free credit			P08	Counter of played album titles			
P10	Cancel of counters			P12	Transfer of NSM DATA PRINT **)			
	Popularity, HIT-Parade, Counter P03-P08, Credit				Counter P03-P08			1, H
	Popularity (P01, P02), HIT-Parade				Counter P03-P08, Settings P21-P56			2, H
	Counter P03-P08				Popularity, Counter P03-P08			3, H
	Credit				Pop. counter P03-P08, Settings P21-P56			4, H
P11	Data transfer and memory (storage) *)							1, H
P20	Autom. programming of the prog. steps P21-P39 according to table							1, H
P21	Unit code	P22	No. max. CD-Tracks to be selected		P23	No. of free credits		x, H
P24	Random play interval	P25	No. of CD's progr. f. backgr. music		P26	Light gener. f. stand by ***)		x, H
P27	Light gener./organ for play ***)	P28	Maximum volume					x, H
P30	Max. play time for a title *)	P31	Sequence of plays *)		P32	Max. titles in CD sequence *)		x, H
P38	Autorization with code numb.	P39	Code number					x, H
P40	Autom. programming of the steps P41 thru P46 (play/cash value) according to table							x, H
P46	No. of credits for an album selection							x, H
P50	Autom. programming of the steps P51 thru P56 (coin value acceptance) to table							x, H
P56	Bonus credit for Bill							x, H
P60	Test programs							x, H
P61	Programming optional Numbers of CD-Tracks							xxxx, H
P62	Read-out of error code							0; 1; 2; 3; 4, 1, H

*) from Progr.-Index 004;

**) from Progr.-Index 003;

***) If installed

Test Programs

P60	(Interrupt/run)	H
	Display 1 Display 2 Display 3 Error Display	
	Display and light test:	1, H
	Input test:	2, H
	Continuous Run 1 (playing continuously): F 3 Number of errors	3, H
	Continuous Run 2 (repeatedly playing): F 4 Number of errors	4, H
	CD = Changer test:	5, H
	"2" = Lift upwards	
	"8" = Lift downwards	
	"4" = Grip left	
	"6" = Grip right	
	"5" = Return holder	
	"0" = Keep lift position	
	"3" = Motor step, upwards *)	
	"9" = Motor step, downwards *)	
	OPTO stepper control OPSTP	
	OPTO endposition OPEND	
	OPTO grip right OPGRR	
	OPTO pickup center OPPUM	
	OPTO grip left OPGR L	
	With Display "0" = lit up	
	With Display "1" = darkened	
P61	Number of track numbers	xxxx, H
P62	Error code of least error	0
	Error code of previous errors (up to 10)	1
	No. of CD at which error occurred	2
	Time in hrs./min. since "power on" or start of P60/3 or P60/4 when error occurs	3
	Cancellation of stored error code	4

*) from Progr.-Index 004

Error Messages

Et	Error	Action
0x	EPROM	Check or replace corresponding component or unit. See special information in "TROUBLE SHOOTING".
1x	RAM	
2x	Program	
3x	Verification	
4x	Price settings	
5x	Coin mechanism/Bill validator	
6x	CD-Player	
7x	CD-Changer	
8x	Wallbox-Connection	

SHORT INSTRUCTION:

For statistics and service programs; test programs, error displays.

Detailed description in Section 3 "Statistics and Service Programs" as well as Section 14 "Trouble-Shooting".

STATISTIC-AND SERVICE PROGRAMS

FOR NSM-PHONOGRAPHS

ES IV-CD TECHNOLOGY



NSM
APPARATEBAU
GmbH & Co. KG
6530 Bingen
Saarlandstraße 240
Telefon 06721/4070

PART-No
209 820 B

INDEX

- 1. SERVICE PROGRAM
 - 1.1. Statistics program
 - 1.1.1. Popularity beginning with least played title upwards
 - 1.1.2. Popularity beginning with most played title downwards
 - 1.1.3. Reading counters
 - 1.1.4. Erasing counters and credits
 - 1.1.5. Data transfer
 - 1.2. GENERAL SETTINGS
 - 1.2.1. Standard settings
 - 1.2.2. Code for NSM DATA PRINT
 - 1.2.3. Position settings
 - 1.2.4. Free credits
 - 1.2.5. Random discs
 - 1.2.6. Light organ/generator (only for phonographs with LP light generator)
 - 1.2.7. Volumes for normal and background titles
 - 1.2.8. Maximum playing time
 - 1.2.9. Sequence of CD's played
 - 1.2.10. Maximum of tunes played on the same CD
 - 1.2.11. Authorization
 - 1.2.12. Change of key code
 - 1.3. PRICE SETTINGS
 - 1.3.1. Standard settings
 - 1.3.2. Price table (plays/monetary value)
 - 1.4. MONETARY VALUE SETTINGS
 - 1.4.1. Standard settings
 - 1.4.2. Monetary values (for Channels 1 to 5)
 - 1.5. TESTING PROGRAMS
 - 1.5.1. Display test, Display 1 "P60"
 - 1.5.2. Entry test, Display 1 "P60"
 - 1.5.3. Continuous Run 1
 - 1.5.4. Continuous Run 2
 - 1.5.5. Test CD changer
 - 1.5.6. Selection of CD and track numbers

1. SERVICE PROGRAM

When opening the cabinet and activating the cabinet interlock switch (pull out plunger), the phonograph is automatically switched from play mode to service mode.

In the service mode the user has available many valuable and easy-to-use aid programs. There are five main sections:

1. Statistical programs which support the reading, evaluating, printing and erasing of all counters (P01 to P12).
2. Programs which permit a standard setting by the manufacturer as well as settings for customers of all machine parameters (P20 to P39).
3. Programs which make possible an individual setting of a price table, but also offer the selection of a standard table out of 20 tables altogether (P40 to P46).
4. Programs which make possible the individual coin value setting for five channels, but also permit programming of one standard setting available for many countries (P50 to P56).
5. Testing programs which support a quick functional test of units as well as locating an error on location (P60/P61).

At delivery the phonograph is "non-coded," e.g. all data and programs are accessible in the service mode. Of course, all confidential data - they are marked in the last column of the following table by an "X" - can be locked via entry of a 4-digit code number (P39).

Short Program

After opening the cabinet and activating the cabinet switch manually, the statistical program "popularity" is automatically turned on. Display 1 shows program step "P01," Display 3 shows the least played CD.

Continue on to the following program steps by pressing "H."

When desiring another program step, press "C," Display 1: "P."

After that one can select a program step directly by entering the desired program number and pressing "H."


Return to normal program by pressing "C" twice.

Information (read-out of counters) of certain program steps through entry of code numbers.

Additional functions of certain program steps through entry of a code number and "H."

Standard settings in program steps P20, P40 and P50 through entry of table number and "H" within that program step.

SELECTOR and DISPLAY PANEL



Display panel with displays 1, 2 and 3 as well as 12 button selector

1.1. Statistical program

1.1.1. Popularity-from least played title upward

Display	Designation	Remarks	x
P01	Number of least played CD.	Enter number "0" (is switched on automatically)	
	Number of next least played CD, etc. upwards to the most played CD.	Advance with "1".	
	Rank of CD displayed.	Enter the number "2". The next display corresponds to the rank of this record Example display "5" corresponds to the fifth least played record.	
	Total of this CD played (max. 255).	Enter number "3" If a pop. counter is greater than 200 at "power off", all counters are divided by 2 (normalized). An "r" appears on display 2 until the counters are reset (the pop. dis- play is relative).	
	Information on a certain CD.	Enter the number "4", the desired CD number and "H". The desired information on this CD can be called up as described previously with the keys "1" through "3".	

1.1.2. Popularity, from best title upwards

P02	Number of most played CD.	Enter number "0" (is switched on automatically).	
	Number of next most played CD etc. down to the least played CD.	Advance with "1".	
	Rank of CD displayed.	Enter the number "2". The next display corresponds to the rank of this record. Example display "5" corresponds to the fifth least played record.	
	Total of this CD played (max. 255).	Enter number "3" If a pop. counter is greater than 200 at "power off", all counters are divided by 2. An "r" appears on display 2 until the counters are reset. Get actual popularity, multiply all by 2.	
	Information on a certain CD.	Enter the number "4", the desired CD number and "H". The desired information on this CD can be called up as described previously with the keys "1" through "3".	

1.1.3. Counter read-out

P03	Cash balance in monetary units (as pro- grammed by the settings in P51 through P55). 5 digits.	Enter number "0" (is switched on automatically).	x
	Cash balance-accumulated-5 digits.	Enter the number "1" Value shown must be multiplied by 100 to get total monetary units.	x
P04	Play counter.	Enter number "0" (is switched on automatically).	x
	Play counter, accumulated	Enter number "1".	x
P05	Number of selected title.	Enter number "0" (is switched on automatically).	x
P06	Number of album selections.		x
P07	Number of free credits.		x
P08	Number of background titles.		x

1.1.4. Counter and credit reset

Display	Designation	Remarks	x
P10	Total reset of popularity (P01, P02) the HIT-parade, the counters P03 through P08 and credits.	Enter number "1" and "H".	x
	Resetting the popularity (P01, P02) and HIT-parade.	Enter number "2" and "H".	
	Resetting the counters (P03 through P08).	Enter number "3" and "H".	x
	Cancel credits.	Enter number "4" and "H".	

1.1.5. Data transfer

P11	Data transfer and memory (storage) with the NSM DATA PRINT. (from Progr. Index 004)	Plug DATA PRINT into "Service Socket" of control unit. Enter Code "1" and "H". Counters (P03-P08) and popularity will be transferred. Display 3 "E0" appears in case of error during data transfer. Counters (P03-P08) and popularity are cancelled after successful data transfer. Also see description NSM DATA PRINT.	
P12	Transfer to NSM-DATA PRINT. Note: If phonograph is "coded", only the de-coded values are printed out unless the code number is entered. (from Progr.-Index 003)	Plug printer into the "service socket" on the control unit. Enter "1" = counters (P03 through P08) or "2" = counters (P03 through P08), settings (P21 through P37, P39) or "3" = counters (P03 through P08), popularity (P01, P02) or "4" = counters, settings, popularity. If overflow has taken place, the popularity is relative, the multiplying of overflows is printed out also. If the printer does not operate, "E0" appears on display 3.	

1.2. Specific Settings

1.2.1. Standard Settings

Display	Designation	Remarks	x
P20	Programming of steps P21 through P39 (for factory setting see table 1).	Press "1" and "H". If values deviating from the table are desired, they can be entered according to the following program steps.	x
Standard table for specific settings in program step P20. The following table shows the basic setting (factory setting) of the phonograph.			
Tab.No.	Result in the individual program step:		
	P21 0000 = unit code (for recording device)		
	P22 0024 = maximum choice CD/track (100 CD's/24 tracks)		
	P23 200 = free credits		
	P24 15 = interval for random play in minutes		
	P25 10 = Number of CD's for background		
	P26 1105 = light organ during standby	} Only for models with light organ/ luminous effects	
	P27 1000 = light organ during play		
	P28 3116 = maximum Volume of both channels for coin-selected titles and background-CD		
*)	P30 0 = No limit of playing time for a title		
*)	P31 0 = Playing in sequence of selection		
*)	P32 0 = No limit on playing titles on the same CD		
	P39 0000 = code number (data and program settings not coded)		

*) from Progr.-Index 004

1.2.2. Code number for NSM DATA PRINT

P21	Machine code number for NSM DATA PRINT	Enter code number between "0" and "9999" as well as "H".	x
------------	--	--	---

1.2.3. Position Settings

P22	Number of maximum choice CD/tracks	Enter desired number between "0101" and "0099" as well as "H". CD Nr. 00 = 100.	
------------	------------------------------------	--	--

1.2.4. Free credits

P23	Number of free credits.	Enter desired number and "H". "0" to "199" The number of free credits set can be released individually by the FREE CREDIT key on remote control. "200" An unlimited number of free credits can be set and released by the FREE CREDIT key on remote control. "201" The phonograph is continuously switched to "free credits" when the FREE CREDIT key is pressed (Credit Display "99"). The phonograph is switched back to operating mode when the FREE CREDIT key is pressed again.	x
------------	-------------------------	--	---

1.2.5. Random title and Background

P24	Time interval for random title.	Enter desired time interval between "0" and "255" minutes, followed by "H". (No random titles are played when "0" is entered).	x
P25	Number of background music-CD.	Enter desired number between "0" and "100", followed by "H". Background starts counting downwards starting with maximum number of CD's up (P22) to set number of background positions. With setting "0" no background operation.	x

1.2.6. Light Console/Light Organ (Only for models with light organ/luminous effects)

Display	Designation	Remarks					
P26 P27	Luminous effects for "stand by mode" or Luminous effects for "play mode"	A	B	C	D	Setting "A" corresponds to the switching characteristics: "0"-slow to "1"-fast. Setting "B" corresponds to speed of intervals (0-3). Setting "C-D" corresponds to the various types of light effects "1" through "15". Complete entry with the "H"-button.	x
		0	0	0	1		
		↓	↓	↓	↓		
		1	3	1	5		
P26 P27	Continuous light for "stand by mode" or Continuous light for "play mode"	0	0	0	0	Setting "B" corresponds to the desired brightness ("0" through "3"). Complete entry with "H"-button.	x
		↓	↓	↓	↓		
		3	3	3	3		
P27	Light organ in "play mode".	1	0	0	0	Setting "B" is for the desired basic brightness ("0" through "3"). Complete entry with the "H"-button.	x
		↓	↓	↓	↓		
		3	3	3	3		

1.2.7. Volumes for Regular and Background Music

P28	Maximum volume.	Enter two digits each for desired maximum volume of normally chosen and background titles as well as "H". e.g.: 31 24 └─ Background └─ Normal	x
-----	-----------------	--	---

1.2.8. Maximum Playing Time

P30	Maximum playing time for a title (from Progr.-Index 004)	Enter desired time in minutes between 0 and 99 and then press "H". With "0" no limit of playing time.	x
-----	--	---	---

1.2.9. Sequence of CD's playing

P31	Sequence of CD's playing (from Progr.-Index 004)	Enter Number 0, 1 or 2 and then press "H". 0 = in sequence of selection (FIFO) 1 = in numerically increasing sequence 2 = random sequence	x
-----	--	--	---

1.2.10. Maximum of tunes played on the same CD

P32	Maximum of tunes played on the same CD (from Progr.-Index 004)	Enter desired maximum number of tunes played and then press "H". With "0" no limit.	x
-----	--	--	---

1.2.11. Authorization

P38	Authorization.	Enter correct code number and "H". Each of the four digits is confirmed by "P". After closing with "H" "PPPP" is shown and the operator is thereby given authorization. Only the correct code number enables access to protected data. After closing of cabinet or going back to regular program by pressing "C" twice, the programs are protected again.	
-----	----------------	---	--

1.2.12. Code number

P39	Code number.	Changing of code number is only possible when operator has been authorized in program step P38. Enter new code number and "H". Each digit is confirmed after entry with "P". After closing with "H" "PPPP" is shown. Possible entries between "0000" and "9999". If "0000" is programmed, the machine is not protected and access to all programs is possible without authorization. A programmed code number is not shown anymore, so please remember your code number!	x
-----	--------------	--	---

1.3. PRICE SETTINGS

1.3.1. Standard Settings, from Progr.-Index 004

Display	Designation	Remarks	x
P40	Programming of the program steps P41 through P46 (Standard setting).	Enter corresponding table No. and "H". If values deviating from those in the table are desired, they can be changed according to the following program steps (P41) through P46).	x

Standard settings for plays per monetary value in program step P40. The result of the programming of a table ("0" through "20") shows the number of plays per monetary value allocated to the program steps P41 through P45. The monetary values are programmed in monetary value units as they are set in P50 through P55; example table 17, P41: If no bonus is to be given for a high monetary value, it is sufficient to program only the small monetary value, the total of the small values results in the larger value; example table 17: 1 x 25 c = 1 play + 100 c = 7 plays. Standard settings for P46 = "0".

Table- No.	Display of Program Number P41 P42 P43 P44 P45 Sp/Gw Sp/Gw Sp/Gw Sp/Gw Sp/Gw					Remarks/ as set by the factory
0	00 000	00 000	00 000	00 000	00 000	no coin conversion in this setting.
1	01 050	01 050	01 050	01 050	01 050	New Zealand 1 play = 50 c (NZ)
2	01 020	01 020	01 020	03 050	03 050	Belgium 1 play = 20,- Bfr 3 plays = 50,- Bfr (B)
3	01 005	01 005	03 010	03 010	07 020	if desired, please adjust 1 play = 5,- 3 plays = 10,- 7 plays = 20,-
4	02 050	02 050	05 100	05 100	12 200	Austria 2 plays = 5,- sS 5 plays = 10,- sS 12 plays = 20,- sS (A)
5	02 010	02 010	05 020	05 020	12 050	Germany 2 plays = 1,- DM 5 plays = 2,- DM 12 plays = 5,- DM (D)
6	01 050	01 050	01 050	03 100	03 100	USA 1 plays = 2x 25 c 3 plays = 4x 25 c (USA)
7	02 010	02 010	02 010	12 050	12 050	Norway 2 plays = 1,- Kr 12 plays = 5,- Kr (N)
8	01 010	01 010	03 020	03 020	03 020	Venezuela 1 play = 1,- Bol 3 plays = 2,- Bol (7 plays = 5,- Bol) (YV)
9	01 010	01 010	03 020	03 020	10 050	Ireland 1 play = 10 p 3 plays = 20 p 10 plays = 50 p (IR)
10	03 010	03 010	07 020	07 020	18 050	Switzerland 3 plays = 1,- sfr 7 plays = 2,- sfr 18 plays = 5,- sfr (CH)
11	01 030	01 030	02 050	02 050	05 100	United Kingdom 1 play = 30 p Denmark 2 plays = 50 p 5 plays = 1 £ (GB)
12	01 020	01 020	01 020	03 050	03 050	Jugoslavia (Din) 1 play = 2x 1,- Finland (mk) 3 plays = 5,- (SF) (YU)
13	01 020	01 020	03 050	03 050	07 100	Union of South Africa (c) 1 play = 20 c France (Fr) 3 plays = 50 c 7 plays = 1,- R (F) (SAU)
14	01 040	01 040	02 060	03 080	04 100	Australia 1 play = 2x 20 c 2 plays = 3x 20 c 3 plays = 4x 20 c 4 plays = 1 Dollar (AUS)
15	01 025	01 025	01 025	01 025	01 025	Canada 1 play = 25 c Dutch Antilles 4 plays = 1 NAF (CAN)
16	01 025	01 025	01 025	05 100	05 100	Spain (pts) 1 play = 0,25 5 plays = 1,- (E)
17	01 050	01 050	03 100	03 100	18 500	USA 1 play = 50 c 3 plays = 1 \$ 18 plays = 5 \$ (USA)
18	01 100	01 100	03 250	03 250	07 500	Netherlands 1 play = 4x 25 c 3 plays = 2,5 hfl 7 plays = 5 hfl (NL)
19	01 100	01 100	03 200	03 200	05 300	Japan 1 play = 100 Yen 3 plays = 2x 100 Yen 5 plays = 3x 100 Yen (J)
20	01 040	01 040	01 040	03 100	03 100	Italy 1 play = 2x 200 L 3 plays = 2x 500 L (I)

1.3.2. Price List (Number of Selections/Monetary Value)

Display	Designation	Remarks	
P41	Number of selections per coin (smallest value).	Enter desired number of plays coin (smallest value) and "H". Entry sequence: 2 digits for number of plays. 3 digits for corresponding coin e.g. 01 020 correspond to one play for 20 pence. Largest programmable number of plays up to 63, price list from 005 to 995. Note: All five program steps must be programmed with the price classes in the sequence or their priority. For less than 5 price classes program more than once or set to "00 000".	x
P42	Operating and display are analogous to program step P41		x
P43			x
P44			x
P45			x
P46	Number of required credits for one album.	Enter desired number and "H". At "0" no album selection allowed.	x

1.4. MONETARY SETTINGS

1.4.1. Standard Settings

P50	Programming of the program steps P51 through P55 (Standard setting).	Enter corresponding table and "H". If values other than those in the table are desired, they can be changed according to the following program steps (P51 through P55).	x
-----	--	--	---

The monetary value settings in the individual program steps are associated with the corresponding coin channel: P51 for channel 1; P52 for channel 2, etc. to P55 for channel 5. This table shows the coin values for the corresponding channel in the currency of the country in columns P51 through P55. Standard setting of P56 = "0".

Table- No.	Display of Program Number					Remarks/ as set by the factory
	P51 (Channel 1)	P52 (Channel 2)	P53 (Channel 3)	P54 (Channel 4)	P55 (Channel 5)	
0	000	000	000	000	000	no coin conversion in this setting
1	010 1,- DM 1 Bol 1,- sfr	050 5,- DM 5 Bol 5,- sfr	020 2,- DM 2 Bol 2,- sfr	000 -- -- --	000 -- -- --	Germany Venezuela Switzerland (YV) (D) (CH)
2	050 5 S	200 20 S	100 10 S	000 --	000 --	Austria (A)
3	020 200 L	010 100 L	050 500 L	000 --	000 --	Italy (I)
4	000 -- -- --	050 5 mK 5 Kr 5 Din	010 1 mK 1 Kr 1 Din	000 -- -- --	000 -- -- --	Finland Norway Jugoslavia (N) (SF) (YU)
5	025 25 c	250 2,5 hfl	100 1 hfl	000 --	000 --	Netherland (NL)
6	000 --	100 1,- NAF	025 0,25 NAF	000 --	000 --	Netherland Antillen (NA)
7	000 --	020 20 Bfr	005 5 Bfr	000 --	000 --	Belgium (B)
8	010 1 Fr 1 dkr	050 5 Fr 5 dkr	100 10 Fr 19 dkr	000 -- --	000 -- --	France Denmark (DK) (F)
9	020 20 p	050 50 p	010 10 p	000 --	000 --	United Kingdom/Ireland (GB) (IR)
10	010 10 c	050 50 c	025 25 c	000 --	100 1 Dollar	USA (USA)
11	000 --	025 25 c	000 --	000 --	100 1 Dollar	Canada (CAN)
12	020 20 c	100 1 R	050 50 c	000 --	000 --	Union of South Afrika (SAU)
13	100 1 Dollar 100 Yen	050 50 c 50 Yen	020 20 c 20 Yen	000 -- --	000 -- --	Australia Japan (J) (AUS)
14	000 --	025 25 pts	100 100 pts	000 --	000 --	Spain (E)

Monetary Setting for electr. Coin Acceptor see chapter 10,
Program Table 209 955

Table- No.	Display of Program Number					Remarks/ as set by the factory
P51 (Channel 1)	P52 (Channel 2)	P53 (Channel 3)	P54 (Channel 4)	P55 (Channel 5)		
15	100 10 Fr 1 £	020 2 Fr 20 p	010 1 Fr 10 p	050 5 Fr 50 p	000 -- --	France (F) United Kingdom (GB)
16	050 5,- DM	010 1,- DM	000 --	020 2,- DM	000 --	Germany (D)
17	050 5,- sfr 500 L 50 c	010 1,- sfr (100 L)	005 1/2 sfr (50 L) 5 c	020 2,- sfr 200 L 20 c	000 -- --	Switzerland (CH) Italy (I) New Zealand (NZ)
18	000 --	050 5 dkr	010 1 dkr	100 10 dkr	000 --	by 3-Channel Denmark (DK)
	100 10 dkr	010 1 dkr	000 0,25 dkr	050 5 dkr	000 --	by 4-Channel (02) Denmark (DK)
	100 10 dkr (new)	050 5 dkr	010 1 dkr	100 10 dkr (old)	000 --	by 4-Channel (1 A) Denmark (DK)
19	200 20 S	050 5 S	010 1 S	100 10 S	000 --	Austria (A)
20	025 25 c	250 2 1/2 hfl	500 5 hfl	100 1 hfl	000 --	Netherlands (NL)

1.4.2. Monetary Values (Allocated to coin channels 1 through 5)

Display	Designation	Remarks	x
P51	Coin value channel 1.	Monetary Setting for electr. Coin Acceptor see chapter 10, Program Table 209 955 Enter desired coin value for channel 1 and "H". Example: "010" corresponds to 10p, "020" to 20p and "100" corresponds to 1 £. Note: When a coin is inserted in the program steps P50 through P55 the channel assigned to this coin is automatically displayed on display 1; P51 for channel 2, etc. to P55 for channel 5. Not used channels are set to "0". The programmed monetary units for P51 through P55 must correspond to the unit programmed by the cash counter (P03), e.g. 050 units for 50p, 020 units for 20p and 100 units for 1 £.	x
P52			x
P53			x
P54	Operation and display are analogous to program step P51.		x
P55			x
P56	Bonus credits for bills.	Enter desired number and "H". When a dollar bill is inserted (Channel 5/P55), the programmed value is added to the credit.	x

1.5. TEST PROGRAMS

The displays in this program step acts as test aids for testing the phonograph. In the event of a malfunction the defective unit can be determined or a malfunction resulting from incorrect settings can be recognized in a simple manner with the aid of these tests. Certain displays are aids for the adjustment of the playing mechanism.

Switch on test program: Open cabinet lid pull out interlock cabinet switch
Display 1 shows "P01", press letter "C".
Display 1 shows "P".
Press number 60 and H, Display 1 shows "P60".

1.5.1. Display Test, Display 1 "P60"

This program tests the lights and displays on the display circuit board. After starting "F1" (first function test) appears on display 2.

The test is run through in steps: 1. All 5 display lights together.
2. The digits are switched on one after another individually with "8".
3. The display lamps 1 through 5 individually.
4. Displays together, running through the numbers "0" through "9".

The "F1" is displayed for approx. 2 seconds before the test repeats, itself.

Designation	Remarks
Display test -continuous test-	Enter "I" and "H". Display 2 "F1".
Stop test sequence	Enter "H". The light "10 top hits" comes on.
Continue test sequence	Enter "H" again. The light "10 top hits" goes off.
Terminate test.	Enter "C" once, display 1 "P60" or actuate cabinet switch, the unit returns to the regular program.

1.5.2. Input Test, Display 1 "P60"

In the following test the functions of all entries of Input Ports 1-5 can be tested:

Port 1, Port 2: Control unit
Port 3 : Keyboard (Display Board)
Port 4, Port 5: Pickup Driver

Every input change is shown on the display as follows:

Input Test	<p>Enter "2" and "H", Display 2 "F2" (second function test)</p> <p>Display</p> <p>Bit information (Switch Status 1 or 0) Bit Number (0 to 7) Port Number; 0 = Control Unit IC 8 1 = Control Unit IC 9 2 = Keyboard IC 304 3 = Pickup Driver IC 1 4 = Pickup Driver IC 2</p> <p>Meaning of the displays: "F 2" = Input Test "1" = Port 1 (IC 9) "8" = Bit 6 (Key Switch) "0" = Switch Status 0 (closed)</p> <p>Instruction: The accuracy of the inputs from the keyboard can be checked due to the entry connections simply by selecting a title!</p>
Terminate test.	Enter "C" 1, display "P60" or actuate cabinet switch, the phonograph returns to the normal program.

1.5.3. Continuous Run 1

The machine is switched to continuous run. Now every CD is played continuously for 16 sec. beginning with the first selection. All errors of the CD changer or CD player are registered.

Continuous Run 1	<p>Enter "3" and "H", Display 2 "F3". After that select the CD with which to begin.</p> <p>Display:</p> <p>Number of errors</p>
Terminate test.	Actuate housing switch.

1.5.4. Continuous Run 2

The machine is switched to continuous run. All selected titles are played for 16 sec. All errors of the CD changer or player are registered.	
Continuous Test2	<p>Enter "4" and "H", Display 2 "F4". The select any title.</p> <p>Displays:</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px;"></div> </div> <div style="margin-right: 10px;"> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px; text-align: center;">2</div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px; text-align: center;">F 4</div> </div> <div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px; text-align: center;">3</div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px; text-align: center;">x x x x</div> </div> Number of errors </div>
Terminate test.	Actuate housing switch.

1.5.5. CD changer Test

All functions of the changer can be tested individually.																					
CD changer test	<p>Enter "5" and "H", Display 2 "F 5".</p> <table border="1"> <thead> <tr> <th>Input</th><th>Function</th></tr> </thead> <tbody> <tr><td>1</td><td>CD-Player, Start/Stop</td></tr> <tr><td>2</td><td>Lift upwardw</td></tr> <tr><td>8</td><td>Lift downwards</td></tr> <tr><td>4</td><td>Grip left</td></tr> <tr><td>6</td><td>Grip right</td></tr> <tr><td>5</td><td>Return holder</td></tr> <tr><td>0</td><td>Stop lift of magazine space</td></tr> <tr><td>3 *)</td><td>Motor steps, upwards (per 0,5 mm)</td></tr> <tr><td>7 *)</td><td>Motor steps, downwards (per 0,5 mm)</td></tr> </tbody> </table> <p>Keep in mind the code numbers for the individual changer functions as per the following keyboard illustration:</p> <p>Displays:</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px; text-align: center;">1</div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px; text-align: center;">x x x</div> </div> <div style="margin-right: 10px;"> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px; text-align: center;">2</div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px; text-align: center;">F 5</div> </div> <div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px; text-align: center;">3</div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px; text-align: center;">x x x x</div> </div> </div> <p>The time in sec. during which the lift position is held. The lift position is held after every function for 2 sec., by touching "0" for 10 sec.</p> <div style="display: flex; justify-content: space-between;"> <div> <p>OPTO stepper control</p> <p>OPTO end position</p> <p>OPTO grip right</p> <p>OPTO pickup center</p> <p>OPTO grip left</p> </div> <div> <p>OPSTP</p> <p>OPEND</p> <p>OPGRR</p> <p>OPPUM</p> <p>OPGRL</p> </div> </div> <p>Meaning of displays: OPTO lit up = "0", OPTO darkened = "1".</p>	Input	Function	1	CD-Player, Start/Stop	2	Lift upwardw	8	Lift downwards	4	Grip left	6	Grip right	5	Return holder	0	Stop lift of magazine space	3 *)	Motor steps, upwards (per 0,5 mm)	7 *)	Motor steps, downwards (per 0,5 mm)
Input	Function																				
1	CD-Player, Start/Stop																				
2	Lift upwardw																				
8	Lift downwards																				
4	Grip left																				
6	Grip right																				
5	Return holder																				
0	Stop lift of magazine space																				
3 *)	Motor steps, upwards (per 0,5 mm)																				
7 *)	Motor steps, downwards (per 0,5 mm)																				
Terminate test.	Actuate housing switch.																				

*) from Progr.-Index 004

1.5.6. Track selection of CD test records

P61	Track selection of CD test records (more than 15 tracks per record).	Select the required CD record and track number and press "H". e.g. 0123 - Disc 01, Track 23. The selected title will be stored and played after returning to play mode.
-----	--	--

1.5.7. Read-out of errors

P62	Error code of lost error (see descr. error displays).	Enter "0". (Is automatically switched on).
	Error code of previous errors (see descr. error displays).	Advance with key "1". Up to max. 10 errors.
	No. of CD at which error occurred.	Enter "2".
	Time since power on or start of test P60/3 or P60/4 when error occurs.	Enter "3". Display in hrs., min.
	Cancellation of stored error code.	Enter "4", "1" and "H".

UNIT DESCRIPTION

CONTROL UNIT

FOR NSM-PHONOGRAPHS

ES IV-CD TECHNOLOGY



INDEX

- 1. FUNCTION
- 1.1. Control unit
- 1.2. Processor
- 1.3. Reset
- 1.4. Low voltage recognition and power off
- 1.5. I/O (input/output)
- 1.6. Output enable
- 1.7. Service plug

Spare parts list

Schematics CONTROL UNIT CD

1. FUNCTION

1.1. CONTROL UNIT

The heart of the control and credit unit is a microprocessor from the proven Rockwell 6500 family.

All unit functions such as keyboard, display, remote control, carriage (light generator/organ), coin mechanism, etc. are controlled by this unit.

Different types of malfunctions are recognized and reported as such on the display. All statistical data such as phonograph status, price adjustments and bookkeeping data are stored in the CONTROL UNIT. These as well as credits remaining are stored when the power is switched off.

Connection of the NSM DATA PRINT is provided at Plug 11.

A number of service programs allow the read-out of statistical data, individual as well as test programs.

1.2. Processor

The processor consists primarily of the microprocessor IC 1, the EPROM IC 2, the battery RAM IC 3 and the I/O component IC 4. Address coding occurs via IC 12.

The tact generator consists of a quartz oscillator with Q 1 (4 MHz) and the frequency divider (1:4) IC 14.

1.3. Reset

The Zener diode ZD 2 with transistors T 1 and T 2 serves to activate the reset when U (+ 5 V) is less than 4,6 V. Transistor T 2 with its antenna connection serves to recognize static discharges and interferences.

When T 2/C is LOW, reset is activated via IC 16, Pin 10, Pin 11. If T 2/C is HIGH, reset remains stored for approx. 200 msec. over the subsequent monoflop 1/2 IC 13 with timing components R 14, C 19 via IC 16, Pin 9.

1.4. Low Voltage Recognition and Power Off

Resistors R 15, R 16, R 18 form a voltage divider for low voltage recognition.

R 17 and D 6 generate a hysteresis when the voltage rises again. The positive edges (10 msec. at 50 Hz, 8.3 msec. at 60 Hz) coming from T 3/C retrigger the monoflop 1/2 IC 13 with timing components R 20, C 20 (approx. 20 msec.) and IC 13, Pin 4 at LOW. This signal is monitored by the processor via IC 4, Pin 6.

When IC 4, Pin 6 is HIGH, the program is prematurely deactivated.

1.5. I/O (Input/Output)

All I/O operations are controlled via a serial bi-directional interface (IC 4, Pin 18 = CLOCK; IC 4, Pin 19 = DATA). IC 18 selects the different input channels; IC 11 decodes the load impulses for the output channels.

Output: IC 5 and IC 6 are output ports. Resistors R 22-40 together make two D/A converters. The DC signals obtained thereby control the volume and are conducted to the amplifiers via plugs ST 2, Pin 2, Pin 3.

Input: IC 8 and IC 9 are input ports. The resistors, in sequence to the input pins, protect the CMOS components.


Serial interfaces are available:
At ST 3 for control of the light generator
At ST 4 for display and keyboard
At St 8 for control of CD changer

1.6. Output - Enable

A clock signal is sent by IC 4, Pin 5. Capacitor IC 26 is charged and keeps IC 15, Pin 8 at LOW. If the clock signal does not occur, IC 15, Pin 14 is LOW and OE of IC 5 and IC 6 is inactive (outputs in tree state). OE also becomes inactive via D 1 when reset (IC 16, Pin 11) becomes LOW.

1.7. Service Plug

Plug ST 11 serves to connect with the NSM DATA PRINT.



SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
	173 663	<u>CB-CONTROL UNIT CD, ASSY</u>		1
ST 07	225 651	PIN PANEL	4 prongs	1
ST 03, 06	225 652	PIN PANEL	6 prongs	2
ST 08	225 653	PIN PANEL	8 prongs	1
ST 04	225 654	PIN PANEL	10 prongs	1
ST 01	225 655	PIN PANEL	12 prongs	1
ST 02	225 656	PIN PANEL	15 prongs	1
ST 09	225 439	PIN PLUG	3 prongs	1
ST 05	225 444	PIN PLUG	8 prongs	1
ST 11	225 828	D-SUBMINIATUR-CONNECTOR	SLEEVE 9 prongs	1
Q 1	221 535	OSCILLATOR QUARTS	4 MHz	1
IC 3	222 446	IC-SOCKET	24 prongs	1
	231 423	IC-MEMORY	MK 48 Z 12-20	1
IC 2	222 447	IC-SOCKET	28 prongs	1
	173 699	IC-MEMORY	AM 27 256 DC	1
IC 1, 4	222 448	IC-SOCKET	40 prongs	2
IC 1	231 413	IC-MICROCOMPUTER	R 65 C 02 - P 2	1
IC 4	231 415	IC-MICROCOMPUTER	R 65 C 22 - P 2	1
IC 8, 9	221 763	IC-CMOS	HEF 4021 B	2
IC 5, 6	221 771	IC-CMOS	HEF 4094 B	2
IC 21-23	221 541	IC-CMOS	F 4049 BC	3
IC 16	221 665	IC-TTL	SN 74 LS 00	1
IC 19	221 525	IC-TTL	SN 74 LS 03	1
IC 17	221 652	IC-TTL	SN 74 LS 04	1
IC 14, 20	221 705	IC-TTL	SN 74 LS 74 A	2
IC 13	221 792	IC-TTL	SN 74 LS 123	1
IC 12	221 653	IC-TTL	SN 74 LS 139	1
IC 18	221 852	IC-TTL	SN 74 LS 151	1
IC 11	221 796	IC-TTL	SN 74 LS 138	1
IC 15	221 813	IC-LINEAR	LM 339	1
IC 26	221 497	IC-LINEAR	ULN 2003 A	1
D 3	221 115	SI-DIODE	1 N 4004	1
D 1,2,4-16	221 114	SI-DIODE	1 N 4148	16
ZD 1	221 539	TRANZORB DIODE	IC TE-5	1
ZD 2	221 948	ZENER-DIODE	ZPD 3,9	1
LED 1	221 466	LIGHT EMITTING DIODE	LR 3160-F	1
T 1, 2	221 757	TRANSISTOR	BC 547 B	2
T 3, 5	221 283	TRANSISTOR	BC 212 B	2
C 22	220 181	CER.-CAPACITOR	47 pF	1
C 23	220 242	CER.-CAPACITOR	68 pF	1
C 24	220 185	CER.-CAPACITOR	270 pF	1
C 18, 28	220 263	CER.-CAPACITOR	1000 pF	2
C 21	220 341	CER.-CAPACITOR	4700 pF	1
I-15,25,27	220 334	MKT-CAPACITOR	0,1 µF 63 V	17
C 19,20,26	220 159	LYTIC	4,7 µF 63 V	3
C 17	220 162	LYTIC	10 µF 63 V	1
C 16	220 160	LYTIC	100 µF 10 V	1

SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
R8,9,116	221 600	RESISTOR	100 OHM 1/4 W	3
R12,19,79	221 099	RESISTOR	470 OHM 1/4 W	3
R 93	221 622	RESISTOR	820 OHM 1/4 W	1
R10,87	221 029	RESISTOR	1 KOHM 1/4 W	1
R 13	221 031	RESISTOR	2,2 KOHM 1/4 W	1
R2-6,102-104, 106-110	221 033	RESISTOR	3,3 KOHM 1/4 W	13
R84,88,89,94, 100,101,105, 113	221 034	RESISTOR	4,7 KOHM 1/4 W	8
R 1, 15	221 172	RESISTOR	8,2 KOHM 1/4 W	2
R11,18,20,47,74, 76,82,83,90-92, 111,112,114,115	221 035	RESISTOR	10 KOHM 1/4 W	16
R16,21,27,33- 40,73,75,85	221 604	RESISTOR	22 KOHM 1/4 W	14
R 17	221 601	RESISTOR	27 KOHM 1/4 W	1
R22-26,28-32, 41-72,98,99	221 038	RESISTOR	47 KOHM 1/4 W	44
R14,81,86,95	221 048	RESISTOR	100 KOHM 1/4 W	4
R 80	221 273	RESISTOR	10 OHM 1/2 W	1

UNIT DESCRIPTION

DISPLAY / KEYBOARD

FOR NSM-PHONOGRAPHS

ES IV-CD TECHNOLOGY



INDEX

1. FUNCTION

1.1. Display

1.2. Keyboard

Spare parts list

1. FUNCTION

1.1. Display

The shift registers IC 301 through IC 303 are the output ports for the display control.

The display is operated in the multiplex mode.

The segment information is prepared for one digit with IC 302 and IC 303 via drivers IC 308 and IC 309.

The transistors T 303 through T 305 are controlled by IC 307 via IC 301 and switch on the appropriate multiplex level for 4 milliseconds.

Resistors R 332 to R 345 determine the segment current.

Lamps L 1 to L 5 are controlled statically via IC 307, Pin 12 and 14 and IC 306, Pin 19, 11, 12.

Resistors R 325 to R 329 limit the transient current.

The load signal for the output shift registers is monitored by circuit IC 306, Pin 4 and 13, R 306, C 303, D 301.

During the duration of the load signal the display is dark.

C 303 is discharged via D 301 and IC 306, Pin 13.

OE of IC 301 to IC 303 becomes LOW and thereby inactive.

If no load signal occurs, OE becomes inactive via R 305.

Capacitor C 302 avoids lighting up of the digits after switching on.


1.2. Keyboard


IC 301 is an input port for the keyboard which is connected to plug St 302.

The circuit with diodes D 302 - D 307 and transistors T 306, T 307 codes the keyboard matrix to a 4-bit signal combination.

SPARE PARTS LIST


POS	PART-№	DESCRIPTION	DATA	QTY
	173 664	CIRCUIT BOARD-DISPLAY CD, ASSY		1
ST 302	225 663	PIN PANEL	8 PRONGS 90°	1
ST 301	225 664	PIN PANEL	10 PRONGS 90°	1
AZ 1-8	231 416	DISPLAY	TD SL 5150	10
	173 384	TUBUS		1
	171 629	HOLDER		4
IC 310	221 573	IC-VOLTAGE	12 V 1 A	1
IC 301-303	221 771	IC-CMOS	HEF 4094 B	3
IC 304	221 763	IC-CMOS	HEF 4021 B	1
IC 306-309	221 497	IC-LINEAR	ULN 2003 A	4
D 301-307	221 114	SI-DIODE	1 N 4148	7
ZD 301	231 079	ZENER-DIODE	ZPD 4,7	1
T 301-305	231 240	SI-TRANSISTOR	BC 636 F	5
T 306, 307	221 283	SI-TRANSISTOR	BC 212 B	2
C 303-307	220 334	MKT-CAPACITOR	0,1 µF 63 V	5
C 308, 309	220 332	MKT-CAPACITOR	0,33 µF 63 V	2
C 302	220 249	LYTIC	1 µF 63 V	1
C 301	220 162	LYTIC	10 µF 63 V	1
R 301	221 611	RESISTOR	10 OHM 1/4 W	1
R 306,332-350	221 627	RESISTOR	1,2 KOHM 1/4 W	20
R302-304,307-309, 314-317,319-323,354	221 033	RESISTOR	3,3 KOHM 1/4 W	16
R 310-313	221 038	RESISTOR	47 KOHM 1/4 W	4
R 305	221 009	RESISTOR	1 MOHM 1/4 W	1
R 325-329	231 366	MET.-RESISTOR	10 OHM 1/4 W	5
	173 900	KEY BOARD, ASSY		1






Drucksicht: Display
TOP VIEW: DISPLAY

1 2 3 4 5
6 7 8 9 10



1 2 3 4 5
6 7 8 9 10

Drucksicht: Spannungsregler IC 310
TOP VIEW: VOLTAGE REGULATOR IC 310



von unten gesehen
BOTTOM VIEW

1 2 3 4 5
6 7 8 9 10


1 2 3 4 5
6 7 8 9 10

1 2 3 4 5
6 7 8 9 10

1 2 3 4 5
6 7 8 9 10

1 2 3 4 5
6 7 8 9 10

1 2 3 4 5
6 7 8 9 10



gerasterte Bauteile sind nicht eingebaut!
DOTTED COMPONENTS ARE NOT INSTALLED!

ÄNDERUNGEN IM SINNE DES TECHN. FORTSCHRITTES VORBEHALTEN,
JEDOCH KEINE NACHRÜSTPFLICHT!
SUBJECT TO TECHNICAL MODIFICATION WITHOUT OBLIGATION
TO MODIFY EQUIPMENT ALREADY DELIVERED!

MUSIKAUTOMATEN
PHONOGRAPHS

ES IV-CD TECHNOLOGY

Schaltbild
WIRING DIAGRAM

Anzeige / Tastatur
DISPLAY / KEY BOARD

Rev. 01.89
Gez. Braun
Bearb. Schödel
Gepr. Hagen

UNIT DESCRIPTION

CENTRAL UNIT

FOR NSM-PHONOGRAPHS

ES IV-CD TECHNOLOGY



Index

- 1. FUNCTION
 - 1.1. Power supply
 - 1.2. Amplifier
 - 1.3. Signal path
 - 1.4. Adjustment of controls
 - 1.5. MIC socket, microphone connection
 - 1.6. TB socket
 - 1.6.1. Tape recorder connection
 - 1.6.2. Connection of auxiliary amplifier
- 2. Adjustment instructions for trimmer of central unit and output stage
- 3. Repair aid
 - 3.1. Output stage
 - 3.2. Control of volume and muting
 - 3.3. Tracing sound signal

1. Function

The power supply, fan controls, stereo amplifier with inputs for microphone, CD and tape are all integrated on one circuit board. The output stages and the fan are connected to the central unit via ST 209, ST 210, ST 211. The music power per channel is 200 watts when matched to a loudspeaker impedance of 2 ohms.

1.1. Power Supply

The power transformer supplies 22 V, 2 x 11,5 V and 2 x 43 V from three separate secondary coils. The supply voltage for the output stages is supplied with 2 x 43 V by a two-way rectifier (D 206) and the center tap of the transformer.

The supply voltage for the voltage regulator VR 201, + 5 V is supplied with 2 x 11,5 V by a two-way rectifier (D 201/202) and the center tap on the transformer. The low voltage recognition is accomplished by D 204 and D 205. Fusing is accomplished with Si 201 and Si 202. Fusing for the output stage is accomplished with Si 204 and Si 205.

The control voltage of +15 Va, for the pickup driver, coin mechanism, control unit, remote control, luminous effects as well as the supply voltage for the preamplifier of +15 Vb, are supplied by the 22 V transformer coil and rectified by D 207 through 210 and VR 203. Fusing is accomplished by Si 203.

The LED's indicate the following supply voltages at the same intensity:

LED 201 = + 5 V

LED 202 = + 60 V

LED 203 = + 15 V a

LED 204 = + 15 V b

The TRIAC TIC 200 controls the output stage fan depending upon the operational state of the amplifier (REJECT); i.e. the fan only runs when the amplifier is not muted.

1.2 Amplifier

The stereo amplifier is equipped with two tone control IC's, one AF switch IC, 50 diodes and 17 transistors.

The output stage is designed without induction coils or transformers and is therefore ironless.

At full volume level the music power is 200 watts per channel.

1.3 Signal path

The input signal MIC goes to microphone amplifier T 230 and background mixer of TA, TR 231 to Pins 4 and 8 of IC 230. The TB input is connected to Pins 3 and 7. The CD input is connected to Pin 2 and Pin 6.

In the play mode the signal goes from Pin 2 to Pin 15 respectively through Pin 6 and Pin 9.

When the microphone switch is actuated, the signal goes from Pin 4 to Pin 15 or from Pin 8 to Pin 9.

In the tape mode (TB/Pin 6 to ground) the signal goes from Pin 3 to Pin 15 or Pin 7 to Pin 9 when the switch is actuated. In the MIC, CD or TB stage, muting is switched off regardless of the operating state of the phonograph. The stage "MIC" has priority switching.

From the AF switch (IC 230) the signal goes via an AVC (automatic volume control) T 250, T 251 at Pin 9 of the tone control IC 251 with associated bass booster. Treble control is accomplished with TR 252 and bass control with TR 253. The control voltage for the volume and muting is on Pin 5; approx. 2,5 V at full volume, approx. 0 V while muting.

The DC signal for the volume setting is supplied by the control unit.

Signal Output Pins 3 and 6 of IC 251 are routed through a network to the driver stage for the output stage.

The parallel complementary power Darlington transistors T 151 through T 154 in the output stage allow a minimum loudspeaker impedance of 2 ohms.

Quiescent current compensation and thermic stabilization is accomplished with T 150, the quiescent current setting with TR 250. The amplifier is equipped with three protective circuits against overload mismatching, thermic overload.

1) T 155 acts as a threshold switch for the electronic fuse. When the emitter current of the output transistors exceeds a certain value, T 252 is switched through by T 155 switching on the muting and thereby limiting the current.

2) The actuation of the electronic fuse at collector T 252 is controlled by the control unit.

When its fuse is tripped a number of times within a certain period, the volume is reduced automatically by one step each time until the electronic fuse is no longer activated.

3) The thermal switch on the heat sink switches off the power supply to the output stage when the heat sink temperature reaches approx. 90 C (cooling malfunctioning). LED 150 is dark. The switch-on point (following cooling down) is approx. 60 C (switch-on hysteresis).

The terminating impedance at the loudspeaker output should not be less than 2 ohms. In the case of mismatching (less than 2 ohms), or short-circuit in the loudspeaker cable, the limiting circuit is actuated.

The result is distorted sound reproduction or reduction of the volume. After elimination of the mismatch the amplifier is ready for operation and the volume can be readjusted.

The volume difference between the two channels is compensated at the factory by setting the levelling potentiometer TR 254.

1.4 Adjustment of Controls

TR 230 = microphone volume
TR 231 = music fade-in for microphone mode
TR 252 = treble control
TR 253 = bass control

TR 230 for setting the microphone amplifier:

This adjustment is dependent upon the position of the phonograph in relation to the microphone and required microphone volume. In case of feedback while paging, the control must be turned counterclockwise or the microphone be positioned in another direction to the speakers.

TR 231 for music fade-in in microphone mode:

There the desired music volume level during paging can be controlled.

TR 252 R and TR 252 L, treble controls, are to be set according according to the locations.

The maximum position is suggested in acoustically balanced rooms only.

TR 253 R and TR 253 L, bass controls, must also be set according to the locations and the desired bass reproduction.

1.5 MIC socket, Microphone Connection

A dynamic microphone with an impedance of 200 ohms - 600 ohms with switch for relay control can be used.

NSM option accessories:

Microphone	Order No. 224 223
Connection cable	Order No. 171 880 (10 m long)

1.6 TB Socket

1.6.1. Tape Recorder Connection

The TB socket allows the music from the phonograph to be recorded on a tape recorder as well as music from a tape recorder to be played by the phonograph.

The AF signal (analog signal) for recording with a tape recorder is on Contacts 1 and 4 and can be connected directly with a stereo diode cable; Contacts 2, 7 and 8 (8 is ground).

1.6.2. Connection of Auxiliary Amplifier

An auxiliary amplifier can be connected to the TB socket. The AF signal can be fed directly from the TB socket (Contacts 1 and 4) to the input of the amplifier with a stereo diode cable. The input sensitivity of the external amplifier should be 200 mV at a minimum input impedance of 47 K ohms.

Note: A stereo diode cable with a 5-pin plug is suitable for the above connections. In this plug Pin 1 must be connected to Pin 1; 3 to 3; etc.

The stereo recording cable is **not** suitable because in such cables Pin 1 is connected to 3 and 4 to 5 (crossed.)

2. Adjustment Instructions for Trimmer of Central Unit and Output Stage

TR 150 for quiescent current adjustment of the output stage: The quiescent current must be set to 40 mA + 5 mA. After replacement of the output transistor T 151 through T 154 a correction may be required.

Important! Muting is to be switched off for measuring and setting. The lift will be put in play position, the volume control is set at 0 and Si 150 or the thermal switch are replaced by an ampere meter.

TR 201 and TR 202 for adjustment of volume control voltage:

Maximum volume for regularly selected titles in program step P 28 must be programmed to "31" (full volume).

Take measurements at test points TP-L and TP-R to ground; nominal value = 2,6 V (factory setting).

The internal resistance of the measuring instrument must be greater than 1 M ohm!

After replacement of IC 251 a correction may be required.

TR 254 R and TR 254 L, level controls for adjustment of the total amplification: Set at factory to correspond to the output voltage of the CD player.

Muting must be switched off. Volume, treble and bass set to maximum.

The output voltage on the loudspeaker connection with a load of 4 ohms is approx. 10 V = 25 W power per channel, with the AVC at full level. At minimum impedance of 2 ohms the RMS output corresponds to 100 W RMS or 200 W music power at disc playing.

3. Repair Aid

Amplifier integrated in central unit ES IV

Malfunction: No sound, no output power:

It is assumed that LD 201 to LD 204 glow with the same intensity and that the power supply is therefore O.K., the CD is on the CD player being played, and normal volume was set in program step P28 to "31."

3.1. Output Stage

LD 150 on the output stage circuit board is dark. Malfunction probably located in the output stage; check Si 150 and replace if required. If the fuse blows again, the output transistors are defective.

Remove output stage unit, pull out cover plates on the bottom. Check for short-circuit on transistors T 151/T 152 and T 153/T 154 with ohmmeter. Since the transistors are connected in parallel, it is only possible to test them in pairs.

For individual testing one transistor must be unsoldered from the defective pair. After replacement of the defective transistors the quiescent current must be readjusted with TR 150 according to the adjustment instructions.

3.2. Control of Volume and Muting

In the play mode approx. 2,6 V must be measured on Pin 5 of IC 251 (for full volume).

If the voltage is near 0 V, T 252 or the control "volume L and R" from the computer must be checked (reject line).

3.3. Tracing Sound Signal

Trace the sound signal arriving at CD plug according to the table.

The point where the signal is missing is probably the cause of the malfunction.

AF Signal Point	Cause of Malfunction When Signal Missing
C 237, C 238	IC 230
IC 251 L/R Pin 9	T 250 / T 251 (AVC)
R 269 L/R (2,6 V at IC 251/Pin 5)	IC 251 L/R
T 255 L/R (collector)	T 253 L/R or T 254

If the signal is there up to T 255, but no output signal arrives at the output stage, plug connectors ST 210/211 as well as the output stage have to be checked.

SPARE PARTS LIST


POS.	PART-No	DESCRIPTION	DATA	QTY
	173 666	CENTRAL UNIT, ASSY	50/60 Hz	
SI 203	225 033	FUSE	T 2,0 A	1
SI 201, 202	225 029	FUSE	T 3,15 A	2
SI 204, 205	225 374	FUSE	T 6,3 A by 50 Hz	2
SI 203	225 220	FUSE	T 2,0 A	1
SI 201, 202	225 225	FUSE	T 3,2 A	2
SI 204, 205	225 218	FUSE	T 6,25 A by 60 Hz	2
SI 201-205	173 730	COOLING PLATE		1
	225 689	FUSE HOLDER		10
	173 698	PROFILE, ASSY		2
	173 944	SHIELDING COVER		1
MIC	225 244	SOCKET	S 5 PRONGS	1
TB	225 749	SOCKET	Mab 8 SV	1
ST 209	225 439	PIN PLUG	RM 2,5 3 PRONGS	1
ST203,206,CD	225 418	PIN PLUG	RM 2,5 4 PRONGS	3
ST 205	225 443	PIN PLUG	RM 2,5 6 PRONGS	1
ST 208	225 328	PIN PLUG	RM 3,96 6 PRONGS	1
ST 207	225 444	PIN PLUG	RM 2,5 8 PRONGS	1
ST 200	225 807	PIN PLUG	RM 3,96 12 PRONGS	1
ST204,210,211	225 654	PIN PANEL	RM 2,5 10 PRONGS	3
ST 202	225 714	PIN PANEL	RM 2,5 12 PRONGS	1
ST 201	225 656	PIN PANEL	RM 2,5 15 PRONGS	1
VR 201	221 572	IC-VOLTAGE	+5 V 1 A	1
VR202,203	221 476	IC-VOLTAGE	+15 V 1,5 A	2
IC 230	231 236	IC-LINEAR	TDA 1029	1
IC 251 RL	231 089	IC-LINEAR	TDA 4290-2	2
201-203,207-210	221 463	SI-DIODE	BY 251	7
211,212,218,222, 3,254RL,255RL	221 115	SI-DIODE	1 N 4004	9
204,205,213-217, 6,251-253 RL,256RL	221 114	SI-DIODE	1 N 4148	27
D 206	231 202	SI-DUO DIODE	BYV 32/100	1
ZD 201	221 821	TRANSZORB DIODE	TVS 515	1
LD201-204	221 466	LIGHT EMITTING DIODE	LR 3160-F	4
TIC 200	231 028	TRIAC	TIC 206 D	1
T204,253RL	221 459	SI-TRANSISTOR	PNP BC 556 B	3
T230,250RL, 251RL	221 249	SI-TRANSISTOR	NPN BC 550 B	5
T 255 RL	221 488	SI-TRANSISTOR	NPN BD 139-10	2
T252RL,205	221 332	SI-TRANSISTOR	NPN BC 337-16	3
C 263 RL	220 342	CER.-CAPACITOR	100 pF	2
C 277 RL	220 185	CER.-CAPACITOR	270 pF	2
C 267 RL	220 274	CER.-CAPACITOR	330 pF	2
C 241, 242	220 241	CER.-CAPACITOR	560 pF	2
C 246	220 263	CER.-CAPACITOR	1 nF	1

SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
C 243, 244	220 240	KT-CAPACITOR	1,5 nF	2
C 269 RL	220 401	KT-CAPACITOR	3,3 nF	2
C218-222,265 RL,279RL	220 435	KT-CAPACITOR	4,7 nF	9
C 268 RL	220 429	MKT-CAPACITOR	0,15 µF 100 V	2
C 270 RL	220 335	MKT-CAPACITOR	0,022 µF 63 V	2
C216,217,230, 234,235,239, 240,271RL,273 RL,281,282	220 334	MKT-CAPACITOR	0,1 µF 63 V	13
C 274 RL	220 333	MKT-CAPACITOR	0,22 µF 63 V	2
C210-214,227, 228,280RL	220 332	MKT-CAPACITOR	0,33 µF 63 V	9
C 205	220 336	MKT-CAPACITOR	2,2 µF 63 V	1
C 206	220 460	MKT-CAPACITOR	3,3 µF 63 V	1
C258RL,259RL	220 243	TAN-CAPACITOR	SF 100 µF 3 V	4
C 260 RL	200 249	LYTIC	1 µF 63 V	2
C231,237,238, 257RL,262RL, 264RL	220 159	LYTIC	4,7 µF 63 V	9
C261RL,266RL, 275RL	220 162	LYTIC	10 µF 63 V	6
C 272 RL	220 389	LYTIC	47 µF 10 V	2
C276RL,278RL	220 158	LYTIC	47 µF 40 V	4
C 236	220 160	LYTIC	100 µF 10 V	1
C 251	220 250	LYTIC	100 µF 25 V	1
C 226	220 289	LYTIC	1000 µF 40 V	1
C 201	220 283	LYTIC	2200 µF 25 V	1
C 202	220 286	LYTIC	4700 µF 25 V	1
C 204	220 287	LYTIC	4700 µF 40 V	1
R 276 RL	221 095	RESISTOR	6,8 OHM 1/4 W	2
R259,279RL, 287 RL	221 611	RESISTOR	10 OHM 1/4 W	5
R 206	221 620	RESISTOR	22 OHM 1/4 W	1
R 277 RL	221 096	RESISTOR	56 OHM 1/4 W	2
R 270 RL	221 600	RESISTOR	100 OHM 1/4 W	2
R 263 RL	221 635	RESISTOR	180 OHM 1/4 W	2
R 264 RL	221 614	RESISTOR	330 OHM 1/4 W	2
R 208	221 099	RESISTOR	470 OHM 1/4 W	1
R 267 RL	221 622	RESISTOR	820 OHM 1/4 W	2
R205,207,269 RL,288RL	221 029	RESISTOR	1 KOHM 1/4 W	6
R 275 RL	221 030	RESISTOR	1,5 KOHM 1/4 W	2
R 209, 283	221 031	RESISTOR	2,2 KOHM 1/4 W	2
R 278 RL, 298	221 033	RESISTOR	3,3 KOHM 1/4 W	3
R 262 RL	221 172	RESISTOR	8,2 KOHM 1/4 W	2
R266RL,226,284, 289RL,292	221 035	RESISTOR	10 KOHM 1/4 W	7
R 219, 220	221 501	RESISTOR	18 KOHM 1/4 W	2
R 268 RL, 227	221 604	RESISTOR	22 KOHM 1/4 W	3
R 290 RL	221 037	RESISTOR	33 KOHM 1/4 W	2
R230,243-248, 271 RL	221 038	RESISTOR	47 KOHM 1/4 W	9

SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
R 274 RL	221 039	RESISTOR	56 KOHM 1/4 W	2
R 258 RL	221 629	RESISTOR	68 KOHM 1/4 W	2
R 261 RL	221 044	RESISTOR	82 KOHM 1/4 W	2
R 273 RL	221 048	RESISTOR	100 KOHM 1/4 W	2
R 272 RL	221 045	RESISTOR	150 KOHM 1/4 W	2
R215,216, 234-241	221 049	RESISTOR	470 KOHM 1/4 W	10
R 265 RL	221 981	RESISTOR	560 KOHM 1/4 W	2
R 260 RL	221 041	RESISTOR	820 KOHM 1/4 W	2
R228,229, 232,233	221 009	RESISTOR	1 MOHM 1/4 W	4
R 231	221 982	RESISTOR	3,3 MOHM 1/4 W	1
R 285 RL	221 230	RESISTOR	470 OHM 1/2 W	2
R 291	221 183	RESISTOR	1 KOHM 1/2 W	1
R 286 RL	221 210	RESISTOR	1,5 KOHM 1/2 W	2
R 1,202,283	221 692	WIRE WOUND RESISTOR	1 OHM 1 W	3
R 222	231 232	WIRE WOUND RESISTOR	6,8 KOHM 1 W	1
TR252RL,253RL	231 086	TRIMMER RESISTOR	10 KOHM 0,15 W	4
TR 230	231 233	TRIMMER RESISTOR	1 MOHM 0,15 W	1
TR 231	231 234	TRIMMER RESISTOR	2,5 MOHM 0,15 W	1
TR230,TR231, TR252RL,253RL	231 235	SHAFT	red Nr. 5214	6
TR 201, 202	221 278	TRIMMER RESISTOR	10 KOHM 0,1 W	2
TR 254 RL	221 414	TRIMMER RESISTOR	100 KOHM 0,1 W	2



UNIT DESCRIPTION

OUTPUT STAGE

FOR NSM-PHONOGRAPHS

ES IV-CD TECHNOLOGY




Output Stage

The output stage is designed without induction coils or transformer and is therefore ironless. At full volume the music power is 200 W per channel when connected to a 2-ohm loudspeaker impedance.

Functions such as power supply, signal path and settings as well as repair aids are described in detail in the unit description "CENTRAL UNIT."


SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
SI 150	171 701	<u>OUTPUT STAGE, ASSY</u>	<u>50 Hz</u>	1
	225 036	FUSE	T 4 A slo blo	1
	225 747	CAP		1
SI 150	171 702	<u>OUTPUT STAGE, ASSY</u>	<u>60 Hz</u>	1
	225 542	FUSE	4 A slo blo	1
	225 748	CAP		1
	171 696	CHASSIS		1
	171 881	VENTILATOR, ASSY		1
	171 699	AIR VANE		1
	222 485	TEMPERATUR CONTROLLER		1
ST 150		<u>CIRCUIT PLATE - OUTPUT STAGE</u>		1
	225 422	TERMINAL BOARD	3 PRONGS	1
	225 654	PIN PANEL	10 PRONGS	1
	225 746	FUSE HOLDER	black	2
D 150, 151	221 115	SI-DIODE	1 N 4004	2
ZD 150	221 650	SI-ZENER-DIODE	ZPD 33	1
LD 150	221 466	LIGHT EMITTING DIODE	CQE 65	1
T 150	221 883	SI-TRANSISTOR	NPN BD 239 B	1
T 155	221 459	SI-TRANSISTOR	PNP BD 256	1
T 151, 152	221 886	DARLINGTON-TRANSISTOR	NPN BDW 83 C	2
T 153, 154	221 902	DARLINGTON-TRANSISTOR	PNP BDW 84 C	2
C 153	220 333	MET.-CAPACITOR	0,22 μ F 63 V	1
C 152	220 162	LYTIC	10 μ F 63 V	1
C 154	220 396	LYTIC	4700 μ F 50 V	1
C 150, 151	220 436	LYTIC	4700 μ F 63 V	2
R 166	221 094	RESISTOR	2,7 OHM 1/4 W	1
R 152, 153	221 096	RESISTOR	56 OHM 1/4 W	2
R 151	231 154	RESISTOR	750 OHM 1/4 W	1
R 159-162	221 029	RESISTOR	1 KOHM 1/4 W	4
R 164	221 032	RESISTOR	2,7 KOHM 1/4 W	1
R 163	221 034	RESISTOR	4,7 KOHM 1/4 W	1
R 154	221 625	RESISTOR	5,6 KOHM 1/4 W	1
R 165	221 604	RESISTOR	22 KOHM 1/4 W	1
R 167	221 267	WIRE WOUND RESISTOR	470 OHM 1 W	1
R 155-158	221 275	WIRE WOUND RESISTOR	0,22 OHM 7 W	4
R 150	221 305	TRIMMER RESISTOR	2,2 KOHM 0,1 W	1



Thermoschalter TEMPERATURE SWITCH

CENTRALE
linker Kanal Stecker ST 210
LEFT CHANNEL PLUG ST 210
rechter Kanal Stecker ST 211
RIGHT CHANNEL PLUG ST 211



- 1/4 W
- 1/2 W
- 1 W
- 5 W


ZD ZENER-DIODE

LD Leuchtdiode
LIGHT EMITTING DIODE

Draufsicht
TOP VIEW



von unten gesehen
BOTTOM VIEW



NF-Pegel bei 1 KHz, Lautstärksteller auf max.
Höhen und Bässe max., ohne (CD/mix) AVC gemessen mit elektron. Voltmeter.
Gleichspannung gemessen mit Voltmeter Ri = 10 MΩ

AC SIGNAL VOLTAGES AT 1000 cps, VOLUME CONTROL TO MAX. TREBLES AND
BASSES MAX., WITHOUT (CD/ WITH) AVC MEASURED WITH ELECTRONIC VOLTMETER.
DC VOLTAGES MEASURED WITH VOLTMETER Ri = 10 MEG OHMS.

Alle Sicherungen träge!
ALL FUSES SLD BLO!

Sicherungen nur durch solche mit gleichen Werten ersetzen!
REPLACE FUSES ONLY BY THOSE OF THE SAME VALUE!

ÄNDERUNGEN IM SINNE DES TECHN. FORTSCHRITTES VORBEHALTEN,
JEDDOCH KEINE NACHRÜSTPFLICHT!

SUBJECT TO TECHNICAL MODIFICATION WITHOUT OBLIGATION
TO MODIFY EQUIPMENT ALREADY DELIVERED-!



MUSIKAUTOMATEN
PHONOGRAPHS

ES IV-CD TECHNOLOGY

Schaltbild Endstufe
WIRING DIAGRAM OUTPUT STAGE

Dat.	Ver.	Gezeichnet	Geprüft
27.01.89	Brown	Lamm	Manacher

UNIT DESCRIPTION

CD CHANGER

FOR NSM-PHONOGRAPHS

ES IV-CD TECHNOLOGY



INDEX

- 1. PICKUP FUNCTION
 - 1.1. Transport
 - 1.2. Pull holder
 - 1.3. Return holder
- 2. PICKUP DRIVER
 - 2.1. Lift control
 - 2.2. Grip control
 - 2.3. CD-Player control
- 3. PLAYER
 - 3.1. Disc player CDM 3
 - 3.2. Servo panel
- 4. PCB DECODER BOARD
- 5. MAGAZINE

Spare parts lists
Schematics CD changer 100
Wiring diagram PICKUP DRIVER

1. PICKUP FUNCTION

The pickup serves to transport the CD's between the magazines and the player.

ATTENTION! When the CD changer has the switch at the window (upper right), the transport does not function if the window is open.

If the window is opened while the CD is playing, the title will be played to the end, but the CD will only be transported back after the window is closed.

1.1 Transport

The lift is moved via a stepping motor controlled by the micro-processor of the control unit. The distance between 2 CD slots is 8 motor steps (1 opto counter step).

During the run the light barrier OPTSP, which is directly connected to the drivewheel, checks the motor's position every 4 steps. Stepping errors are immediately recognized and displayed with Er 75.

Together with the light barrier OPEND the end position of the lift is verified. Should a mistake appear here (signal too late or early) the display shows Er 76.

1.2 Pull Holder

With both grip levers, brought into lock position by DC motors MOGRL for left and MOGRR for right, the CD holders with their CD's are pulled out of the magazine. The light barrier OPPUM reports the correct position of the CD holder in the pickup unit.

If there is no report 2 sec. after switching on the motor, the display will show Er 71 for the left magazine or Er 72 for the right magazine.

1.3 Return Holder

To return a CD holder to its magazine, either motor MOGRL for the left magazine or MOGRR for the right magazine is switched on in the opposite direction.

Light barriers OPGRL or OPGRR report the end position of the grips.

If the report does not appear within 2 sec. after switching on the motor, the display shows Er 73 for the left magazine or Er 74 for the right magazine.

2.1. PICKUP DRIVER

2.1 Lift Control

With output port IC3 the microprocessor of the control unit controls switch transistors T2-T5 via drivers T6-T9. These drive the unipolar coil of the stepping motor (ST4, Pin 1-6). Using signal OPSTP (ST4, Pin 7) the microprocessor controls the position of the motors.

Together with signal OPEND (ST 3, Pin 8) the end position of the lift is reported via input port IC 1.

2.2 Grip Control

Both of the grip motors (MOGRL for the left magazine and MOGRR for the right magazine) are driven from the double motor bridge IC6 via output port IC3.

While pulling a CD from the magazine the signal OPPUM (ST 3, Pin 7) reports the end position of the CD holder in the pickup to the microprocessor of the control unit.

While returning the CD it recognizes the end position of the grips via signals OPGRL (ST 3, Pin 5) for left and OPGRR (ST 3, Pin 6) for right.

2.3 Control of the CD Player

Microcomputer IC 8 (T018) is used to convert the incoming serial data in I2C-Bus format from the decoder panel into parallel signals that can be processed.

The microprocessor of the control unit communicates with it via ports IC 4 and IC 2.

3. PLAYER

3.1 Disc Player CDM3

The CDM3 contains the components laser diode, play motor, radial motor, and focus unit.
It reads the data from the CD.

3.2 Servo Panel

The servo panel contains the components to control the CDM3. They consist primarily of the photodiode signal processor, the radial error processor, the drivers for the laser diode, the focus unit, the radial motor and the playing motor.



4. PCB DECODER BOARD

The components servoprocessor, decoder, digital filter, DA converter and NF output driver are combined on the decoder board. It also contains the circuit to process the complete power supply for decoder board CDM3 and servopanel.

5. MAGAZINES


2 equal magazines that are equipped with 50 CD holders each are in the CD changer. With different CD holders it is possible to play 5- or 3-inch CD's.

The magazine can be swung out and totally taken out. Equipping with or changing CD's can be done simply by taking out the respective CD holders, inserting the new CD into the holder and pushing it back till it locks in the magazine.



SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
	173 470	<u>CD-CHANGER 100, STANDARD</u>	without design parts magazines	1
800	173 487	CABINET, welded		1
801	174 296	CLOSING LEDGE, left upper		1
802	174 297	CLOSING LEDGE, right upper		1
803	174 294	CLOSING LEDGE, left lower		1
804	174 295	CLOSING LEDGE, right lower		1
805	173 485	CONTROL KNOB		2
806	206 655	CONNECTION AXLE		2
807	222 531	MICRO SWITCH f. CONNec. BLOCK	E 63 - 10 K	1
808	174 293	FLAT SPRING for VIEW GLASS		2
809	173 538	SCREW SLEEVE, ASSY		2
810	173 522	STEP WHEEL, MOUNTED		1
811	173 521	WASHER 48		1
812	173 526	BOARD WASHER		1
813	173 558	AXLE		1
814	173 559	GUIDE AXLE		1
	174 275	VIEW GLASS, MOUNTED	GALAXY	
	174 276	VIEW GLASS, MOUNTED	FIRE	1
	174 277	VIEW GLASS, MOUNTED	HIDE-AWAY	
	173 635	LIGHTING, ASSY		1
815	173 491	MAGAZINE LEFT, MOUNTED	without CASSETTE	1
	209 737	NUMBER STRIP, 01-50		2
816	173 499	MAGAZINE RIGHT, MOUNTED	without CASSETTE	1
	209 779	NUMBER STRIP, 51-100		2
817	174 536	CASSETTE CD 120	only 10 piece	
	174 537	CASSETTE CD 80		
	212 425	TRANSPORT GUIDE for CASSETTE		2
818	173 551	PLAY BACK UNIT, ASSY	with CD-PLAYER	1
819	173 518	STEP MOTOR, ASSY		1
820	206 644	BELT	MXL 195	1
821	206 643	BELT	MXL	1
822	173 607	LIFT, ASSY		1
	206 629	RUBBER RING		1
	209 776	LABEL	NSM 100 CD	1
	174 220	DECOR COVER		1
823	173 614	BELT LOCK		1
824	173 581	LIFT AXLE		1
825	173 606	MOTOR, ASSY		2
826	173 630	GEAR, MOUNTED		2
	173 552	CB - CASSETTCONTROL, ASSY		1
	173 563	CB - STEPPER, ASSY		1
	173 507	CB - DECODER BOARD, ASSY		1
	173 665	CB - PICK UP DRIVER, ASSY		1
	173 510	CB - LIFT ADAPTER, ASSY		1
	173 557	CB - MOTORCONTROL, ASSY		2
	173 508	CB - CHANGER ADAPTER, ASSY		1




SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
	173 665	CB - PICK UP DRIVER, ASSY		1
ST 08	225 392	PIN PLUG	2 PRONGS 90°	1
ST 03	225 912	PIN PLUG	14 PRONGS	1
ST 07	225 650	PIN PANEL	2 PRONGS	1
ST 05	225 850	PIN PANEL	5 PRONGS	1
ST 02	225 653	PIN PANEL	8 PRONGS	1
ST 01	225 654	PIN PANEL	10 PRONGS	1
ST 04	225 655	PIN PANEL	12 PRONGS	1
Q 1	221 535	OSCILLATOR QUARTZ	4 MHz	1
IC 8	222 447	IC-SOCKET	28 PRONGS	1
	231 409	IC-MICROCOMPUTER	MAB 8441	1
			T 018	
IC 6	231 303	IC-LINEAR	L 298	1
IC 3, 4	221 771	IC-CMOS	HEF 4094 B	2
IC 1, 2	221 763	IC-CMOS	HEF 4021 B	2
D 14-16, 17	221 114	SI-DIODE	1 N 4148	4
D 2-13	221 822	SI-DIODE	BA 157	12
D 18, 19	221 115	SI-DIODE	1 N 4004	2
ZD 1, 2	231 326	ZENER-DIODE	ZY 24	2
T 11, 14	221 283	SI-TRANSISTOR	BC 212 B	2
T 6-9, 12	221 757	SI-TRANSISTOR	BC 547 B	5
T 2-5	221 777	SI-TRANSISTOR	BD 679	4
T 10	231 150	SI-TRANSISTOR	TIP 130	1
C 19, 20	220 266	CER.-CAPACITOR	27 pF	2
C 12	220 342	CER.-CAPACITOR	100 pF	1
C 5-8, 22	220 334	MKT-CAPACITOR	0,1 µF 63 V	5
C 4	220 332	MKT-CAPACITOR	0,33 µF 63 V	1
C 21	220 249	LYTIC	1 µF 63 V	1
C 18	220 389	LYTIC	47 µF 10 V	1
C 3	220 160	LYTIC	100 µF 10 V	1
C 2	220 391	LYTIC	220 µF 25 V	1
C 1	220 165	LYTIC	470 µF 40 V	1
R 64	221 606	RESISTOR	47 OHM 1/4 W	1
R 25, 54	221 600	RESISTOR	100 OHM 1/4 W	2
R 35	221 632	RESISTOR	160 OHM 1/4 W	1
R 37-40	221 614	RESISTOR	330 OHM 1/4 W	4
R 56, 67	221 099	RESISTOR	470 OHM 1/4 W	2
R 45, 49	221 029	RESISTOR	1 KOHM 1/4 W	2
R 27-29	221 033	RESISTOR	3,3 KOHM 1/4 W	3
R 46, 47	221 034	RESISTOR	4,7 KOhm 1/4 W	2
R26,41-44,68,69	221 035	RESISTOR	10 KOHM 1/4 W	7
R 5-12	221 603	RESISTOR	12 KOHM 1/4 W	8
R13-20, 55	221 036	RESISTOR	15 KOHM 1/4 W	9
R21-23,59-63	221 604	RESISTOR	22 KOHM 1/4 W	8
R 24	221 048	RESISTOR	100 KOHM 1/4 W	1
R 48	221 009	RESISTOR	1 MOHM 1/4 W	1
R 3	221 392	RESISTOR	390 OHM 1/2 W	1
R 1, 36, 65	221 692	WIRE WOUND RESISTOR	1 OHM 1 W	3
R 66	231 418	WIRE WOUND RESISTOR	2,7 OHM 1 W	1


SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
	173 508	<u>CB - CHANGER APAPTER, ASSY</u>		1
ST 3	225 418	PIN PLUG	4 PRONGS	1
ST 2	225 412	PIN PLUG	4 PRONGS 90°	1
ST 12	225 660	PIN PANEL	2 PRONGS 90°	1
ST 1	225 661	PIN PANEL	4 PRONGS 90°	1
ST 9	225 652	PIN PANEL	6 PRONGS	1
ST 10	225 662	PIN PANEL	6 PRONGS 90°	1
ST 7, 11	225 653	PIN PANEL	8 PRONGS	2
ST 6	225 663	PIN PANEL	8 PRONGS 90°	1
ST 5	225 654	PIN PANEL	10 PRONGS	1
ST 4	225 664	PIN PANEL	10 PRONGS 90°	1
ST 8	225 655	PIN PANEL	12 PRONGS	1



SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
	173 510	<u>CB - LIFT ADAPTER, ASSY</u>		1
ST 2	225 892	PLUG	14 PRONGS	1
ST 1	222 445	IC-SOCKET	16 PRONGS	1
OPEND	231 322	OPTO-COUPLER	LTH-301	1



SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
	173 563	<u>CB - STEPPER, ASSY</u>		1
	231 322	OPTO-COUPLER	LTH-301	1
	112 464	CABLE HARNESS	4-PRONGS	1
	173 557	<u>CB - MOTORCONTROL, ASSY</u>		1
	231 322	OPTO-COUPLER	LTH-301	1

SPARE PARTS LIST

POS.	PART-No	DESCRIPTION	DATA	QTY
	173 636	CABLE HARNESS: LIFT		1
	173 639	CABLE HARNESS: PICK UP - CABLE I		1
	173 641	CABLE HARNESS: PICK UP - CABLE II		1
	173 644	CABLE HARNESS: TRAILING CABLE		1
	151 645	CABLE HARNESS: DECODER CABLE I		1
	173 646	CABLE HARNESS: DECODER CABLE II		1
	173 647	CABLE HARNESS: DRIVER CABLE I		1
	173 648	CABLE HARNESS: DRIVER CABLE II		1
	173 649	CABLE HARNESS: DRIVER CABLE III		1
	173 740	CABLE HARNESS: NF - CABLE		1

CD Changer 100

test, set, adjust

6.1. GENERAL INFORMATION

Please note the illustration of the CD changer on the last page regarding the following text.

After exchanging units their functions must be checked and, if needed, certain adjustments must be made.

To exchange the playing unit the CD changer can remain in the phonograph. But to remove or install the lift the changer has to be removed from the machine; tests and adjustments are only possible at a bench tester or at the machine with appropriate extensions!

Take care that the changer is set down on supports so that the board disc (12) or the main axle (14) which protrude from the cabinet floor are not pushed inside. Otherwise the board disc will jam the gear belt (2); a displaced axle changes the position of the upper distance sleeve so that the lift drives against it and blocks!

In service program step P60, Pt. 1.5.5 "Test CD Changer" the grips can be moved left or right with Keys "4"/"5" or "6"/"5" and the lift can be moved up or down with key "2"/"8". With Key 1 the CD player can be started and stopped.

For fine adjustments of the lift position the lift can be moved with Key "3" (+) or "9" (-) one motor step at a time (equals about 0,5 mm height difference) either up or down; this option is available for ES-IV CD phonographs as of Program Index 004. The distance between two magazine slots is 8 motor steps (or 1 opto step).

In the displays the present status of the respective opto mask and the time in seconds during which the lift position is held are shown.

6.2. MAGAZINE

The magazines in swung-in and locked position are supported by height-adjustable studs. Changing the height setting can be necessary when the lift is exchanged; setting see Pt. 4 "Lift."

6.3. PLAYING UNIT

To exchange the playing unit with CD player

- * remove both magazines
- * pull lift up on belts
- * swing support clamps on chassis of playing unit out
- * carefully(!) pick up playing unit, watch balance washers under cabinet
- * open plug connections
- * installation of playing unit in opposite sequence
- * function test:
 - remove decorative cover (01) and check if axle of suspension plate is in the center of the upper lift bore.
 - choose CD, check if CD is securely clamped in play position.
 - further tests see Pt. 4 "Lift."



6.4. LIFT

To exchange the lift as well as to check and adjust the opto coupler of the CD changer, completely remove the CD changer, disconnect cables, remove rear wall.


- * From the rear side of the machine pull lift (04) up by the gear belt (02), interrupt connection between lift and gear belt by unscrewing the gear belt lock (03).
- * Pull out plug of connecting cable (06).
- * Remove board disc (12) after removal of washer.
- * Pull distance sleeve (13) at bottom of main axle (14) from cabinet floor upwards; remove securing clamp of main axle from inside of cabinet.
- * Remove securing clamp of guiding axle (10) from inside of cabinet.
- * Pull guiding axle down through floor of cabinet.
- * Push main axle down until upper distance sleeve can be removed.

If main axle is pulled out all the way, do not mistake upper and lower distance sleeves; they are of different length!

- * Remove lift; mount exchange lift in opposite sequence.
- * Function test, basic setting; CD changer must be completely connected to operate either with extensions to phonographs or a bench tester:
 - turn on test program P60/5, "test CD changer" F5. All functions of the changer can be checked, see excerpt of service program below:

All functions of the changer can be tested individually.																						
CD changer test	Enter "5" and "H", Display 2 "F 5". <table border="1"> <thead> <tr> <th>Input</th> <th>Function</th> </tr> </thead> <tbody> <tr><td>1</td><td>CD-Player, Start/Stop</td></tr> <tr><td>2</td><td>Lift upwards</td></tr> <tr><td>8</td><td>Lift downwards</td></tr> <tr><td>4</td><td>Grip left</td></tr> <tr><td>6</td><td>Grip right</td></tr> <tr><td>5</td><td>Return holder</td></tr> <tr><td>0</td><td>Stop lift at magazine space</td></tr> <tr><td>3 : :</td><td>Motor steps, upwards (per 0,5 mm)</td></tr> <tr><td>9 : :</td><td>Motor steps, downwards (per 0,5 mm)</td></tr> </tbody> </table>	Input	Function	1	CD-Player, Start/Stop	2	Lift upwards	8	Lift downwards	4	Grip left	6	Grip right	5	Return holder	0	Stop lift at magazine space	3 : :	Motor steps, upwards (per 0,5 mm)	9 : :	Motor steps, downwards (per 0,5 mm)	Keep in mind the code numbers for the individual changer functions as per the following keyboard illustration: 
	Input	Function																				
1	CD-Player, Start/Stop																					
2	Lift upwards																					
8	Lift downwards																					
4	Grip left																					
6	Grip right																					
5	Return holder																					
0	Stop lift at magazine space																					
3 : :	Motor steps, upwards (per 0,5 mm)																					
9 : :	Motor steps, downwards (per 0,5 mm)																					
<div>Displays:</div> 	The time in sec. during which the lift position is held. The lift position is held after every function for 2 sec., by touching "0" for 10 sec. <table border="0"> <tr> <td>OPTO stepper control</td> <td>OPSTP</td> </tr> <tr> <td>OPTO end position</td> <td>OPEND</td> </tr> <tr> <td>OPTO grip right</td> <td>OPGRR</td> </tr> <tr> <td>OPTO pickup center</td> <td>OPPUM</td> </tr> <tr> <td>OPTO grip left</td> <td>OPGRL</td> </tr> </table>		OPTO stepper control	OPSTP	OPTO end position	OPEND	OPTO grip right	OPGRR	OPTO pickup center	OPPUM	OPTO grip left	OPGRL										
OPTO stepper control	OPSTP																					
OPTO end position	OPEND																					
OPTO grip right	OPGRR																					
OPTO pickup center	OPPUM																					
OPTO grip left	OPGRL																					
Meaning of displays: OPTO lit up = "0", OPTO darkened = "1".																						
Terminate test.	Actuate housing switch.																					

- The basic setting occurs in parked position at Magazine Slot 25/75. Drive pick-up to this position with Keys "2" and "8."
The lift is held after each function in this position for 2 sec.; with Key "0" for 10 sec.
- Drive cassette in and out with Keys "4"/"5" or "6"/"5."
Check function for smooth movement.
The respective grip lever must fall into the cassette w/o hindrance!
- To adjust lift height loosen belt lock and move up or down; then tighten screws!
- Move lift down one motor step (about 0,5 mm height difference) with Key "9" (-); same test for smooth movement.
- Drive to normal park position with key "0" and with Key "3" (+); switch lift one motor step above normal position. Same check for smooth movement.
- Set magazine height: If magazine slots do not align with lift, then adjust lift only to one magazine at first. After that the other magazine is adjusted with support screw (11/15) to the correct height.
- The light barrier (08) on the step motor must in parked position 25/75 be in the center of the opto scanner OPSTP (09) (status display of OPSTP in display = "1"). If necessary, loosen screw on hexagon bolt and set PCB with opto coupler to center of mask.
- To adjust opto coupler OPEND (05) lift must be driven down to bottom. Drive lift upwards with Key "3" (press 4 times) or manually with one half opto step; the mask (16) must release OPEND (05) when OPSTP (09) opens the light mask, displayed by "0." Adjustment done by shifting of light mask angle (16) of OPEND, displayed by transition of "0" to "1" or "1" to "0."
- Select CD in normal program. In the parked position of the playing position the lift must have a gap to the lower end position.
- The distance between a cassette and the clamping dish should be at least 1 mm during a gripping procedure. So that the clamping dish can be magnetically attracted, the decorative cover must be in place.
- The CD must run w/o touch and grinding sounds when in a suspended position.
To test the function get cassette with CD from magazine by pressing correct keys and place it on CD player in play position.
Turn on CD player with Key "1." After test with Key "1" or any of the other function test keys turn off CD player.
The clamping dish must clamp down on CD exactly in center.
- Check function of fork light masks OPGRR, OPGRL, OPPUM as per test "F5." The respective mask must cover the light barrier in its entire breadth when Status Display "1" is shown and may not touch the housing physically.



CD CHANGER, COMPL.


OP END OPTO END POSITION
 OP GRL OPTO GREIFER LINKS
 OPTO GRASP LEFT
 OP GRR OPTO GREIFER RECHTS
 OPTO GRASP RIGHT
 OP PUM OPTO PICK UP MITTE
 OPTO PICK UP CENTER
 OP STP OPTO STEPPER CONTROL
 MO GRL MOTOR GREIFER LINKS
 MOTOR GRASP LEFT
 MO GRR MOTOR GREIFER RECHTS
 MOTOR GRASP RIGHT

Draufsicht
 TOP VIEW
 LTH 301

Motor rechts
 MOTOR RIGHT
 MO GRR




MOTOR CONTROL
 OP GRR




CD-PLAYER

MOTOR CONTROL
 OP GRL




Motor links
 MOTOR LEFT
 MO GRL




LIFT-ADAPTER

CASSET CONTROL
 OP PUM







DECODER BOARD

Beleuchtung
 ILLUMINATION



PICK UP - DRIVER

WECHSLER - ADAPTER
 CHANGER



ÄNDERUNGEN IM SINNE DES TECH. FORTSCHRITTES VORBEHALTEN,
 JEDOCH KEINE NACHTRISTPFLICHT!
 SUBJECT TO TECHNICAL MODIFICATION WITHOUT OBLIGATION
 TO MODIFY EQUIPMENT ALREADY DELIVERED!




MUSIKAUTOMATEN
 PHONOGRAPHS

ES IV - CD TECHNOLOGY

ELEKTROPLAN CD-WECHSLER
 OPERATING SCHEME CD-CHANGER

Dat. 01.09.89 Gez. Braun Bearb. K. Kopr. M. M.

209 809 A



WECHSLER - ADAPTER


Stecker ST8
PLUG ST8

- 1/4 W
- 1/2 W
- 1 W
- 1N4148
- ZENER CODE

Druckseite
TOP VIEW



von unten gesehen
BOTTOM VIEW



LIFT - ADAPTER

Stecker ST2
PLUG ST2

- OP END OP10 END POSITION
- OP GR1 OP10 GREIFER LINKS
OP10 GRASP LEFT
- OP GR2 OP10 GREIFER RECHTS
OP10 GRASP RIGHT
- OP PLM OP10 PICK UP MITTE
OP10 PICK UP CENTER
- OP STP OP10 STEPPER CONTROL
- MOGR1 MO10 GREIFER LINKS
MO10 GRASP LEFT
- MOGR2 MO10 GREIFER RECHTS
MO10 GRASP RIGHT

gerasterte Bauteile sind nicht bestückt!
DOTTED COMPONENTS ARE NOT INSTALLED!

ÄNDERUNGEN IM SINNE DES TECHN. FORTSCHRITTES VORBEHALTEN,
JEDOCH KEINE NACHRUFPLICHT!
SUBJECT TO TECHNICAL MODIFICATION WITHOUT OBLIGATION
TO MODIFY EQUIPMENT ALREADY DELIVERED!

MUSIKAUTOMATEN
PHONOGRAPHS

ES IV - CD TECHNOLOGY

Schaltbild
WIRING DIAGRAM

PICK UP - DRIVER

Verf. 16.02.89	Gez. Braun	Gez. Braun	Gez. Braun
----------------	------------	------------	------------

209 810

UNIT DESCRIPTION

REMOTE CONTROL


FOR NSM-PHONOGRAPHS

ES IV-CD TECHNOLOGY



INDEX

- 1. FUNCTION
 - 1.1. Infrared remote control (wireless)
 - 1.2. Wired remote control
 - 1.3. Installation instructions for infrared remote control
 - 1.4. Volume control (on rear cabinet wall)




INFRARED REMOTE CONTROL, ASSY.

Part No.	171 808
with sender	217 817
Receiver	173 178
and connection cable (standard)	171 883
Connection cable (5 m)	170 459

REMOTE CONTROL with 5 m cable

Part No.	171 743
----------	---------



VOLUME CONRTOL (rear wall of box; although not in wallboxes or Hide-Away's).

Part No.	170 212
----------	---------

1. FUNCTION

1.1. Infrared remote control (wireless)

The cable of the remote control receiver has to be put into plug ST 205 of the central unit.

Pin 1 supplies the + 15 V voltage.

Pin 2 = GND

The commands - as per chart - are fed to the computer inputs via Pins 3 through 6 by switching to ground.

The signals go to the control unit via plug ST 201.

1.2. Wired remote control

For remote controls with cable the plug has to be connected with ST 205 on the central unit (instead of infrared remote control). The corresponding channels (Pins 3 through 6) - as per chart - are connected to GND Pin 2 via the remote control diode linkage.

TASTE / KEY	AUSGANGS- OUTPUT- CODE	STECKER / PLUG ST 205 / PIN
VOLUME - I	2 / 4	5 / 3
VOLUME + I	4	3
VOLUME - II	2 / 3	5 / 4
VOLUME + II	3	4
FREE CREDIT	1 / 3	6 / 4
BACKGROUND	1 / 4	6 / 3
REJECT	2	5
MUTING	1	6
VOLUME + (I+II)	3 / 4	4 / 3
VOLUME - (I+II)	2 / 3 / 4	5 / 4 / 3

1.3. Installation Instructions for Infrared Remote Control

The receiver with standard connection cable is mounted onto the back of the cabinet or the back of the hood when a small distance is involved. The top (receiving side) of the receiver should be mounted a little underneath the upper edge of the rear cabinet. Wallboxes and Hide-Away's have to be mounted close to the machine.

If a greater distance has to be bridged or an absorbing ceiling is influencing correct functioning the receiver has to be mounted in such a way on the wall or the ceiling that direct radiating of the manual sender is possible. A connection cable (5 m), Part. Nr. 170 459, is available for this purpose.

The connection cable of the receiver is put into plug S 205 of the central unit.

SECURING MANUAL SENDER

To protect the manual sender from theft, mount the bracket with two screws onto the back of the sender (see fig.). This way the sender can be secured with a chain.




Fig. 1




Fig. 2

Manual sender with safety bracket and screws

1.4. Volume Control (On Rear Cabinet Wall does not apply to wallboxes and Hide-Away's.

The connection cable must be put into plug ST 206 of the central unit. When the volume keys are pressed, the computer inputs are switched to GND via the diode linkage D 213 - D 217.

TASTE / KEY	AUSGANGS- OUTPUT- CODE	STECKER / PLUG ST 204 / PIN
VOLUME + (I+II)	3 / 4	3 / 2
VOLUME - (I+II)	2 / 3 / 4	4 / 3 / 2
REJECT	2	4

UNIT DESCRIPTION

OUTPUT TRANSFORMER

FOR NSM-PHONOGRAPHS

ES IV-CD TECHNOLOGY



NSM
APPARATEBAU
GmbH & Co. KG
6530 Bingen
Saarlandstraße 240
Telefon 067 21 / 4070

PART-№
209 829 A


OUTPUT TRANSFORMER with cable harness

Part. No. 172 431


The output transformer is connected directly to the terminals of the output amplifier. It has an input impedance of 4 ohms and transforms the input voltage down so that smaller output voltages are available at Connection Terminals 1 through 5 permitting speakers with lower impedances to be connected.

A number of loudspeakers can be connected together (in parallel) up to a total maximum power of ~130 W music power per channel; depending on how much power is taken directly from the amplifier.

The table below shows the power required for a loudspeaker with the corresponding impedance at Connection Terminals 0-1 through 0-5. Also observe the output transformer diagram and connection schematics. Further information is given in the "TECHNICAL INSTRUCTIONS" under "Loudspeaker Connection".



Anschlußschema für Ausgangsübertrager
CONNECTION DIAGRAM FOR OUTPUT TRANSFORMER



Klemme TERMINAL POSITION	Lautsprecher SPEAKER			
	2,5 Ω	4 Ω	8 Ω	16 Ω
0 - 5	100 W	70 W	45 W	22 W
0 - 4	48 W	30 W	16 W	8 W
0 - 3	24 W	15 W	8 W	4 W
0 - 2	12 W	7,5 W	4 W	2 W
0 - 1	3 W	1,8 W	1 W	0,5 W

Maximum Power Output Connections

The maximum power output of the amplifier is 2x200 W music power at 2 ohms.

The following is an example of how to connect external loudspeakers to the "CD GALAXY": The phonograph itself consumes (when directly connected at 5,5 ohm impedance) 2x70 watts.

Therefore, 2x130 W is still available for external loudspeakers.

For example, two 4-ohm loudspeakers each can be connected to Terminals 0-5 (see diagram) or four loudspeakers (with 4 ohms each) can be connected to Terminals 0-4.

Example for connection of wallboxes or Hide-Away's

If loudspeakers with 4 ohm are connected directly to a wallbox or Hide-Away, the consumption is 100 watts; therefore, there is only 100 watts left for the loudspeaker connected to the transformer.

Connection for Lower Phonograph Output Power

When full power is not required from the phonograph, it can be connected to the corresponding terminals of the transformer and external loudspeakers can then be connected directly to the output amplifier for higher output.

70 V - High Voltage Output

Additionally, the transformer also has a 70 V high-voltage output (A1-B1/A2-B2) for each channel.


These features are provided for operation of a widespread external loudspeaker system whereby the higher voltages keep the line losses low. Only loudspeakers with input transformers (socalled high-impedance loudspeakers of 50 ohms upwards) can be connected to this terminal. These outputs also provide a maximum of 100 W music power each, e.g. two 50 W loudspeakers (200 ohms) can be connected to each channel.

Lautsprecher-Impedanz Loudspeaker -Impedance	Ausgangsleistung A1-B1 Output power A2-B2
50 Ohm	100 W
100 Ohm	50 W
150 Ohm	35 W
200 Ohm	28 W
250 Ohm	20 W

The total wattage of all remote loudspeakers connected to one channel of the output transformer (whether low impedance, high impedance or combined) may not exceed max. 130 W.


HV - MONO Mode

Since the high-voltage coils are connected with their center, a loudspeaker connected to A1-B2 or B1-A2 radiates sound from both (stereo) channels; for this mono mode no special NF-coupling of the channels is necessary, coupling is provided by the transformer.



HV - STEREO Mode

If the loudspeakers are connected to A1-B1 and A2-B2, stereo mode is possible, but without NF-coupling of the channels.



TROUBLE SHOOTING

FOR NSM-PHONOGRAPHS

ES IV-CD TECHNOLOGY



INDEX

- 1. TROUBLE SHOOTING
 - 1.1. Description of malfunction/cause
 - 1.2. Error displays
 - 1.3. Trouble shooting for NSM phonographs ES-IV/CD technology

I. TROUBLE SHOOTING

I.1. Description of malfunction/cause

DESCRIPTION	CAUSE
Phonograph illumination and LED's in central unit/CD supply do not light up.	<ol style="list-style-type: none"> 1. Power cord 2. Main switch 3. Power fuse (switch plate/fuse box)
Phonograph illumination okay, LED's in central unit do not light up.	<ol style="list-style-type: none"> 1. Plug connection ST 200 of central unit 2. Fuses Si 201-205 of central unit 3. Power transformer connection
Luminous effect lights do not light up. (Only for phonographs with light generator)	<ol style="list-style-type: none"> 1. Fuse T 8 A on switch plate 2. Fuses Si 701-703 as well as 3. Plug connection of luminous effects PCB
Fan for output stage does not run while disc is playing.	<ol style="list-style-type: none"> 1. Plug connection ST 209 2. Triac TIC 200 3. Transistors T 204/205
+5 V; +15 V LED's in central unit do not light up or are darker Fuses are okay	<ol style="list-style-type: none"> 1. Voltage regulators VR 201-203 in central unit defective 2. Short circuit in connected units. (Pull plugs one after another and observe LED's)
No tone signal at loudspeaker even though a CD is playing and the volume is switched on.	<ol style="list-style-type: none"> 1. Loudspeaker connection 2. Plug connection of frequency network and output transformer 3. Interruption on signal wire (plug connection "ST" 4 pol. of central unit to "ST 2" on changer adapter, from "ST 3" on changer adapter to decoder board).
Volume reduced by electronic protection device	<ol style="list-style-type: none"> 1. Loudspeaker mismatch (less than 2 ohms impedance) due to remote speakers. 2. Transistor T 252 defective 3. Output transistor defective 4. Control unit defective
Poor bass reproduction	Loudspeaker connections reversed
Er xx-display	See "Error Displays"

1.2. Error Displays

Displays 1 2 3			Possible Causes	Corrections
	Er	01	EPROM contents (CONTROL UNIT) interrupted.	Change EPROM (IC 2).
	Er	10	RAM (CONTROL UNIT) defective.	Change RAM (IC 3). After that reprogram all program steps (P20-P56).
	Er	11	RAM contents (CONTROL UNIT) short-term disturbance.	No correction necessary; program is teinitialized. Change RAM IC 3 if frequently occurring.
	Er	20	Verification errors in program (CONTROL UNIT).	No correction necessary; program is reinitialized. Change CPU IC 1 if frequently occurring.
Pxx	Er	30	Memory contents (CONTROL UNIT) invalid.	No correction necessary; program step Pxx (in Display 1) is automatically reprogrammed.
Pxx	Er	31	Memory contents (CONTROL UNIT) invalid or not programmed.	Service step Pxx shown in Display 1 must be reprogrammed.
Pxx	Er	40	Wrong price setting.	Check price setting and, if necessary, reprogram (P41-P45, check sequence).
	Er	50	Coin mechanism defective. Too much credit.	Check coin mechanism.
	Er	6x	Error at CD player.	See Er 60 - Er 62. Play interrupted after error.
	Er	60	Error before playing CD (track selection).	Exchange decoder board, microcomputer T018 on pickup driver (IC8).
	Er	61	No CD recognized by player. No CD in CD tray, CD defective. Player defective. Decoder board defective.	Check CD and exchange if needed. Laser player (CDM-3). Exchange decoder board.
	Er	62	Error after playing CD (stop).	As in Er 60.
	Er	63	Track cannot be played (CD defective) or choosing a track number which is too high (error display appears only during continuous test P 60/3 or P 60/4; during regular operation track No. 1 is played when choosing a track number which is too high).	Exchange CD, check track selection.
	Er	7x	Malfunction on CD changer.	See Er 70 - Er 76. If error display does not disappear after 2 sec., error cannot be automatically corrected. No CD will be played until cabinet switch or "power on" is activated.
	Er	70	CD tray after playing CD incorrect in pickup.	Check function of light barriers OPPUM, OPGRRL, OPGRRL.
	Er	71	Error during grip from left-side magazine.	Check alignment from magazine to pickup assy and adjust if necessary. Check function of light barrier OPPUM.
	Er	72	Error during grip from right-side magazine.	As in Er 71.
	Er	73	Error during replacing in left-side magazine. Malfunction of left grip lever.	Check alignment of magazine to pickup assy and adjust if needed. Check function of grip. Check function of light barrier OPGRRL.
	Er	74	Error during replacing of right-side magazine. Malfunction of right grip lever.	As in Er 73. Check function of light barrier OPGRRL.
	Er	75	Malfunction during lift drive.	Check lift for jamming. Check function and correct adjustment of light barrier OPSTP (drive wheel).
	Er	76	End position of lift not o.k.	Check function and adjustment of light barrier OPEND.
	Er	80	Short circuit on wallbox signal wire.	Check wallbox connection.


The memorized values of program steps P20 to P56 are checked after each "power on" and by activating the cabinet switch.

An error in the programmable memory area the corresponding program steps is show on Display 1; Pxx Er 31; the "error" lamp flashes.

After the phonograph is turned on, the malfunction display in Display 3 and the flashing of "error" remains visible for 2 sec. After that the phonograph is operational; without regarding the malfunctioning program step, though.

1.3. Trouble-Shooting Chart for NSM Phonographs ES-IV/CD Technology

Conditions: Line voltage present, line connection and power supply in order.



yes
no

1405

Compare also 1.2. "Error Displays".

ACCESSORIES
FOR NSM-PHONOGRAPHS
ES IV-CD TECHNOLOGY



INDEX

1. Microphone with paging switch
2. REMOTE CONTROL WALL BOXES
3. REMOTE CONTROLS
 - 3.1. Infrared remote control
 - 3.2. Remote control with cable
4. TAPE RECORDER CONNECTION CABLE
5. OUTPUT TRANSFORMER with cable harness
6. DOLLAR BILL ACCEPTOR -ARDAC MINI- (only for USA)
 - 6.1. Installation Instructions for DOLLAR BILL ACCEPTOR in "CD GALAXY"
 - 6.2. Installation Instructions for DOLLAR BILL ACCEPTOR in wallbox
7. "NSM DATA PRINT"
 - 7.1. Data transfer and memorizing with NSM DATA PRINT
 - 7.2. Printout on NSM DATA PRINT

1. MICROPHONE with Paging Switch

Part No. 224_223

Socket for microphone

Part No. 225 758

Connection cable with plug
and microphone socket

Part No. 171 880 (10 m)

Plug for central unit

Part No. 225 260

Connection via microphone socket to the central unit.

Microphone announcements are possible in any phonograph mode.

The microphone amplifier with electronic switch-over is integrated into the central unit.

The volume for the background music and microphone can be adjusted separately in the central unit.

2. REMOTE-CONTROL WALLBOXES

"FIRESTREAM" - Part No. 173 600

"CARAVELLE" - Part No. 173 450

For connection to NSM phonographs in CD technology. Connection Adapter belongs to the equipment.

(Part Number see Spare Parts List in "TECHNICAL INSTRUCTIONS")

Detailed installation instructions are included in the adapter kit.

3. REMOTE CONTROLS

3.1. Infrared Remote Control

Part No. 174 258

Wireless remote control consisting of transmitter, receiver and parts for installation. See wiring diagram for connections.

3.2. Remote Control with Cable

Part No. 171 743

The connection points are illustrated in the wiring diagram and described in unit description "REMOTE CONTROL".

4. TAPE RECORDER CONNECTION CABLE

Part No. 172 025

Connection for tape recorders with DIN input and output.
Connection for additional amplifier.

5. OUTPUT TRANSFORMER with cable harness

Part No. 172 431

Significantly expanded adaptation capabilities and low line losses with 70 V output.

(See unit description "OUTPUT TRANSFORMER")

6. DOLLAR BILL ACCEPTOR -ARDAC MINI- (only for USA)

6.1. INSTALLATION INSTRUCTIONS for DOLLAR BILL ACCEPTOR in "CD GALAXY"

- Install chute in place of cover in lid (see Fig. 1).
- Hang dollar bill validator into the 2 attachment studs (Pos. 1).
The unit must be installed so that it does not interfere with the lid when closing - however, the chute must close tightly to the dollar bill validator.
The depth can be adjusted at Pos. 2.
The height should be adjusted at Pos. 3 so that the dollar bill validator is aligned with the chute in the lid and is guided exactly into the acceptor slot (see Fig. 1).
Secure dollar bill validator with sheet metal screws F 3.9 x 6.5 at Pos. 4.
- Install dollar bill adapter PCB (Pos. 6) on 2 spacers with wood-screws to the left inside of cabinet.
- Put 2 contacts from the harness (as can be seen in Fig. 2/ Pos. 5) into Plug Housings 6 and 7 of the 21-pole plug.
- Mount dollar bill electronic (control box) as shown in illustration.
- Make plug connections from dollar bill adapter PCB to the acceptor to the control unit and to the control box; plug connection cable from control box into plug; plug in control box into service socket.
- Program price setting (plays/monetary value) in program step 45, e.g. "07 100" = 7 plays/1 dollar).
- Program monetary value in Program Step 45, e.g. "07 100" = 7 plays/1 dollar.
- Program monetary value for Channel 5 in Program Step 55; e.g. "100" = 1 dollar.

CHUTE
SIDE VIEW




Fig. 1







Fig. 2

6.2. Installation instructions for DOLLAR BILL ACCEPTOR in wallbox "Fire" and remote control wallbox "FIRESTREAM"

- Pull up latch (1) and adjust stacker (2) so it is positioned vertically under the acceptor (3).
- Hang dollar bill validator into the 2 studs (4). The unit must be installed so that it does not interfere with the lid when closing - however, the chute must close tightly to the dollar bill validator. The depth can be adjusted by loosening the three screws (5) and by moving the bracket. The height can be adjusted by loosening the four screws (7) and moving in a vertical direction; bill validator must be aligned with the chute in the lid and guided exactly into the acceptor slot.
- Secure dollar bill with screw M 4 at Pos. 8.
- Move stacker backwards into its final position until the latch (1) locks in at the second position.
- Put the 2 contacts from the harness, as seen in Pos. 9, into plug housings 6 and 7 of the 21-pole plug.
- Mount dollar bill electronic (control box), as shown in illustration, at the top of the cabinet. First push it into rear guide studs, then mount the front side with two screws. The plastic discs serve as spacers between the control box.
- Make plug connections to the acceptor, to the stacker and to the control box. Plug power plug from control box into service socket (10).
- Program price setting (plays/monetary value) in program step 45, e.g. "07 100" = 7 plays/1 dollar.
- Program monetary value for channel 5 in program step 55, e.g. "100" = 1 dollar.
- Lay harnesses so that they do not hinder other units!



7. NSM DATA PRINT (Part Number see Spare Parts List in "TECHNICAL INSTRUCTIONS")

The printer is intended for connection to:

- NSM phonographs ES-IV CD Technology
- A detailed description is included with the printer.
- Putting in the paper roll and color ribbon are described in detail in the TECHNICAL INFORMATION for the NSM DATA PRINT.

7.1. Data Transfer and Memorizing with NSM DATA PRINT

- Turn on service program by opening cabinet and pull out cabinet switch manually, Display 1 "P01".
- Put in printer connector into "Service Socket" of the CONTROL UNIT.
- Enter "C", Display 1 "P".
- Enter "11" and "H", Display "P11".
- Enter Code "1" and "H".

Counters P03 to P08 as well as popularity are transferred.

Note: Display 3 "E0" appears if an error occurs during data transfer. Counters P03 to P08 as well as popularity are reset after successful data transfer.


7.2. Transfer to Printer

- Switch on service program by opening cabinet; if needed, pull the cabinet switch manually, Display 1 "P01".
- Plug printer connector into socket of CONTROL UNIT.
- Enter "C", Display 1 "P".
- Enter "12" and "H", Display 1 "P12".
- Enter code for the desired print-out and press "H".
 - "1" and "H" = Counters (P03 to P08)
 - "2" and "H" = Counters and settings (P03 to P08, P21 to P37, P39)
 - "3" and "H" = Counters and popularity (P03 to P08, P01, P02)
 - "4" and "H" = Counters, settings and popularity (P03 to P08, P21 to P37, P39, P01, P02)

Note: When a popularity counter has reached value 200, all popularity counters are divided by half of the amount. After dividing the popularity printed out is relative; the number of divisions appears in the printout: "RELATIVE 000" to "xxx".

If the printer does not start, "E0" appears in Display 3.

DATA PRINT



8. CD-AUDIO CONNECTION

To connect an amplifier directly to the output of the CD changer an adapter PCB "CD-AUDIO" (Part #174 648) is available.

The NF cable on the CD audio PCB is to be plugged into the "CD" plug of the central unit. The cable from the CD changer is to be plugged into the adapter PCB "CD-AUDIO".

The CD audio PCB is to be fastened with 4 distance holders. The following sketches show possible mounting points.


Ground has to be connected to the metal housing or with wood housings to the next grounded piece of metal.

To connect the external amplifier to the CD-AUDIO high-grade connecting cables with RCA plugs on both ends are available.

Stereo cable set (2 m) Part No. 227 533

Installation
in

CD-GALAXY and CD-HIDE AWAY



NSM-CD FIRE

