

SECTION 4- TROUBLESHOOTING

INTRODUCTION

The phonograph incorporates several modules which plug in for rapid service. The block diagram (pg. 70) shows the modules and the wiring between them. It also shows wiring between modules and components (switches, motors, coils).

The most likely cause of phonograph problems are:

1. Continuous or intermittent opens in harness. The cause can be; the wiring, the terminal, or a bad wire to terminal crimp.
2. A defective module. A list is shown.

It is important to troubleshoot logically so that effort is not wasted in removing and replacing the wrong parts. Most failures are caused by minor defects, such as loose connections or dirty contacts. Check the following before replacing any parts:

1. Check that all plugs are firmly seated.
2. Check that connector pins are not bent, broken or pushed through the back of the connector when mated.
3. Check that wires are not broken at connector pins.

CONTINUOUS FREE PLAY

In some cases, continuous free play operation is desirable. Set the phonograph to "free play" by positioning the "Test-Norm" switch, on the central control computer, to test. This gives continuous credit and selections may be made.

If automatic continuous music is desired set the playmaker switch on the central control computer to "continuous". This will keep the location in Music until repairs can be made.

| PART NO. | DESCRIPTION | NOTES |
|------------|-----------------------------------|--|
| 6-08870-04 | Central Control Computer (C.C.C.) | Module contains Circuit Board Assembly - C.C.C. 6-8871-03 |
| 4-07221-02 | Mechanism Control | Module contains Circuit Board Assembly - Mech Control 6-08709-02 |
| 4-07706-01 | Power Supply | Module contains Circuit Board Assembly 6-09357-01 |
| 6-08878-04 | Pricing Board | Uses pricing inserts |
| 4-07459-01 | Digital Display | |

TROUBLESHOOTING CHARTS

One of the best ways to isolate a problem is to determine the exact state of the phonograph when the failure occurs. This means recording the condition of digital display, status LED's, gripper bow, detent pawl, magazine, cam switches etc.

This information can help you identify the cause of intermittent or continuous failures.

The chart has three columns.
 The trouble column lists different types of failures.
 The symptom column shows the state of the phonograph when the failure occurs.
 The last column shows the probable cause.

| TROUBLE | SYMPTOM | PROBABLE CAUSE |
|---|---|---|
| Phonograph fails to operate when power is turned on | LEDs on power supply and fluorescent lights fail to light. | <ol style="list-style-type: none"> 1. Rear power switch off. 2. Plug not in wall 3. Wall circuit is dead 4. 10 amp circuit breaker tripped 5. Wiring to rear power switch 6. Rear power switch. |
| | LEDs on power supply fail to light but fluorescent lamps lit | <ol style="list-style-type: none"> 1. 2 amp circuit breaker tripped. 2. Power Supply 3. 28 VAC overload from bill acceptor or mag., transfer, or T.T. motor |
| | "+8 VDC" LED on power supply fails to light but lights when phono harness at power supply is unplugged | <ol style="list-style-type: none"> 1. Central Control Computer 2. Mech control 3. Wallbox interface 4. Bill Acceptor 5. On/Service/Off switch 6. Wiring <p>NOTE: To locate problem reconnect phono harness and unplug connectors in order below. If +8 VDC LED lights replace last unit unplugged.</p> <ol style="list-style-type: none"> 1. Wallbox Interface (J103) 2. Central Control Computer (J105) 3. Mech Control Harness (J205) 4. Mech Control (J206) 5. Bill Acceptor |
| | "+28 VDC" LED on Power Supply fails to light but lights when Phono Harness at Power Supply is unplugged | <ol style="list-style-type: none"> 1. Mech Control Board 2. Bill Acceptor 3. Detent Coil 4. Wiring |

| TROUBLE | SYMPTOM | PROBABLE CAUSE |
|---|--|--|
| Magazine does not rotate when power is turned On or a Selection is made | "Mag. Motor" and "Detent" LED's ON, detent is actuated | 1. Wiring to Magazine Motor 2. Magazine Motor 3. Mech. Control Board |
| | "Mag. Motor" and "Detent" LED's ON, Detent not actuated | 1. Wiring to Detent Coil 2. Detent Coil 3. Mech. Control Board |
| | "Mag. Motor" LED OFF or "Detent" LED OFF | 1. Wiring from Central Control Computer to Mech Control Board 2. Central Control Computer 3. Mech. Control Board |
| Magazine Rotates Continuously | "Mag Motor" LED OFF | 1. Wiring to Magazine Motor 2. Mech. Control Board |
| | "Mag. Motor" LED ON, and "Opt. Sw. Index" LED not flashing, and/or "Opt. Sw. Home" LED does not flash at record number 99. | 1. Optical Switch 2. Wiring to Optical Switch 3. Mech. Control Board 4. Optical Switch or Home Position Blocked |
| | "Mag. Motor" LED on and both Optical Sw. LED's Normal | 1. Wiring from Central Control Computer to Mech Control Board |
| Record does not Transfer | "Tran. Motor" LED is ON | 1. Wiring to Transfer Motor 2. Mech. Control Board 3. Transfer Motor |
| | "Tran. Motor" LED is OFF | 1. Wiring from Central Control Computer to Mech Control Board 2. Central Control Computer 3. Mech. Control Board |
| | "Tran. Motor" LED comes ON and transfer starts but LED and Motor turn off when cam leaves inner cam Switch | 1. Outer cam Switch 2. Central Control Computer 3. Mech. Control Board |
| Transfer Starts when Power is applied and runs continuously | "Tran. Motor" LED is OFF | 1. Mech. Control Board 2. Wiring to Motor |
| | "Tran. Motor" LED is ON | 1. Central Control Computer 2. Mech Control Board 3. Wiring from Central Control Computer to Mech Control |
| Transfer starts and runs continuously | "Tran. Motor" LED comes ON when Motor starts and stays ON | 1. Wiring to Outer cam Sw. 2. Outer cam Switch 3. Central Control Computer 4. Wiring from Central Control Computer to Mech Control 5. Mech Control Board |

| TROUBLE | SYMPTOM | PROBABLE CAUSE |
|--|--|--|
| Turntable motor does not run | "T.T. Motor" LED is ON | 1. Wiring to T.T. Motor 2. T.T. Motor 3. Mech Control |
| | "T.T. Motor LED is OFF | 1. Wiring from Central Control Computer to Mech Control Board. 2. Central Control Computer 3. Mech. Control Board |
| Record will not Cancel when Finished Playing | "Cancel" LED is ON | 1. Wiring from Mech Control to Central Control Computer 2. Central Control Computer 3. Also see "Record Does not Transfer" |
| | "Cancel" LED is OFF | 1. Wiring to Cancel Switch 2. Cancel Switch 3. Mech. Control Board |
| Record Cancels without Playing | "Cancel" LED stays ON | 1. Short in Cancel Switch Wiring 2. Cancel Switch 3. Mech Control Board |
| | "Cancel" LED flashes ON as Record sets down | 1. Auto Cancel Misadjusted |
| | "Cancel" LED does not flash | 1. Wiring to outer cam Switch. 2. Outer cam Switch 3. Wiring from Mech Control to Central Control Computer 4. Mech Control Board 5. Central Control Computer |
| Left Side of Record Plays when Right Side Selected | "Toggle" LED is ON | 1. Wiring to Toggle Coil(s) 2. Toggle Coil(s) 3. Mech. Control |
| | "Toggle" LED is OFF | 1. Wiring from Central Control Computer to Mech Control Board 2. Central Control Computer 3. Mech. Control Board |
| Money Counter or Play Counter Fails to Count | Fails to Count | 1. Wiring to Counter 2. Counter 3. Mech Control Board 4. Wiring from Central Control Computer to Mech Control 5. Central Control Computer |
| Automix does not Work | Turntable Motor runs, Hub does pop up, but speed changes for 33 RPM Records | 1. Hub Shift Wiring 2. Automix Switch 3. Hub Shift Coil |
| | Turntable Motor Runs, Hub pops up, but speed does not shift for 33 RPM Records | 1. Speed Shift Wiring 2. Automix Switch 3. Speed Shift Coil |
| | Hub does not pop up and speed will not change | 1. Wiring 2. Automix Switch 3. Mech. Control Board |

| TROUBLE | SYMPTOM | PROBABLE CAUSE |
|---|--|--|
| Phonograph is always in Service ("Memorec") Mode of Operation | Record Number / Times selected Display is always lit | <ol style="list-style-type: none"> 1. On/Service/Off Switch 2. "+8 on Signal" Wiring 3. Central Control Computer |
| Phonograph will not go into Service Mode of Operation | Record Number/ Times selected Display will not light when ON/ /Service/Off Switch is in Service Position | <ol style="list-style-type: none"> 1. Central Control Computer 2. "+8 On Signal" Wiring 3. On/Service/Off Switch |
| No Credit | No Credit given by Coins and Dollar Bill | <ol style="list-style-type: none"> 1. Central Control Computer |
| | No Credit given by Coins but Dollar Bill gives Credit | <ol style="list-style-type: none"> 1. Coin Switch common wiring 2. Central Control Computer |
| | One value of Coin will not give Credit | <ol style="list-style-type: none"> 1. Coin Rejected 2. Wiring to Coin Switch 3. Coin Switch 4. Central Control Computer |
| | Dollar Bill will not give Credit | <ol style="list-style-type: none"> 1. Bill Acceptor 2. Wiring to Bill Acceptor 3. Central Control Computer |
| Wrong Credit | Credit for amount deposited does not agree with Price Card setting | <ol style="list-style-type: none"> 1. One or more Coins did not register (See No Credit) 2. Pricing Inserts 3. Pricing Board 4. Wiring from Pricing Board to Central Control Computer 5. Central Control Computer |
| System does not respond to Key board | "Make Selection" LED not lit | <ol style="list-style-type: none"> 1. Insufficient Credit |
| | "Make Selection" LED lit but entire Keyboard does not work | <ol style="list-style-type: none"> 1. Shorted "Reset" Key 2. Central Control Computer 3. Short in "Reset" Key Wiring |
| | "Make Selection" LED lit but certain Keys do not work | <ol style="list-style-type: none"> 1. Wiring from Central Control Computer to Pricing Board 2. Keyboard 3. Central Control Computer 4. Pricing Board |
| Digital Display does not work | Display Lights but shows Wrong Information | <ol style="list-style-type: none"> 1. Central Control Computer |
| | " +8 VDC" LED on Central Control Computer is lit but Display Digits and LED lamp will not light | <ol style="list-style-type: none"> 1. Central Control Computer |
| | Certain LED Lamps and/or Digits will not work | <ol style="list-style-type: none"> 1. Wiring from Central Control Computer to Digital Display 2. Digital Display 3. Central Control Computer |


SEQUENCE OF OPERATION

The sequence of operation diagrams which follow illustrate the phonograph operational cycle.

The first diagram shows voltage and common connections to the electronic circuit modules, and the electrical components located on the mechanism.

The remaining diagrams illustrate which signals are active during each point in the phonograph operational cycle.


Most of the voltages listed on the block diagram can be measured with an inexpensive VOM.



1

Power turned on, voltages and commons applied to circuits and components.


1. Power flows thru power cord and power switch to energize power supply. The three power supply LEDs light. The voltages go thru on-service-off switch and energize 28 VAC, +28 VDC, and +8 VDC busses. The "+8 VDC" LED on C.C.C. Lights.
2. "28 VAC" goes to magazine motor, transfer motor, and mechanism control. The 28 VAC is routed thru mechanism control to the turntable motor.
3. "+28 VDC" goes to amplifier mute plug, and mechanism control.
4. "Power common" goes to outside record cancel, and manual scan switch, tonearm cutoff, toggle shift coils, inner and outer cam switches, detent coil, and mechanism control. It is routed thru mechanism control to play and money counters, and hub shift and speed shift coils.



2

C.C.C. senses power turned on (no selections in memory).


1. The C.C.C. begins to constantly monitor the state of all switches and determines that the transfer arm (gripper bow) is in home position.
2. C.C.C. sends the detent and mag. motor signals to the mechanism control. The "detent" and "Mag. Motor" LED's light. The mechanism control energizes the detent coil and magazine motor.
3. The magazine rotates and magazine gear teeth interrupt the optical switch light beam causing the "optical sw. index" LED to flash. The C.C.C. advances the magazine (record) position by one each time the LED flashes from dark to light.



The "optical sw. home" LED lights when record position "99" aligns with the transfer arm. When this happens the C.C.C. sets the next magazine position equal to record "0".

Magazine completes one revolution and stops. (If there are selections in memory, the magazine continues to turn to a selection and the selection is played).


4. Digital display and most popular LED flash and show most popular record on the phono. This continues during standby. The diagram shows record "111" as the most popular.




3

Patron inserts quarter. Standard credit established. (Credit is set at 1 play for 25¢, 3 for 50¢ and 1 premium equals 2 standard).

1. Patron inserts quarter into coin slot. The coin passes through the validator and actuates the 25¢ coin switch.
2. The C.C.C. senses the switch closure and stores 5 money units (nickels) in its memory.
3. 5 pulses are sent to the money counter.




4. The C.C.C. uses the amount of money stored in its memory and the pricing information which it reads from the pricing board to calculate the remaining credit equal to 1.
5. The C.C.C. turns on the "standard credit" LED.
6. The "selections remaining" LED lights and the digital display shows 1 credit for about four seconds.




4 Second quarter inserted. Premium credit established.

1. Patron inserts another quarter into coin slot. The coin passes through the validator and actuates the 25¢ coin switch.
2. The C.C.C. senses the switch closure and stores 5 money units (nickels) in its memory.
3. Five pulses are sent to the money counter.




- The C.C.C. uses the amount of money stored in its memory and the pricing board information to calculate the remaining credit equal to 3.
- C.C.C. turns on both standard credit and "premium credit" LEDs.
- The "selections remaining" LED lights and the digital display shows 3 credits for about four seconds.




5

First digit selected and displayed.

1. Patron presses first digit of his selection (in this illustration number 1).
2. The C.C.C. senses the key closure, checks that credit is available, stores the selected first digit and displays it on the digital display. The "selection being made" LED lights.




NOTE: The first digit of a selection must be a 1 or a 2. If any other key is pushed the computer ignores it. To make a correct selection merely push the correct key.




6

Second digit selected and displayed.

1. Patron presses second digit of his selection (in this illustration number 2).
2. The C.C.C. senses the key closure, stores the selected second digit and displays it.




NOTE: If the phonograph has premium selections and the selection is in a premium group, and premium credit is not available the key is ignored. Either add more credit or make a standard selection.




7

Third digit selected and displayed selection stored, Memorec incremented.

1. Patron presses third digit of his selection (in this illustration number 3).
2. The C.C.C. senses the key closure, stores the third digit and displays it.






8

Credit cancelled – Selections remaining displayed.


1. C.C.C. cancels one credit (two credits would be cancelled for a premium selection).
2. "Selections remaining" LED lights and display shows 2 credits.



9

Detent coil and magazine motor energized – Magazine rotates.

1. C.C.C. signals the mechanism control to energize detent coil. "Detent coil" LED lights and the energized detent coil operates a mechanical linkage to unlock the magazine.
2. C.C.C. signals the mechanism control to energize magazine motor. "Magazine Motor" LED lights and motor is energized causing the unlocked magazine to rotate.




10

Magazine rotates until selection is located.

1. Magazine rotates and gear teeth interrupt optical switch light beam.

NOTE: "Optical sw. index" LED going from dark to light (off to on) tells C.C.C. the magazine is moving to the next record position and two things happen.


1. C.C.C. keeps track of magazine position by adding 1 to value stored in C.C.C.
2. C.C.C. checks the selection memory to see if left or right side of this next record has been selected.



11

Selection located, record transferred to turntable, tone arm set down.


1. C.C.C. signals turn off "detent" and "mag. motor" LEDs causing mechanism control to de-energize detent coil and magazine motor.
2. Magazine is locked by detent pawl falling into slot in detent wheel.
3. C.C.C. signals turn on "tran. motor" and "T.T. motor" LEDs, causing mechanism control to energize transfer and turntable motors. C.C.C. signals mechanism control to advance play counter.




12

Amplifier unmuted and record plays.

1. Transfer motor rotates and cam moved onto outer cam switch.
2. "Outer cam sw. N.O. contact" signals C.C.C. to turn off transfer motor. "Tran. motor" LED turns off and transfer motor stops.




3. Ground signal is removed from "Outer cam sw. N.C. contact", causing amplifier to unmute.
4. Record plays.



13

Record ends and is returned to magazine

1. Tone arm cutoff sends a cancel signal to C.C.C.



15

15. Phonograph returns to standby condition, most popular selection displayed.

1. All selections have been played.
2. Most popular LED and digital display flash and show most popular record on the phono. The diagram shows record "111" as the most popular.

SOUND SYSTEM QUIK CHECK

Rowe solid state sound systems are service designed for easy, fast repair. The following check list will enable locating troubles on location with your finger, a paper clip or an inexpensive VOM. Be sure not to plug in or unplug circuit boards with power on. Checks should be made with the mechanism in the record playing position. Perform the checks in the order listed.

NO SOUND - BOTH CHANNELS

1. Power - Second Level - Check that the amplifier is plugged in and is receiving power from the junction box. Disconnect mute plug. Press the circuit breaker reset pushbutton on the amplifier chassis to make sure that it is not tripped. Application of power to the amplifier should result in an audible "thump" through the speaker.
2. Volume Control - Disconnect the volume control plug from the amplifier chassis and short pins 1 and 2 and pins 3 and 4 with a paper clip. Full volume indicates an open volume control or line.
3. Cartridge Connections - Make sure that the stylus is not bent or broken; replace if necessary. With a selection playing, unplug the tone arm cable from the amplifier. Holding a paper clip, insert it into each phono input and check for hum. If hum is present, check cartridge wiring against the service manual; replace the cartridge if necessary.
4. Extension Speakers - To check if extension speakers are shorting out the amp, simply disconnect the extension speakers from the output transformers.
5. Output Devices - Visually inspect the driver board fuses for an open condition. If a fuse is open, replace the associated output device. The two devices used in each channel are not interchangeable; check the part number on the case and install an identical or equivalent replacement. Before mounting the device onto the heat sink, be sure that the heat sink surface is flat and that there are no burrs around the mounting holes to cause a short. Be sure that one and only one mica insulator is between the device and the heat sink and heat transfer compound (spec 53) is on both sides of insulator.
6. Filter Capacitors - Check for 22 ± 2 VDC in the amplifier power supply. Check the voltage at the terminals of the two large electrolytic filter capacitors located on the driver board. Check that the voltage on each capacitor is the same. A lowered voltage at one of the capacitors indicates that the capacitor may be defective and should be replaced, or that the bridge rectifier is defective. Another indication of defective filter capacitors is excessive hum in the sound output.
7. Pre-Amp Output - Short all five of the volume control pins located on amp.

Press finger against pins 1 or 3 (outside pins) labeled phono cartridge input and check for approximately 1 VAC at pre amp output (pins 3 or 5 of 13 pin connector-chassis common). Replace pre amp board if voltage is not present.

If voltage is present check center pin of output driver board for approximately 16 VAC. If voltage is not present make sure finger is pressed against the same outside pin with respect to channel that is being checked with volt meter.

NO SOUND, LOW SOUND OR DISTORTED SOUND RIGHT OR LEFT CHANNEL ONLY

1. Balance Control - Adjust control for equal sound from each channel. Leave in mid position if adjustment is not possible.
2. Reverse Cartridge Leads - With a selection playing, reverse tone arm cable connections to the amplifier. If the sound switches channels, check cartridge connections against the service manual. Replace the cartridge if connections are O.K. Make sure that the stylus is not bent or broken; replace if necessary.
3. Extension Speakers - See Step 4 NO SOUND BOTH CHANNELS.
4. Output Devices - See Step 5 NO SOUND BOTH CHANNELS.
5. Preamp - See Step 7 NO SOUND BOTH CHANNELS.

CONSTANT HIGH VOLUME - CANNOT BE ADJUSTED AT VOLUME CONTROL

1. Volume Control - Disconnect volume control plug from amplifier chassis. No sound indicates that there is a short in the volume control line.
2. Preamp - If there is full volume with control plug disconnected, replace the preamplifier board.

EXCESSIVE RECORD SCRATCH

1. Worn Records - Replace worn records.
2. Damaged Stylus - Make sure that the stylus is not worn or broken; replace if necessary. Check stylus force.
3. Treble Range Control Too High - Reduce setting of control for worn or noisy records.

EXCESSIVE HUM, LOW VOLUME

1. Open shield - Be sure that shield or wires are not broken between cartridge and the amplifier input plug.
2. Cartridge Defective - Substitute a good cartridge.
3. Filter Capacitors - Check filter capacitor, parallel an extra 500 Mfd. 50V capacitor across filter capacitor on printed circuit board. If hum drops, replace capacitor.