


ZIP SOFTWARE UPDATING USING FASHSTA.EXE

The software for ZIP is composed by 2 file called : xxx.id, xxx.mot .
This file must be stored into the same directory.


1. Switch OFF CPU power .
2. Connect by a serial cable the PC UART RS232 port to Flash Programmer DB9 female contacts connector.
3. Connect CPU Board DB9 female contacts connector to Flash Programmer DB9 male contacts connector.
4. Switch ON CPU power and verify that programmer bi-color led turns on with green light.
5. Run **Flashsta.exe** program in the PC:

- It will appear:




Select the COM port and then "OK".

- It will appear:




Push “Refer...”, select the file (file.mot) you want to load, push “Open” and wait the file loading.

- When loading is complete:




Verify the file path is correct and then confirm pushing “OK”.

- If the communication between CPU and PC is active, the next window will appear, on the contrary, if there is a problem a message will explain it.




Choose "Setting...", set Baud Rate = 57600, push "OK".
Then choose "E.P.R..." (Erase+Program+Read).

- It will ask you:



Push "OK" to confirm.

- Flash programming will start :



wait the flash programming end...:



Push "OK" to confirm.

Push "Exit" on the M16C Flash Start window to close the Flashsta.

6. Switch OFF power and disconnect the Programmer from CPU board.