

Colibrì

Espresso

Instant

UK

English

Page

1




DOC. NO. H 155U 01
EDITION 2 00 12

Telefono +39 035 606111
Fax +39 035 606460
Trib. Bergamo Reg. Imp. n. 2534
R.E.A. Bergamo n. 319295

Cap. Soc. L. 29.064.000.000 i. v.
Cod. Fisc. 12806340159
Part. IVA 02747810162
Cod. ISO IT 02747810162

DICHIARAZIONE DI CONFORMITA'
DECLARATION OF CONFORMITY
DÉCLARATION DE CONFORMITÉ
KONFORMITÄTSESKLÄRUNG
DECLARACIÓN DE CONFORMIDAD
DECLARAÇÃO DE CONFORMIDADE
VERKLARING VAN OVEREENSTEMMING
INTYG OM ÖVERENSSTÄMMELSE
OVERENSSTEMMELSESERKLÆRING



Valbrembo, 04/04/00

Dichiara che la macchina descritta nella targhetta di identificazione, è conforme alle disposizioni legislative delle direttive: **89/392, 89/336, 73/23 CEE** e successive modifiche ed integrazioni.

Declares that the machine described in the identification plate conforms to the legislative directions of the directives: **89/392, 89/336, 73/23 EEC** and further amendments and integrations.

Déclare que l'appareil décrit dans la plaque signalétique satisfait aux prescriptions des directives: **89/392, 89/336, 73/23 CEE** et modifications/intégrations suivantes.

Erklärt, daß das im Typenschild beschriebene Gerät den **EWG** Richtlinien **89/392, 89/336, 73/23** sowie den folgenden Änderungen/Ergänzungen entspricht.

Declara que la máquina descrita en la placa de identificación, resulta conforme a las disposiciones legislativas de las directivas: **89/392, 89/336, 73/23 CEE** y modificaciones y integraciones sucesivas.

Declara que o distribuidor descrita na chapa de identificação é conforme às disposições legislativas das directivas **CEE 89/392, 89/336 e 73/23** e sucessivas modificações e integrações.

Verklaart dat de op de identificatieplaat beschreven machine overeenstemt met de bepalingen van de **EEG** richtlijnen **89/392, 89/336** en **73/23** en de daaropvolgende wijzigingen en aanvullingen.

Zanussi intyggar att maskinen som beskrivs på identifieringsskylten överensstämmer med lagstiftningsföreskrifterna i direktiven: **89/392, 89/336, 73/23 CEE** och påföljande och kompletteringar.

Det erklæres herved, at automaten angivet på typeskiltet er i overensstemmelse med ovsdirektiverne **89/392, 89/336** og **73/23 CEE** og de senere ændringer og tillæg.

GOFFREDO BUTTAZZONI

Direttore Generale
Directeur General
Director General
Directeur-generaal
Direktør

General Manager
Generaldirektor
Director-Geral
Verkställande direktor



THE EUROPEAN NETWORK FOR QUALITY SYSTEM ASSESSMENT AND CERTIFICATION

This is to state that

ZAMUSSI VENDING S.p.A.
Via Roma, 24 - 24030 VALEREMBO (BG)

holds the Quality System Certificate

CISQ/CISQ 9130-ZA18

*for the standard from the
ISO 9000 / EN 29000
series, and the scope as specified therein*

Signed for and on behalf of EQNet member

Federazione CISQ
IL PRESIDENTE
Dr. Ing.

DATE

June 1st, 1994

EQNet members are:

AENOR Spain AFAQ France AIB-Vincotte Belgium BSI QA United Kingdom
CISQ Italy DS Denmark DQS Germany ELOT Greece IPQ Portugal KEMA Netherlands
NCS Norway NSAI Ireland ÖQS Austria SFS Finland SIS Sweden SQS Switzerland

The issuing member holds all other EQNet members harmless for any claims arising from the existence of this document.



CERTIFICAZIONE ITALIANA DEI SISTEMI
QUALITA' AZIENDALI
ITALIAN CERTIFICATION OF COMPANIES
QUALITY SYSTEMS



CERTIFICATO n.
CERTIFICATE No. 9130-ZA18

SI CERTIFICA CHE IL SISTEMA QUALITA' DI
WE HEREBY CERTIFY THAT THE QUALITY SYSTEM OPERATED BY

ZAMUSSI VENDING S.p.A.

Via Roma, 24 - 24030 VALEREMBO (BG)

UNITA' OPERATIVA
OPERATIVE UNIT

Via Roma, 24 - 24030 VALEREMBO (BG)

E' CONFORME ALLA NORMA
IS IN COMPLIANCE WITH THE STANDARD UNI-EN 29001-ISO 9001

PER I SEGUENTI TIPI DI PRODOTTI - PROCESSI - SERVIZI
CONCERNING THE FOLLOWING KINDS OF PRODUCTS - PROCESSES - SERVICES

Progettazione, produzione e commercializzazione di
apparecchiature elettromeccaniche/elettroniche per
la distribuzione automatica e la ristorazione
design, manufacturing and sale of
electromechanical/electromechanical vending machines

IL PRESENTE CERTIFICATO E' SOGGETTO AL RISPETTO DEL REGOLAMENTO
DELL'IMO PER LA CERTIFICAZIONE DEI SISTEMI QUALITA' DELLE AZIENDE
THIS CERTIFICATE SHALL SATISFY THE REQUIREMENTS ESTABLISHED BY IMO
FOR THE CERTIFICATION OF SUPPLIERS' QUALITY SYSTEMS

25 Luglio 1994

DATA DI RILASCIO
ISSUED ON

IMO

Il presente certificato annulla e sostituisce il precedente 9130.ZA18 del 01.06.94
This certificate supersedes the previous one 9130.ZA18 issued on 01.06.94

CISQ è un sistema internazionale di
certificazione indipendente del Siste-
mi Qualità aziendali, gestito in modo
coordinato da organismi di certifica-
zione referenziali.

The CISQ is an international system of
independently certification of Suppliers'
Quality Systems, which is coordinated
by several certification bodies.

MLU 373-500-694

English

TABLE OF CONTENTS

INTRODUCTION	PAGE 2	OPERATING MODES	PAGE 15
IDENTIFICATION OF THE VENDING MACHINE	PAGE 2	NORMAL OPERATING MODE	PAGE 15
IN CASE OF FAILURE	PAGE 2	PRE-SELECTIONS	PAGE 16
TRANSPORT AND STORAGE	PAGE 2	MAINTENANCE MODE	PAGE 16
USING THE VENDING MACHINE	PAGE 3	AUTOTEST	PAGE 17
POSITIONING THE VENDING MACHINE	PAGE 3	EMPTYING THE AIR-BREAK	PAGE 17
WARNING FOR INSTALLATION	PAGE 3		
PRECAUTIONS IN USING THE MACHINE	PAGE 3	DISPLAYING THE STATISTICS	PAGE 17
WARNING FOR SCRAPPING	PAGE 3	PRINTING THE STATISTICS	PAGE 17
		RESETTING THE STATISTICS	PAGE 17
TECHNICAL SPECIFICATIONS	PAGE 4	GENERAL COUNTER	PAGE 17
POWER CONSUMPTION	PAGE 5		
ACCESSORIES	PAGE 5	PROGRAMMING	PAGE 18
		DISPLAYING CURRENT FAILURES	PAGE 18
LOADING AND CLEANING	PAGE 6	PROGRAMMING WATER AND POWDER DOSES	PAGE 19
DOOR SWITCH	PAGE 6	PROGRAMMING THE PRICES	PAGE 19
MAINTENANCE AND DISINFECTION	PAGE 6	PROGRAMMING THE PRICES AND THE PUSH-BUTTON STATUS	PAGE 19
CONTROLS AND INFORMATION	PAGE 6	PROGRAMMING THE BASIC COIN AND THE DECIMAL POINT	PAGE 20
LOADING CUPS	PAGE 7	PAYMENT SYSTEMS	PAGE 20
LOADING COFFEE	PAGE 7	PROGRAMMING THE VALIDATOR	PAGE 20
LOADING SUGAR AND INSTANT PRODUCTS	PAGE 7	INITIALISING	PAGE 20
LOADING STIRRERS	PAGE 7	SETTING THE MACHINE CODE	PAGE 20
SANITISING THE FOODSTUFF		MACHINE CONFIGURATION	PAGE 21
CIRCUITS AND THE MIXERS	PAGE 8	SELECTIONS COUNTER	PAGE 21
CLEANING THE MIXER	PAGE 8	SETTING THE PROMOTIONAL MESSAGE	PAGE 21
CLEANING THE WATER SUPPLY TANK	PAGE 9	SETTING THE LANGUAGE	PAGE 21
CLEANING THE SUGAR RELEASE DEVICE	PAGE 9	WHIPPING TIME	PAGE 21
CLEANING THE WASTE TRAYS	PAGE 9	PROGRAMMING ACCESS PASSWORD	PAGE 21
CLEANING THE CUP SHIFT ARM	PAGE 10	CONFIGURING THE SELECTION	PAGE 21
WEEKLY CLEANING OF COFFEE UNIT	PAGE 10	DISCOUNT	PAGE 21
SUSPENDING FROM USE	PAGE 10	SPECIAL SALES	PAGE 22
		EURO	PAGE 22
INSTALLATION	PAGE 11	INSTALLATION	PAGE 22
UNPACKING THE VENDING MACHINE	PAGE 11	RESETTING FAILURES	PAGE 22
CONNECTING TO THE WATER MAINS	PAGE 11		
CONNECTING TO THE POWER SUPPLY	PAGE 12	PROGRAMMER	PAGE 22
DOOR SWITCH	PAGE 12	AUTOMATIC SETUP TRANSFER	PAGE 22
INSTALLING THE PAYMENT SYSTEM	PAGE 12	TRANSFERRED DATA	PAGE 23
WATER SOFTENER UNIT	PAGE 12	CONFIGURING THE LANGUAGE	PAGE 23
INSERTING THE LABELS	PAGE 12		
LENGTH OF THE STIRRERS	PAGE 12	MAINTENANCE	PAGE 24
INITIALISING	PAGE 13	INTRODUCTION	PAGE 24
FILLING THE WATER SYSTEM	PAGE 13	BREWING UNIT MAINTENANCE	PAGE 24
		REGENERATING THE SOFTENER UNIT	PAGE 25
OPERATION OF THE COFFEE UNIT	PAGE 13	ANNUAL SANITISING	PAGE 25
COFFEE DISPENSING CYCLE	PAGE 13		
CHECKING AND ADJUSTING THE MACHINE SETTINGS	PAGE 14	PRINTED BOARD FUNCTIONS AND INDICATOR LIGHTS	PAGE 26
STANDARD SETTINGS	PAGE 14	CONTROL BOARD	PAGE 26
ADJUSTING THE COFFEE UNIT		PUSH-BUTTON BOARD	PAGE 27
PISTON STROKE SETTING	PAGE 14		
WATER TEMPERATURE CONTROL	PAGE 14	HYDRAULIC SYSTEM	PAGE 28
ADJUSTING THE GRADE OF GRINDING	PAGE 15		
ADJUSTING THE COFFEE DOSE	PAGE 15		

INTRODUCTION

This technical documentation is part and parcel of the vending machine and must always follow the machine in case it is moved or ownership is transferred, so as to permit consultation by different operators.

Before installing and using the machine, it is first necessary to carefully read and understand the instructions contained in this manual, as they offer important hints on safe installation, use and maintenance.

This manual is divided into three sections.

The **first section** describes the loading and routine cleaning operations which are carried out in areas of the machine accessible with simple use of the door key, without using any other tools.

The **second section** contains the instructions for correct installation and all information necessary for optimum use of the machine.

The **third section** describes maintenance operations which involve the use of tools to access potentially dangerous areas.

The operations described in the second and third sections must be carried out only by personnel who have the specific knowledge of the machine functioning from a point of view of electrical safety and health regulations.

IDENTIFICATION OF THE VENDING MACHINE AND ITS CHARACTERISTICS

Every machine is identified by its own serial number, indicated on the data plate attached to the cabinet on the right-hand side.

This plate (see Figure below) is the only one acknowledged by the manufacturer and indicates all of the data which readily and safely gives technical information supplied by the manufacturer. It also assists in spare parts management.

IN CASE OF FAILURE

In most cases, any technical problems are corrected by small repair operations; however, before contacting the manufacturer we recommend that this manual be read carefully.

Should there be serious failures or malfunctions, then contact the following:

NECTA VENDING SOLUTIONS SpA
Via Roma 24
24030 Valbrembo
Italy - Tel. +39 - 035606111

TRANSPORT AND STORAGE

To prevent any damage, special care should be taken when loading or unloading the vending machine.


The machine can be lifted by a motor-driven or manual fork lift truck, and the blades are to be placed underneath the machine.

Do not:

- overturn the vending machine;
- drag the vending machine with ropes or similar;
- lift the vending machine by its sides;
- lift the vending machine with slings or ropes;
- shake or jolt the vending machine and its packing.

The machine should be stored in a dry room where the temperature remains between 0° C and 40° C.

Using the original packing, no more than 2 machines can be stacked one on top of the other and always kept upright as indicated by the arrows on the packing.



USING THE VENDING MACHINES OF HOT DRINKS IN OPEN CONTAINERS

(Ex.: plastic cups, ceramic cups, jugs)

The vending machines of drinks in open containers should be used only to sell and dispense drinks obtained by:

- brewing products like coffee and tea;
- reconstituting instant and lyophilized products;

These products should be declared by the manufacturer as "suitable for automatic vending" in open containers.

The dispensed products should be consumed immediately. Under no circumstances should they be preserved and/or packed for later consumption.

Any other use is unsuitable and thus potentially dangerous.

POSITIONING THE VENDING MACHINE

The vending machine is not suitable for outdoor installation. It must be installed in a dry room where the temperature is between 2°C and 32°C, and not where water jets are used for cleaning (e.g. in large kitchens, etc.).

The machine should be placed close to a wall, so that the back panel is at a minimum distance of 4 cm from it and correct ventilation may be ensured.

The machine must never be covered with cloth or the like. The machine should be positioned with a maximum inclination of 2°.

If necessary provide proper levelling by way of the adjustable feet included.

Important notice!!

Access to the machine interior for maintenance and/or repairs is via the back panel.

Therefore, provisions should be made for the machine is to be rotated, thus allowing removal of the back panel.

Positioning the machine on a cabinet

The machine can be installed on a table or on any other suitable stand (recommended height is 820 mm).

If possible, it is advisable to use the special cabinet, which can house the liquid waste tray, the water supply kit, the payment system and, in the case of very hard water, the softener unit.

WARNING FOR INSTALLATION

The machine installation and the following maintenance operations should be carried out by qualified personnel only, who are trained in the correct use of the machine according to the standards in force.

The machine is sold without payment system, therefore the installer of such a system has sole responsibility for any damage to the machine or to things and persons caused by faulty installation.

The integrity of the vending machine and its conformity with the rules and regulations in force for its relevant systems must be checked by qualified personnel at least once a year.

All packing materials shall be disposed of in a manner which is safe for the environment.

PRECAUTIONS IN USING THE MACHINE

The following precautions will assist in protecting the environment:

- use biodegradable products only to clean the machine;
- adequately dispose of all containers of the products used for loading and cleaning the machine;
- switch the machine off during periods of inactivity, thus achieving considerable energy savings.


WARNING FOR SCRAPPING

Whenever the machine is to be scrapped, the laws in force regarding environment protection should be strictly observed. More specifically:

- ferrous and plastic materials and the like are to be disposed of in authorized areas only;
- insulating materials should be recovered by qualified companies.

TECHNICAL SPECIFICATIONS

DIMENSIONS



Height	=	650	mm
Height with container	=	750	mm
Width	=	410	mm
Depth	=	490	mm
Overall dimension with door open	=	830	mm
Height of cabinet	=	mm. 820	
Weight			

Colibri	Espresso	Instant
Kg.	38	33

Power supply voltage	230	V~
Frequency	50	Hz
Installed power	1300	W

CUP DISPENSER

Suitable for cups with a rim diameter of 73-74 mm. with a capacity of approximately 170 cups.

PAYMENT SYSTEM

The machine is supplied with all prearrangement for a front validator. Specific kits are provided for the installation of payment systems with Executive, MDB or BDV protocol. The machine can accommodate the "cashless" payment system, while the "change giver" payment system must be installed in the special support cabinet (optional).

SALES PRICES

A different programmable price can be set for each selection; the standard setting has the same sales price for all selections.

COIN BOX

Made of plastic with lock as optional accessory.

WATER SUPPLY

From the mains, with a water pressure of 5 to 85 N/cm². A water supply tank can be installed in the support cabinet (optional).

AVAILABLE ADJUSTMENTS

Grade of grinding for espresso coffee; coffee and water doses by volume; time adjustment for instant products.

Temperature control

Factory set on the correct operating temperature. A trimmer located on the control board allows small adjustments (as necessary).

CONTROLS

- Presence of cups
- Presence of water
- Presence of coffee
- Operating temperature reached
- Cup release microswitch

SAFETY DEVICES

- Door switch
- Presence of coffee waste container (Espresso models only)
- Manual-reset boiler safety thermostat
- Air-break float jamming (only with water supply from the mains)
- Overflow solenoid valve (only with water supply from the mains)
- Time protection for:
 - Pump
 - Coffee unit ratiomotor
 - Coffee grinder

- Temperature protection for:
 - Doser units
 - Coffee unit ratiomotor
 - Magnets
 - Pump
 - Electric mixers
 - Coffee grinder motor
- Fuse protection for:
 - Main electrical circuit
 - Board power supply transformer

CAPACITY OF CONTAINERS

Capacity of containers (Kg)	Espresso	Instant
Coffee beans	2	-
Instant coffee	-	0.7
Sugar	1.0	1.9
Milk	0.8	0.8
Chocolate	1.4	1.4
Stirrers	160	-

POWER CONSUMPTION

The machine power consumption depends on many factors, such as the temperature and ventilation of the room where it is installed, the inlet water and boiler temperature, etc.

With an ambient temperature of 22° C the following power consumption levels resulted:

	Espresso	Instant
30 drink selections	0.96 l	1.21 l
average drink temperature	76.2° C	76.1° C
Power consumption		
to reach operating temperature	28.6 Wh	28.6 Wh
24 h of stand-by	1414 Wh	1414 Wh
30 selections /hour	171.2 Wh	152.9 Wh

The above power consumption calculated from average data should only be taken as an indication.

ACCESSORIES

A wide range of accessories can be installed on the machine to change its performance:

The assembly kits are supplied with their own installation and test instructions, which must be strictly observed to ensure the machine's safety.

Important notice!!

The use of kits which are not approved by the manufacturer of the vending machine does not guarantee observance of safety standards, especially for energised parts.

The manufacturer declines all responsibility for the use of non approved components.

Installation and the following testing operations, must be carried out only by qualified personnel who have the specific knowledge of the machine functioning from a point of view of both electrical safety and health regulations.

LOADING AND CLEANING

DOOR SWITCH

When opening the door a special switch disconnects the power from the machine electrical system to allow the operations described below, regarding loading and routine cleaning, in full safety.

All operations requiring the machine to be energized should be carried out by qualified personnel ONLY, informed about the specific risks of such situation.

To energize the system with the door open, simply insert the special key into the slot (see Figure 1).

The door can be closed only after removing the key.




Fig. 1

- 1 - Door lock bolt
- 2 - Door lock
- 3 - Stirrer stacker adjusting slots
- 4 - Door switch
- 5 - Stirrer weight

MAINTENANCE AND DISINFECTION

According to current safety rules and health regulations, the operator of an automatic vending machine is responsible for the hygiene and the maintenance of the foodstuff circuits, to prevent formation of bacteria.

At installation the hydraulic circuits and the parts in contact with foodstuff should be fully sanitised to remove any bacteria which might have formed during storage.

It is advisable that specific sanitising agents (such as chlorine-based detergents or similar) are used for cleaning also the surfaces which are not directly in contact with foodstuff.

Some parts of the machine can be damaged by strong detergents.

The manufacturer declines all responsibility for any damage caused by the use of strong or toxic chemicals.

Before starting any maintenance operations requiring parts of the unit to be removed, the machine must always be disconnected from the power supply.

CONTROLS AND INFORMATION

All user controls and information are located on the external side of the door (see Fig. 2).

The labels with the selection menu and the operating instructions supplied with the machine must be inserted at the time of installation, referring to the selection dose table.




Fig. 2

- 1 - Liquid waste tray
- 2 - Dispensing compartment
- 3 - Lock
- 4 - Spaces for product labels
- 5 - Alphanumeric display
- 6 - Selection buttons
- 7 - Prearrangement for front validator
- 8 - Prearrangement for "cashless" payment systems

The Programming button, used to access the machine functions, is located on the internal side of the push-button board.

Press the button once to enter "Maintenance" mode; press the Programming button twice to enter "Programming" mode.

Press selection button No. 3 and immediately after selection button No. 6 to automatically start filling the machine hydraulic system.

LOADING CUPS

To load cups do as follows:

- open the door;
- slightly lift the cup dispenser and tilt it (see Fig. 3);
- do not rotate the columns during loading operations;
- **load the columns with cups, without exceeding the dispenser height;**
- re-engage the cup dispenser;
- close the machine and make a test selection.




Fig. 3

- 1 - Spacer washer
- 2 - Knurled nut
- 3 - Cup shift arm
- 4 - Cup container

LOADING COFFEE

The cover can be opened only with the door open. Lift the cover and fill the coffee container, ensuring that the shutter is fully open (see Fig. 4).




Fig. 4

- 1 - Coffee container shutter
- 2 - Coffee container
- 3 - Milk container
- 4 - Chocolate container
- 5 - Powder chute
- 6 - Powder feeder

LOADING SUGAR AND INSTANT PRODUCTS

The covers can be opened only with the door open. After lifting their cover, fill the single containers with the appropriate products, taking care not to compress them to prevent packing. Make sure the products do not contain any clots.

When handling the sugar/stirrer dispenser shelf, ensure that the key (see Fig. C) is completely rotated clockwise to prevent the lock bolt from interfering with the stirrer stacker.

LOADING STIRRERS

Remove the stirrer weight (see Fig. 1) and insert the stirrers to be loaded.

Remove the paper strip, ensuring that the stirrers are all placed horizontally.

Replace the stirrer weight.

The stirrers must be burr free and not curved.

SANITISING THE MIXERS AND FOODSTUFF CIRCUITS

When installing the machine, and then at least once a week or even more frequently according to the use of the machine and the quality of the inlet water, the mixers and the instant drink dispensing conduits must be thoroughly disinfected, to guarantee proper hygiene of the dispensed products.

The parts to be cleaned are the following:

- powder deposit drawers, mixer and instant drink dispensing conduit;
- coffee dispensing spout;
- sugar chute;
- dispensing compartment.





Fig. 5

- 1 - Powder feeder
- 2 - Powder funnel
- 3 - Powder deposit drawer
- 4 - Water funnel
- 5 - Feeder
- 6 - Mixer wheel

- remove the powder and the water funnels, the feeders, the powder deposit drawers and the mixer wheels from the mixers (see Fig. 5);
- in order to remove the wheels, block the disk fitted on the mixer shaft with a finger (see Fig. 6);

Fig. 6



- wash all parts with detergent being sure that all visible residue and product layers are mechanically removed, using a brush if necessary;

Disinfection should be carried out using chlorine-based detergents.

- soak all components for approx. 20 minutes in a container filled with the previously prepared chlorine-based detergent;
- reinstall the feeders and the water funnels;
- reinstall the powder deposit drawers and the powder funnels after thoroughly drying them.

After reinstalling all parts the following is however required:

- add a few drops of the chlorine-based detergent in the mixer;
- using the mixer cleaning function with the door closed, thoroughly rinse all components to ensure that all residue of the detergent solution is removed.

MIXER CLEANING

The mixer must be cleaned daily and every time the machine is refilled to prevent clogging of the mixer if any product is accidentally spilled during refilling.


It must also be cleaned after the mixer sanitating operations, as described in the relevant chapter.

The mixer is cleaned with the door closed doing as follows:

- press button 8 for 2 seconds

The display will show the request to enter the password;

- press one after the other buttons 4 4 8 8 to start cleaning.



CLEANING THE WATER SUPPLY TANK (OPTIONAL)

For machines equipped with a water tank inside the support cabinet, at least once a week, such tank must be sanitised with the chlorine-based detergent used for the mixers.

CLEANING THE SUGAR DISPENSER

For models with sugar dispensed directly into the cup, the sugar dispensing system must be cleaned periodically using hot water (see Fig. 7) proceeding as follows:

- release the return spring;
- lift the flexible lever to free the pin;
- remove the pin and the dispensing spout;
- after cleaning, thoroughly dry all parts and reinstall them in the reverse order.




Fig. 7

- 1 - Sugar dispensing spout
- 2 - Pin
- 3 - Flexible lever
- 4 - Return spring

CLEANING THE WASTE CONTAINERS

The waste containers can be easily removed even with the door closed (see Fig. 8) permitting quick emptying and cleaning.

The coffee container capacity is greater than that of the waste container (if the support cabinet is not used).

The machine control software indicates on the display that the maximum number of coffee selections has been reached with the message "Waste container full".

After a few further selections the machine will lock.

The waste container must be emptied without switching the machine off, to allow the software to detect the operation.




Fig. 8

- 1 - Coffee waste container
- 2 - Dispensing compartment drip tray

With the coffee waste container removed, the machine is still available for instant drink selections but indicating the message "Insert waste container" on the display.

The selection counters are reset with the door closed doing as follows:

- press button 8 for 2 seconds

The display will show the request to enter the password;

- press one after the other buttons 4231 to reset the counters.

CLEANING THE CUP SHIFT ARM

The cup shift arm must be cleaned periodically by removing it from the machine. In order to remove it, completely undo the fastening knurled nut (see Fig. 3).

When reinstalling it, ensure that the spacer washer is positioned correctly.

WEEKLY CLEANING OF THE COFFEE UNIT

Every time coffee is refilled, or at least once a week, any powder residue should be removed from the external parts of the coffee unit, particularly from the coffee funnel area (see Fig. 17).

SUSPENDING FROM USE

If for any reason the machine is switched off for a period exceeding the use-by date of the products, the following will be necessary:

- completely empty the containers and thoroughly wash them with the chlorine-based detergents used to clean the mixers.
- completely empty the coffee doser unit by dispensing coffee until the empty condition is indicated.
- completely empty the hydraulic system.

INSTALLATION

Installation and the following maintenance operations must be carried out by qualified personnel only, trained in the correct use of the machine and informed on the specific risks of such operations.

The machine must be installed in a dry room, where the temperature stays always between 2° C and 32° C.

At installation it is necessary to completely sanitise the hydraulic system and all parts in contact with food, in order to eliminate any possible bacteria formed during storage.

UNPACKING THE VENDING MACHINE

After removing the packing, check that the machine is not damaged.

If in doubt do not use the machine.

No packing elements (i.e. plastic bags, polystyrene foam, nails, etc.) should be left within the reach of children, as they are potentially dangerous.

Packing materials must be disposed of in authorized areas only, and all recyclable materials must be recovered by specialised companies.

Important notice!!

The machine should be positioned with a maximum inclination of 2°.

If necessary provide proper levelling by way of the adjustable feet included (see Fig. 9).




Fig. 9

1 - Adjustable foot

CONNECTING THE MACHINE TO THE WATER MAINS

The machine must be connected to the drinking water mains, taking into account law provisions in force in the country where the machine is installed.

The water pressure must be 5 to 85 N/cm² (0,5-8,5 bar). Run some water from the mains until it is clear and without impurities.

Use a hose (also available as a kit) capable of withstanding the water mains pressure and suitable for use with food-stuff (min. inside diameter of 6 mm) to connect the water supply to the union (3/4" gas) of the water inlet solenoid valve (see Fig. 10).

It is good practice to install the water supply tap outside the machine in an easily accessible position.




Fig. 10

1 - Water inlet union (3/4" gas)
2 - Water supply hose
3 - Overflow hose

OVERFLOW DEVICE

The water inlet solenoid valve (see Fig. 10) is equipped with an overflow device mechanically preventing the water from flowing in if there is a malfunction in the solenoid valve itself or in the control device of the boiler water level.

To restore normal operation, proceed as follows:

- drain the water contained in the overflow pipe;
- shut off the valve of the water supply outside the machine;
- loosen the union which secures the solenoid valve supply tube to relieve the water mains residual pressure and then tighten again (see Fig. 10);
- open the valve and switch on the machine.

CONNECTING THE MACHINE TO THE POWER SUPPLY

The machine is designed to operate under a single-phase 240 V~ voltage and is protected by 10 A fuses. Before making the connection make sure that the ratings correspond to those of the power grid, and more specifically:

- the supply voltage rating should be within the limits recommended for the connection points;
- the main switch should be capable of withstanding the peak load required, and at the same time ensure proper omnipolar disconnection from the power grid with an opening gap of the contacts of at least 3 mm.

The main switch, the power outlet and the plug should be located within easy reach.

The power cable is of the type fitted with a fixed plug. Any replacement (see Fig. 11) should be done by qualified personnel only, using exclusively cables of the type HO5 RN - F or HO5 V V-F or H07 RN-F with a section of 3x1-1,5 mm².




Fig. 11

- 1 - Cable from the mains
- 2 - Cable clamp
- 3 - Cover

The electrical safety of the machine is ensured only when it is correctly and efficiently earthed according to the safety standards in force.

This fundamental safety requirement must be duly verified, and if in doubt the system must be carefully tested by qualified technicians.

Do not use adapters, multiple sockets and/or extensions.

Before switching the machine on, be sure it is correctly connected to the water mains and the cutoff valve is open.

THE MANUFACTURER DECLINES ALL RESPONSIBILITY FOR ANY DAMAGE CAUSED BY NONCOMPLIANCE WITH THE ABOVE MENTIONED SAFETY RULES.

DOOR SWITCH

When opening the door a special microswitch disconnects the power from the machine electrical system.

With the door open, no energised parts can be accessed. Inside the machine the only energised parts are the ones which are covered with protective casings which are marked with a plate indicating "before removing the cover disconnect the electricity".

Before removing these covers it is necessary to unplug the machine from the mains socket.

To energize the system with the open door, simply insert the special key into the slot (see Fig. 1).

All operations requiring the machine to be energized with the door open should be carried out with the door switch key inserted, and therefore by qualified personnel informed about the specific risks of such situation.

INSTALLING THE PAYMENT SYSTEM

The machine is sold without payment system, therefore the installer of such a system is responsible for any damage to the machine or to things and persons caused by faulty installation.

- Install the validator and make sure that the programming of the relevant parameters is correct.

Other payments systems such as "change giver" and "cashless" can be installed by using the specific kits.

The "cashless" systems can be housed inside the machine (see Fig. 2); other payments systems such as "change giver" must be housed inside the support cabinet (optional).

WATER SOFTENER UNIT

The machine is sold without water softener.

Should the water be very hard, a 2-litre ion-exchange resin water softener unit can be installed in the cabinet.

The water softener, available as accessory, must be replaced or regenerated regularly following the directions of the manufacturer.

For health and functional reasons, higher capacity water softener units should not be used.

INSERTING THE LABELS

The menu and instruction labels are supplied with the machine and must be inserted at the time of installation according to the layout and to the language (see "selection dose" table).

LENGTH OF STIRRERS

The correct installation position of the stirrer stacker must be checked according to the length of the stirrers to be used (see Fig. 1)

INITIALISING

The machine was designed for different market needs. The software is capable of managing all possible configurations.

For this reason, before starting the machine, some parameters must be set.

"Model"

Defining whether the machine is Espresso or Instant.

"Country"

Intended as type of basic doses for the different selections (e.g. strong coffee IT = 40 cc - strong coffee FR = 60 cc). The available "Countries" are:

It - Fr - Es- Uk

"Layout"

A number of Button/Selection combinations to choose from is provided for each dose type model (the combinations available for each layout are indicated in the dose selection table supplied with the machine).

"Tank"

Intended as water supply from a tank. This can be enabled or disabled (water supply from the mains):

FILLING THE WATER SYSTEM

When the machine is switched on the condition of air-break (full or empty), pump (electrical functioning and water flow) and boiler (pressure).

If required by the conditions, the machine will automatically start an installation cycle, and namely:

- the display will show "Installation" for the entire duration of the cycle;
- the water mains solenoid valve is opened or the water supply pump is started to fill the air-break;
- the milk solenoid valve is opened so that the air may be bled from the boiler and 400 cc. of water filled.

N.B.: If there is no water flow during the installation cycle, the machine will lock until the water is resumed or the machine is switched off.

IMPORTANT NOTICE!!!

If a considerable amount of air bubbles is formed in the water system, for example during maintenance, it is possible that an installation cycle is automatically started when the machine is switched on.

Versions with internal tank

For models with an internal tank, when the machine is first switched on, the installation procedure MUST BE carried out manually (see relevant chapter).

OPERATION OF THE COFFEE UNIT

COFFEE DISPENSING CYCLE

After each time the machine is switched on, upon the first espresso coffee based selection, the coffee unit is rotated completely before the normal cycle, too ensure that the device is in the correct start position.

When selecting coffee, the grinder is started and will continue until the coffee doser chamber is full (see Fig. 15). When the doser unit is full, the ground coffee dose is released into the coffee unit.

The coffee falls into the vertical brew chamber (1) (see Fig. 12).




Fig. 12

- 1 - Brew chamber
- 2 - External disk
- 3 - Upper piston
- 4 - Lower piston
- 5 - Pre-brewing spring
- 6 - Swinging lever

The ratiomotor handle engaged with the disk (2) located outside of the unit rotates by 180°, causing the brew chamber to swing and lowering the upper piston (3) (see Fig. 13).

Due to the water pressure, the pre-brewing spring (5) sinks and the lower piston (4) goes down 4 mm, thus forming a water cushion which allows an even use of the coffee dose. At the end of the dispensing cycle and during a pause of 3 seconds, the pre-brewing spring (5) will discharge the water through the third way of the dispensing solenoid valve, lightly pressing the used coffee dose.

By completing its rotation, the ratiomotor makes the swinging lever (6) lift the pistons and the coffee dose.

At the same time, when the brew chamber returns to its vertical position, the scraper on the coffee hopper stops the used coffee dose and drops it. The lower piston now returns to the bottom dead centre.




Fig. 13

- 1 - Brew chamber
- 2 - External disk
- 3 - Upper piston
- 4 - Lower piston
- 5 - Pre-brewing spring
- 6 - Swinging lever

CHECKING AND ADJUSTING THE MACHINE SETTINGS

To get the best results from the product used, the following should be checked:

for coffee

That the used coffee dose is lightly compressed and damp.

The grade of grinding of coffee.

The weight of the ground coffee.

The dispensing temperature.

The water dose.

For instant products

The weight of the instant products.

The drink temperature.

The water dose.

Should the standard settings be varied, proceed as indicated in the next sections of this manual.

The weight of the instant products, the water dose and temperature are directly controlled by the microprocessor. To adjust them it is therefore necessary to follow the programming procedures.

STANDARD SETTINGS

The vending machine is supplied with the following settings:

- coffee temperature (at the spout) approx. 70÷80° C;
- instant product temperature (at the spout) approx. 70÷80° C;

The machine standard settings assign the same price, expressed in number of basic coins, to all selections.

ADJUSTING THE SETTING OF THE COFFEE UNIT PISTON STROKE

When the upper piston is correctly positioned, the coffee unit can operate with coffee doses of 5.5 to 7.5 g. To change the piston position (see Fig. 14):

- remove the snap ring from its seat;
- place the piston in the proper adjusting notches:
 - .less deep notches for 5.5 to 6.5 g doses;
 - .deeper notches for 6.5 to 7.5 g doses.




Fig. 14

- 1 - Snap ring
- 2 - Upper piston
- 3 - Reference fins

WATER TEMPERATURE CONTROL

If the boiler temperature is to be changed, adjust the special trimmer (see Fig. 19) keeping in mind that:

- tightening will increase the temperature;
- loosening will decrease the temperature;
- the temperature varies by approx. 1° C every 2 turns.

ADJUSTING THE GRADE OF GRINDING

When a variation in the grade of grinding is desired, turn the relevant adjusting knob on the grinder (see Fig. S) and more specifically:

- turn the knob anticlockwise for coarser grinding;
- turn the knob clockwise for finer grinding.




Fig. 15

- 1 - Coffee grinder
- 2 - Grinding adjusting knob
- 3 - Dose regulator
- 4 - Dose adjusting lever
- 5 - Reference notches

For optimum results, it is good practice to vary the grade of grinding with the coffee grinder motor running.

N.B.: After adjustment of the grade of grinding, at least 2 test selections must be performed in order to check the new grade of the ground coffee:

the finer the grade of grinding the longer the time necessary for dispensing the coffee and vice versa.

ADJUSTING THE COFFEE DOSE

The dose adjusting lever can be positioned in one of the 6 reference notches bearing in mind that:

- the dose is increased by lifting the lever:
- the dose is reduced by lowering the lever:
- every notch changes the dose by approx. 0.25 g.

In addition, when the lever is fully rotated upwards, the ratchet can be released from the groove in the dose regulator (see Fig. 15) and replaced into a different groove to change the average dose setting to:

- low 6 g. ± 0.5
- medium 7 g. ± 0.5
- high 8 g. ± 0.5

To take the dose just remove the coffee unit and press button "6" from "Special functions" of the "maintenance" menu (see relevant section).

Important notice!!!

To refit the coffee unit, pay special attention to the piston position. Reference notches on the external disk and on the unit case should match (see Fig. 17).

OPERATING MODES

Three different operating modes are provided for the machine, accordingly the buttons may have different functions based on the preset mode of the buttons. The available operating modes are as follows:

DISPLAY	FUNCTIONS
Normal operating mode	
"Ready for use"	coins accepted products dispensed
Maintenance mode	
"Maintenance"	test dispensing machine maintenance
Programming mode	
"Programming"	programming

NORMAL OPERATING MODE

When switching the machine on, the message "Rev. X.X" (X.X indicates the software release number) is displayed for a few seconds, after which the machine goes into normal operating mode.

The messages displayed according to the current operation are as follows:

DISPLAY	FUNCTION
"Ready for use"	Machine ready.
"Price:...."	Price display selection made
"Credit:....."	Credit display.
"Out of Service"	Machine out of service
"Drink in Process"	Preparation of drink
"Temperature"	Wait time before reaching the operating temperature
"Installation"	Installation under way
"Sel. not avail."	Selection disabled
"Coffee sel. out"	For espresso models only Coffee unit out of service
"Take the drink"	Drink ready

PRE-SELECTIONS

According to the layout set at the time of initialising buttons "1" and "5" can be assigned the function of sugar dose selection; in this case the display will indicate

"Sugar ■ ■ ■ □ □" which represents the programmed median dose. Each time buttons "1" (minus) and "5" (plus) are pressed the dispensed dose varies by 1/3 of the median dose.

For other layouts button "5" alone is used to increase the sugar dose by 1/3 of the median dose; when the highest level is reached, pressing button "5" again will bring the sugar dose to 0 (unsweetened selection).


In still other layouts, selections are normally unsweetened; it is possible to pre-select either a normal sugar dose (button 1) or extra sugar (button 5); sugar doses can be programmed. The display will indicate the message (sugar, extra sugar) which is current at the moment.

MAINTENANCE MODE

When the programming button located on the internal side of the push-button board (see Fig. 20) is pressed once the machine will go to "Maintenance" mode.

The message "Maintenance" is displayed for approx. two seconds and then the first option of the "Statistics" menu allowing management of data.

When in maintenance mode the buttons have the following functions:



- 1 - ↑ Previous function / Increase data item (+1)
- 2 - ← Exit function / Cancel change
- 3 -
- 4 -
- 5 - ↓ Next function / Decrease data item (- 1)
- 6 - → Confirm function / confirm data item
- 7 - → Change data item
- 8 -

Press button "6" to access the following functions:

Display statistics

Print statistics

Delete statistics

Display selection counter

Scroll through the menu with the "↑" and "↓" buttons to highlight the following functions:


"Compl. selec."	Dispensing test including cup, sugar and stirrer
"Powd. only"	Dispensing powder only
"Water only"	Dispensing water only
"No Accessories"	Dispensing test without cup, sugar and stirrer

When pressing button "6" the selection buttons will have the original function for 7 seconds, permitting the test dispensing provided for each function.

N.B. For espresso coffee based selections, only the additions are dispensed with the partial dispensing of powder and water; if a selection requires no addition the message "Sel. disabled" will be displayed.

"Special functions"

When the display shows "Special functions" the buttons have the following functions:



- 1 - ↑ Previous function
- 2 - Grind and release a coffee dose
- 3 - Dispense sugar
- 4 - Autotest
- 5 - ↓ Next function
- 6 - Rotate coffee unit
- 7 - Release cup
- 8 - Empty air-break

In order to weigh the coffee dose using the "Grind and release" function, the coffee unit must be removed. The function stays enabled anyway.

If a coffee dose is accidentally released with the unit installed, the unit will have to be rotated to unload the excess coffee.

According to the type of pre-selection set in the layout, button "3" allows access to the sugar dose, which can be adjusted with buttons "1" and "5"; pressing button "6" again will release the set sugar dose.

Alternatively, button "3" indicates the available doses on the display (sugar, extra sugar).

When pressing button "6" the current sugar dose will be dispensed.

AUTOTEST

This function is used to check the functioning of the main machine components.

Before carrying out this operation, remove the waste tray and the powder containers and disassemble the coffee unit.

When pressing button "4" the message "AUTOTEST" will be displayed blinking.

Press button "2" to cancel the operation, confirm with button "6" to start the autotest cycle.

In a sequence:

- the doser units are activated for 2 seconds
- the mixers are activated for 2 seconds
- a cup is released
- a stirrer is released
- (for Espresso models only) the coffee unit is rotated, a coffee dose is ground and then released.
- (for Espresso models only) the waste tray is detected; the machine stops until the waste tray is manually re-inserted
- the push-button panel is checked; the machine displays the number of the button which must be pressed and waits for this to be done before going to the next button (number 9 corresponds to the cleaning button).

EMPTYING THE AIR-BREAK

This function is used to partially empty the air-break, dispensing water from the milk solenoid valve for 8 seconds before blocking the machine, to allow the machine to be moved without spilling water; to restore normal functioning the machine must be switched off and then on.

Before moving the machine on a long distance, especially if involving the use of a vehicle, the hydraulic system must be emptied manually.

DISPLAYING THE STATISTICS

Pressing button "F" when the display indicates the "Display statistics" function causes the stored data to be sequentially shown on the screen, and more precisely:

- 1 - single selection counter;
- 2 - single price counter;
- 3 - counter per type of coin cashed;
- 4 - total cash counter;
- 5 - failure counter.

PRINTING THE STATISTICS

The statistics described in the section "displaying the statistics" can be printed with a RS-232 serial printer with a Baud rate of 9600, 8 data bit, no parity, 1 stop bit, connected to the serial port located on the push button board (the CITIZEN I-DP 3110-24RF 230 A p/n 9210219 printer is recommended). The hardcopy printout will also contain the machine code number and the printout progressive number.

The progressive hardcopy printout number can be reset only by initializing the machine.

To connect the printer do as follows:

- Press button "F" when the display indicates the "Print statistics" function and the message "Confirm?" will be displayed;
- before confirming connect and switch on the printer;
- press the confirm button "F" to start printing.

RESETTING THE STATISTICS

Press button "F" when the display indicates the "Reset statistics" function and the message "Confirm?" will be displayed blinking.

Press the confirm button "F", the message "Working" is displayed for a few seconds and the statistics are reset.

GENERAL COUNTER

The machine stores all selections in this counter, which cannot be reset.

This function allows reading of the counter or its display when the machine is switched on.

Press button "F" when the display indicates the "General counter" function and the function status (ON/OFF) will be displayed; press button "F" to display the status blinking, which can then be changed with the "▲" and "▼" buttons. Press button "F" again and the stored value will be displayed for 3 seconds.

PROGRAMMING

When the programming button located on the internal side of the push-button board (see Fig. 20) is pressed twice the machine will go to "Programming" mode.

The message "Programming" is displayed for approx. 2 seconds, after this the first option of the programming menu appears on the display enabling the following functions:

"Present failures"	reading of present failures
"Water dose"	water dose setting
"Powd. dose"	powder dose setting
"Set Price"	price setting
"Set price/button"	prices/button setting enable/disable selections
"Basic unit / DP"	basic coin value setting and decimal point position
"Payment systems"	validator totalizator Executive standard Executive price holding ECS URW3
"Initialising"	RAM initialising
"Machine code"	machine identification code setting
"Machine Config."	machine configuration setting
"Selec. counter"	setting the number of selections after which the machine will lock
"Prom. message"	enabling and setting the promotional message
"Language"	setting the language used to display messages
"Whipping time"	setting whipping time for instant coffee
"Password"	enabling password to access programming


"Selec. configuration" determining the accessories to be dispensed with each single button.

"Discount" determining the price reduction for selections without cup

"Special sales" setting free vend and jug facilities parameters

"Euro" displaying prices in the local currency and/or euro

When in "programming" mode the selection buttons have the following functions:



- 1 - ↑ Previous function / Increase data item (+1)
- 2 - ← Exit function / Cancel change
- 3 - Machine installation
- 4 -
- 5 - ↓ Next function / Decrease data item (- 1)
- 6 - → Confirm function / confirm data item
- 7 - → Change data item
- 8 - Reset failures

The buttons preceded by the symbol allow scrolling through the menu or changing of data, the other buttons are used directly for that function.

DISPLAYING PRESENT FAILURES

When the "Present failure" function from the "programming" menu is displayed, pressing confirm button "→" will display the error code of the current failure; when pressing button "↓" the error code of the next applicable failure is displayed.

If no failure is currently present, pressing confirm button "→" will display the message "No Failure".

The possible failures are shown in the following cases:

AIR-BREAK FAILURE

The machine will lock if after dispensing water corresponding to 150 pulses of the volumetric counter the microswitch has not signalled the lack of water.

BOILER FAILURE

The machine will lock if after 10 minutes of heating from the machine start, or from the last selection, the boiler fails to reach the operating temperature.

COIN MECHANISM FAILURE

The machine will lock if it receives a pulse longer than 2 seconds on a validator line or the communication with the serial coin mechanism does not take place for more than 30 seconds.

RAM DATA FAILURE

Data contained in the EEprom (i.e. the chip that stores the setting variations) is wrong and must be retrieved from the Eeprom, whereas all statistics information will be lost. The message "INITIALISE" will be displayed blinking.

WATER FAILURE

Models with water supply from the mains

If the air-break microswitch is closed for more than one minute. When pressing a selection button the water inlet solenoid valve is triggered to check water flow from the mains.

If the machine is equipped with a liquid waste container (housed in the cabinet) fitted with an overflow warning device, the solenoid valve will stay triggered until water from the mains is resumed.

Models with water supply kit (tank)

If the water level in the tank falls to less than approximately 300 cc.

CUP FAILURE

When the empty cup column microswitch opens, the column shift motor is activated. If after one full turn of the cup dispenser the microswitch is not closed the message "No cups" is displayed and the machine locks.

WATER LEAK FAILURE

If water is requested by the air-break without having been used (selections, cleaning etc.) the machine will block further water requests.

VOLUMETRIC COUNTER FAILURE

Failed computation by the volumetric counter within a max. given time.

COFFEE UNIT FAILURE

Due to a mechanical block, or non installation, of the unit. The machine is not locked, but all coffee based selections will be disabled.

COFFEE FAILURE

If after a period of 15 seconds of grinding coffee, a dose is not obtained, all coffee based selections are disabled.

COFFEE RELEASE FAILURE

If after releasing the ground coffee dose the microswitch of the coffee doser unit indicates the presence of coffee in the doser chamber, all coffee based selections are disabled.

CUP RELEASE FAILURE

If after releasing one cup the positioning microswitch is not triggered the control software disconnects power from the release motor and the machine locks.

LIQUID WASTE CONTAINER FULL

If the machine is equipped with a liquid waste container (housed in the cabinet) fitted with an overflow warning device, the machine locks.

PROGRAMMING THE WATER AND POWDER DOSES

When either the "Wat. dose" or the "Powd. dose" functions are displayed the doses can be varied from the "programming" menu.

The various doses are identified with a dose code, which is displayed each time.

The dose code locates the water and powder doses related to a given selection; changing the doses of a selection will have effect also on composed selections where the dose code is used.

Refer to the selection dose table for the dose code list.

The values of the doses displayed are expressed in:

- tenths of a second for powder;

- number of pulses of the volumetric counter for water.

Press the confirm button "☑" from the "programming" menu to access the dose code list, which can be scrolled with the "↓" and "↑" buttons.

When pressing correction button "→", this value will be displayed blinking and can be modified as necessary.

PRICE SETTING

When the "Set Price" function of the "programming" menu is displayed, the 8 sales prices stored can be changed.

The prices are indicated as number of basic coins.

Press the confirm button "☑" from the "programming" menu to access the price list, which can be scrolled with the "↓" and "↑" buttons.

When pressing correction button "→", this value will be displayed blinking and can be modified as necessary.

PROGRAMMING THE PRICES AND THE BUTTON STATUS

When the "Set Price/Button" (price setting) function of the "programming" menu is displayed, the combination of the button to one of the stored prices and/or to the status of a selection can be changed.

Press the confirm button "☑" from the "programming" menu to access the price list, which can be scrolled with the "↓" and "↑" buttons.

When pressing correction button "→" the selection status will blink and can be changed from (enabled) to (disabled) with the "↓" and "↑" buttons.

Press again the confirm button "☑" to display the price number referred to in the price table.

When pressing correction button "→", this value will be displayed blinking and can be modified as necessary.

The buttons which control pre-selections do not need combination with prices. In any case prices have no effect on the pre-selection buttons.

PROGRAMMING THE BASIC COIN AND THE DECIMAL POINT

When the "Basic unit / DP" (basic coin value) function of the "programming" menu is displayed, the value of the basic coin as well as the position of the decimal point can be modified.

Pressing the confirm button "↵" from the "programming" menu will display the current value of the basic coin.

By using the "↓" and "↑" buttons, the display will alternate between the value of the basic coin and the number of the decimal point position "DP", i.e.:

0	disabled decimal point
1	XXX.X
2	XX.XX
3	X.XXX

When pressing the correction button "↩", these values will be blinking and can be modified as necessary.

PAYMENT SYSTEMS

When the "Payment system" function is displayed, it is possible to define which payment system with Executive communication protocol to use, selecting among:

Validator

Totalizator

Executive standard

Executive price holding

ECS

URW3

In order to instal payment systems different from the validator or cashless, special kits must be used.

The payment systems must be housed in the cabinet (optional).

PROGRAMMING THE VALIDATOR

If the selected payment system is a validator, the parameters with which operate must be defined.

CREDIT CONTROL

It is possible to decide whether to cash the excess credit paid or to leave it available to the user.

OPERATING VOLTAGE

According to the type of validator it necessary to select the operating voltage, 12 V or 24 V.

VALIDATOR LINES

When the "Validator lines" function (line programming) is displayed, the value of the 6 validator coin lines can be changed.

The value of the lines is expressed in number of basic coins.

Press the confirm button "↵" from the "programming" menu to access the list of lines, which can be scrolled with the "↓" and "↑" buttons.

When pressing correction button "↩", this value will be displayed blinking and can be modified as necessary.

INITIALISING

When the "Initialising" function is displayed, the machine can be initialised, thus resetting all default data.

This function is used in case of stored data error or replacement of the EPROM.

All statistical data are reset.

Press the confirm button "↵" and message "Confirm?" is displayed. Press the button "↵" again to display the first variable parameter to define the machine configuration.

The available options (blinking) can be scrolled with the "↓" and "↑" buttons, the selection is confirmed with button "↵" and the next parameter is presented. When pressing button "↵" after the last parameter the display will show the message "Working" for a few seconds and the machine is initialised.

The parameters are as follows:

"Machine type"	C - Espresso I - Instant
"Country"	Type of doses to be used for the selections
"Layout"	Layout of containers and selection menu from the available ones
"Tank"	Water supply from the mains or from a tank

SETTING THE MACHINE CODE

When the "Machine code" function is displayed the identification code number of the machine can be changed (from the default 0000 to a number up to 9999).

Press the confirm button "↵" to display the current code; when pressing the correction button "↩" the first digit will blink.

The value of the blinking digit can be increased or decreased with the "↓" and "↑" buttons.

When pressing the confirm button "↵", the blinking digit will be given the displayed value and the next digit starts blinking.

MACHINE CONFIGURATION

When the "Machine Config." function is displayed, the machine configuration can be changed, and namely:

- cup dispensing / without cup
- dispensing stirrers with unsweetened selections
- water supply from the mains / internal tank
- presence of warning device for full liquid waste container (inside cabinet)
- for instant models, before releasing the cup, dispensing 20 cc. of water to heat the coffee mixer; this function can either be enabled or disabled.

Press the confirm button "➡" to display the current status; when pressing the correction button "←" the status blinks and can be changed with the "↓" and "↑" buttons.

IMPORTANT NOTICE!!!

When the machine is initialised, the configuration will be assigned the default values "/with cup/with stirrer/without mixer heating/without full waste container warning device".

THEREFORE, AFTER INITIALISING THE MACHINE MUST BE RECONFIGURED.

SELECTION COUNTER

This function is used to lock the machine after a preset number of coffee selections, and a preset number of instant selections.

Since this is a control tool used only by the vending manager, a 4-digit password must be entered.

After entering the password, the number of selections, after which the machine locks, can be set, the number of selections already made can be read and the lock counter can be reset.

N.B.: The counters are set to zero by default;


With the counters set to zero, this function is disabled.

SETTING THE PROMOTIONAL MESSAGE

When this menu is displayed, press the confirm button "➡" to display whether the message is enabled or not (ON/OFF).

If the message is enabled, when pressing the confirm button "➡" the first character will blink, which can then be changed.

The buttons will be assigned the following functions:



- 1 - Previous character
- 2 - Next character
- 3 - Upper case/lower case

The values are displayed one after the other by pressing the button.

The message is stored by pressing button "2" when on the last position.

SELECTING THE LANGUAGE

This function is used to select the language to be used for displaying the messages.

The available languages are: Italian, French, English, Spanish, Portuguese and German.

WHIPPING TIME

This function is used to define how long (in tenths of a second) instant coffee is to be whipped according to the amount of drink to be obtained.

PROGRAMMING ACCESS PASSWORD

This function is used to enable the request for a password to access the programming procedures.

The password is composed the sequence of buttons 1 1 2 2 and cannot be changed.

SELECTION CONFIGURATION

This function is used to determine, as an exception to the machine configuration, which accessories should or should not be dispensed for a single selection.

The following is possible for each selection button (1 to 8, excluding the pre-selection buttons):

- not dispense the cup (if the machine configuration includes the cup, but not vice versa);
- not dispense the stirrer if the selection is unsweetened;
- not dispense sugar and stirrer for selections which are defined as sweetened (but not dispense sugar for selections which are defined as unsweetened).

The settings defined with the selection configuration are used also for complete test selections.

DISCOUNT

This function is used to define the price reduction (in basic coins) to be applied to the pre-selection "without cup".

SPECIAL SALES

Free Vend and "Jug facilities" can be enabled/disabled by entering a programmable password.

The password and the number of selections for each jug facilities cycle can be programmed only if the function to which they are connected is enabled.

A password already used for other functions is not accepted and a different button combination must be used. The password must be entered for each special sales cycle, after pressing button "8" for 2 seconds.

EURO

Normally prices and credit are displayed according to what was set in price programming.

If enabled, this function allows the display of such values alternating in Euro and in the local currency.

It is also possible to define whether the conversion is to be made from Euro to local currency or vice versa; the calculation is carried out using the conversion parameters set for each currency.

INSTALLATION

Pressing the installation button "3" will enable the filling operation of the hydraulic system, even with the air break full.

RESETTING FAILURES

When pressing the failure reset button "8" the message "Working" is displayed for a few seconds and all current failures will be reset.

PROGRAMMER (OPTIONAL)

AUTOMATIC SETUP TRANSFER

Using the programmer device makes it possible to read out the programming routines set and transferred to other apparatuses from a given vending machine.

These data are preserved also when the programmer is disconnected thanks to a couple of Duracell batteries LR03 Format AAA 1.5 V (to be replaced every 12 months). The programmer allows up to twenty different programs (setups) to be stored.

To identify, among the 20 setups available, those containing data, a special character is displayed, and more precisely:

< - > = Setup free

< □ > = Setup with data.

When creating the setup only the programs containing data are available; if no setup contains data, the message "no data available" will appear on the programmer display. The special holder (see Fig. 16) is used to connect the programmer to the machine, connecting the cable to the special connector of the push-button board (see Fig. 20). Then enter the "programming" mode and press twice the relevant button on the push-button board.

Now, by inserting the programmer in its holder, an automatic connection will take place, and the setup menu will be shown on the programmer display:

- Pressing button "E" will access the displayed function;
- Pressing button "O" will display the following function;
- Pressing button "C" will display the previous function.




Fig. 16

- 1 - Connector
- 2 - Programmer holder
- 3 - Programmer

PROGRAMMER SETUP READING	SETUP READING SETUP 01 <X>	SETUP 01 Confirm?	<X>
	SETUP READING SETUP 20 <X>		
PROGRAMMER CREATE SETUP	CREATE SETUP SETUP 01 <X>	SETUP 01 Confirm?	<X>
	CREATE SETUP SETUP 20 <X>		

SETTING THE LANGUAGE

It is possible to change the programmer configuration as concerns the language in which the messages are to be displayed as well as to reset all of the data therein contained. To activate the "Programmer configuration" operate as follows:

- insert the programmer in its holder and start the machine.
- wait about 10" and then press the programmer buttons "C" and "O"; the first function will be thus displayed:

LANGUAGE CONFIGURATION	CONFIGURATION ITALIAN	CONFIGURATION Confirm?
	CONFIGURATION FRENCH	
	CONFIGURATION GERMAN	
	CONFIGURATION ENGLISH	
	CONFIGURATION SPANISH	
CONFIGURATION	INITIALISE INITIALISE	Confirm?
CONFIGURATION CONFIG. END	Exit from the configuration menu The software starts again from address 0000 (as when the machine is started)	

TRANSFERRED DATA

Data transferred with the set up is as follows:

Water and powder doses
8 price table
Prices/button status
Basic coin
Decimal point position
Payment systems
Validator operating voltage
Validator lines
Credit control
Machine type
Country
Layout
Water supply
Machine code
Machine configuration
Selection counter
Promotional message
Setting the language
Whipping time
Programming access password
Discount
Special sales
Password for Free Vend
Password for "Jug facilities"
Number of selections for "Jug facilities"

MAINTENANCE

Important notice!!

Access to the machine interior for maintenance and/or repairs is via the back panel.

Therefore, provisions must be made for the machine to be rotated, thus allowing removal of the back panel.

The integrity of the vending machine and its conformity with the rules and regulations in force for its relevant systems must be checked by qualified personnel at least once a year.

Switch the machine off before any maintenance operations which require removal of components.

The following operations must be carried out only by personnel who have the specific knowledge of the machine functioning from a point of view of electrical safety and health regulations.

INTRODUCTION

To ensure perfect operation for a long period, the machine must be subjected to regular maintenance.

The following sections contain the procedures and the maintenance schedule, which are only a general indication, as they greatly depend on the operating conditions (e.g. water hardness, environmental humidity and temperature, type of product used, etc.).

The procedures described in this chapter are not exhaustive of all maintenance operations to be carried out.

More complex operations (e.g. boiler descaling) should be carried out by qualified technicians only having specific knowledge of the machine.

To prevent oxidation or the action of chemical agents, the stainless steel and varnished surfaces should be kept clean by using mild detergents (solvents must not be used).

Never use water jets to clean the machine.

MAINTENANCE OF THE BREWING UNIT

Every 10,000 selections or every 6 months some maintenance of the coffee unit must be carried out.

Maintenance is carried out as follows:

- remove the boiler teflon hose connection from the upper piston, paying attention not to lose the seal (see Fig. 17);
- undo the knob securing the unit to the bracket;
- remove the brewing unit.




Fig. 17

- 1 - Coffee funnel
- 2 - Boiler connecting hose
- 3 - Unit securing knob
- 4 - Upper piston snap ring
- 5 - Lower piston snap ring
- 6 - Reference notches
- 7 - Ratiomotor handle pin

Removing the upper filter

- Take the snap ring out of its seat;
- remove the piston from the crosspiece;
- remove the filter and the piston sealing.

Removing the lower filter

- Loosen screws A and B enough to release the coffee funnel (see Fig. 17);
- remove the lower piston snap ring;
- take the piston from out of brew chamber and remove the filter.

Soak all components removed from the unit in a solution of boiling hot water and coffee machine detergent for approx. 20 minutes.

Thoroughly rinse and dry all parts, then reinstall them in the reverse order of disassembly, taking particular care that:

- the piston is positioned in the correct notch for the coffee dose used (see relevant section);
- the two reference notches match and that the coffee unit is inserted.

Important notice!!!

Check that the handle pin of the ratiomotor is correctly engaged in its seat.

REGENERATING THE SOFTENER UNIT (OPTIONAL)

Only a 2-litre ion-exchange resin softener unit can be used on these machines.

The resins should be regenerated at least once a week or even more frequently depending on the hardness of the water from the mains used to supply the machine (see table below).

Water hardness		Number of selections	
° F	° G	60 cc.	130 cc.
10	5,6	5600	2800
20	11,2	2800	1400
30	16,8	1900	900
40	22,4	1400	700
50	28,0	1100	550

To regenerate the resins correctly do as follows:

- remove the softener unit from the cabinet and shake it vigorously to eliminate any preferential paths which may have formed;
- fill 0.5 Kg. of sodium chloride (ordinary salt);
- connect the side hose union to a tap and the middle rubber-holder to a drain point; the direction of the water flow must be

NECESSARILY

the one shown in the figure 18




Fig.. 18

- 1 - From the tap
- 2 - Cap
- 3 - To the machine
- 4 - Softener unit
- 5 - To the drain

- adjust the water flow in such a way as to completely dissolve the salt in 10 litres water within 25 minutes;
- during the regeneration operation, ensure that the softener unit is always full of water, bleeding any air which may have entered;
- at the end of this operation ensure that outlet water is no longer salted; it is advisable to check the hardness of the water by means of appropriate chemical reagents: the outlet water hardness should be 0° F.

ANNUAL SANITISING

At least once a year, or more frequently according to the use of the machine and the quality of the inlet water, the entire foodstuff circuit system must be cleaned and sanitised in the following way:

- all parts of the hydraulic system in contact with food, including the hoses, must be removed from the unit and fully disassembled;
- wash all components with detergents, ensuring that all visible residue and product films are mechanically removed using brushes or similar tools, if necessary;
- all components must be soaked in a sanitising solution for at least 20 minutes;
- the unit internal surfaces are to be cleaned with the same sanitising solution;
- Thoroughly rinse and then reinstall the parts.

Before restarting the unit, the same sanitising procedure described in section "Sanitising the foodstuff circuits and the mixers" should be repeated with the components reassembled.

PRINTED BOARD FUNCTIONS AND INDICATOR LIGHTS

CONTROL BOARD

This board, placed at the back of the machine, (see Fig. 19) processes the information from the push-buttons and from the payment system, it also controls the actuations and the push-button board.

The 15 V AC voltage required for board operation is supplied by a transformer which is protected by a 125 mA T fuse on the primary and by a 1.25 AT fuse on the secondary winding. The voltage supply is rectified and stabilised directly by the board.

The board also houses the EPROM (see Fig. 19).

- the yellow LED indicates the presence of 12 V DC;
- the green LED, when blinking indicates that the micro-processor is working correctly;
- the red LED indicates the operating status of the boiler heating element.

RELAIS	ESPRESSO	INSTANT
K1	ER	E3
K2	ESC	MD3
K3	MAC	MF2
K4	PM	PM
K5	M	MD4
K6	EV2	EV2
K7	EV1	EV1
K8	MF1	MF1
K9	MDZ	MDZ
K10	MD2	MD2
K11	MD1	MD1
K12	EEA	EEA
K13	MSCB	MSCB
K14	MSB	MSB
K15	MSP	MSP





Fig. 19

- 1 - 230 V~ users
- 2 - RAM
- 3 - EPROM
- 4 - Input signal
- 5 - Green LED
- 6 - Not used
- 7 - To push-button board
- 8 - Expansion board for payment systems (optional)
- 9 - Boiler temperature trimmer
- 10 - Yellow LED
- 11 - Board power supply
- 12 - Red LED
- 13 - To boiler heating element
- 14 - Boiler heating element triac
- 15 - 230 V~ users
- 16 - Relay
- 17 - Expansion board
- 18 - Transformer fuse
- 19 - Mains fuse



PUSH-BUTTON BOARD

This board controls the alphanumeric display, the selection keys and the programming button (see Fig 20). It supports the coin mechanism connectors as well as the printer port.






Fig. 20


- 1 - To the front validator
- 2 - Not used
- 3 - To machine board
- 4 - Signals: free vend- jug facilities
- 5 - To display board
- 6 - Display contrast adjusting trimmer
- 7 - Programming button
- 8 - Cleaning button
- 9 - RS232 port
- 10 - To the programmer
- 11 - Display board

Espresso




- 1 - Water inlet solenoid valve
- 2 - Air-break
- 3 - Volumetric counter
- 4 - Vibration pump
- 5 - Bypass
- 6 - Boiler
- 7 - Coffee unit


Instant




"Maintenance" menu




"Maintenance" menu



"Maintenance" menu




Programming menu



FAILURE DISPLAY


LIST OF FAILURES

- N. 1 - Air-break
- N. 2 - Boiler
- N. 3 - Coin mechanism
- N. 4 - RAM data
- N. 5 - Water failure
- N. 6 - Cup failure
- N. 7 - Water leak
- N. 8 - Volumetric counter
- N. 9 - Coffee unit
- N. 10 - Coffee failure
- N. 11 - Coffee release
- N. 12 - Cup release
- N. 13 - Liquid waste full




WATER DOSES

Refer to the selection dose table for the correspondence between dose code and water dose




POWDER DOSES


Refer to the selection dose table for the correspondence between dose code and powder dose




PRICE VALUE




Programming menu




Programming menu




Programming menu




Programming menu



Programming menu




Programming menu





SELECTION CONFIGURATION

DISCOUNT WITHOUT CUP

- 1 - ↑ Previous function / Increase data item (+1)
- 2 - ← Exit function / Cancel change
- 3 - Machine installation
- 4 -
- 5 - ↓ Next function / Decrease data item (- 1)
- 6 - → Confirm function / confirm data item
- 7 - → Change data item
- 8 - Reset failures




Programming menu










Failure list

- 1 - ↑ Previous function / Increase data item (+1)
- 2 - ← Exit function / Cancel change
- 3 - Machine installation
- 4 -
- 5 - ↓ Next function / Decrease data item (- 1)
- 6 - → Confirm function / confirm data item
- 7 - → Change data item
- 8 - Reset failures





WIRING DIAGRAM LEGEND

CODE	DESCRIPTION	CODE	DESCRIPTION
BDV	BDV COIN MECH CONNECTOR	MAC	GRINDER
CM1	COFFEE UNIT MOTOR CAM	MD1-..	DOSER UNITS - INSTANT
CMSB	CUP RELEASE MOTOR CAM	MDB	CONNECTOR FOR MDB COIN MECHANISM
CV	VOLUMETRIC COUNTER	MDZ	DOSER UNIT - SUGAR
E1-...	SOLENOID VALVE - INSTANT	MF1-..	WHIPPER MOTOR
EEA	WATER INLET SOLENOID VALVE	MSB	CUP RELEASE MOTOR
ER	COFFEE DISPENSER SOLENOID VALVE	MSCB	CUP CONTAINER SHIFT MOTOR
ESC	COFFEE RELEASE MAGNET	MSP	STIRRER RELEASE MOTOR
EX	EXECUTIVE COIN MECH CONNECTOR	NTC1-..	TEMPERATURE PROBE
FA	RADIO INTERFERENCE SUPPRESSOR	PM	PUMP
ID	COFFEE DOSE SWITCH	RCC	COFFEE BOILER HEATING ELEMENT
IMSP	STIRRER RELEASE MICROSWITCH	RIS	COFFEE UNIT HEATER
IP	DOOR SWITCH	RS232	SERIAL PORT
IPF	WASTE CONTAINER OVERFLOW SWITCH	SM	CONTROL BOARD
IVA	EMPTY BOILER MICROSWITCH	SP	PUSH-BUTTON BOARD
IVB	EMPTY CUP DISPENSER MICROSWITCH	TR	TRANSFORMER
KC1-..	COFFEE BOILER CUTOUT	TR1	TRANSFORMER 230 V 24 V
KS1-..	SAFETY CUTOUT	TX....	DELAYED FUSE (X=CURRENT)
LCD	LIQUID CRYSTAL DISPLAY	VAR	VARISTOR
M	COFFEE UNIT MOTOR	VENT	FAN








NECTA VENDING SOLUTIONS SpA
 SI RISERVA A TERMINI DI LEGGE
 LA PROPRIETA' DEL PRESENTE
 DISEGNO CON DIVIETO DI
 RIPRODURLO O DIVULGARLO SENZA
 SUA PREVIA AUTORIZZAZIONE

- | | |
|---|------------|
| 0 | NERO |
| 1 | MARRONE |
| 2 | ROSSO |
| 3 | ARANCIO |
| 4 | GIALLO |
| 5 | VERDE |
| 6 | BLU |
| 7 | AZZURRO |
| 8 | ROSA |
| 9 | VIOLA |
| 0 | GRIGIO |
| 1 | BIANCO |
| 2 | BLACK |
| 3 | BROWN |
| 4 | RED |
| 5 | ORANGE |
| 6 | YELLOW |
| 7 | GREEN |
| 8 | BLUE |
| 9 | LIGHT BLUE |
| 0 | PINK |
| 1 | VIOLET |
| 2 | GREY |
| 3 | WHITE |
| 4 | NOIR |
| 5 | MARRON |
| 6 | ROUGE |
| 7 | ORANGE |
| 8 | JAUNE |
| 9 | VERT |
| 0 | BLEU CIEL |
| 1 | ROSE |
| 2 | ROSE |
| 3 | GRIS |
| 4 | BLANC |
| 5 | SCHWARZ |
| 6 | BRAUN |
| 7 | ROT |
| 8 | GELB |
| 9 | GRUEN |
| 0 | BLAU |
| 1 | HELLBLAU |
| 2 | ROSA |
| 3 | LILLA |
| 4 | GRAU |
| 5 | FELTS |
| 6 | NEGRO |
| 7 | MARRON |
| 8 | ROJO |
| 9 | NARANJA |
| 0 | AMARILLO |
| 1 | VERDE |
| 2 | OSCURO |
| 3 | AZUL CLARO |
| 4 | ROSA |
| 5 | ROSA |
| 6 | GRIS |
| 7 | BLANCO |





	MODELLO Colibrì Espresso	GRUPPO SCHEMA ELETTRICO FUNZIONALE	DATA 22-04-00	FOGLIO 1/1	DISEGNATO BONACINA	CONTROLLATO AGUTI
			LEGENDA	CODICE 608535400		



NECTA VENDING SOLUTIONS SpA
 SI RISERVA A I TERMINI DI LEGGE
 LA PROPRIETA' DEL PRESENTE
 DISEGNO CON DIVIETO DI
 RIPRODURLO O DIVULGARLO SENZA
 SUA PREVIA AUTORIZZAZIONE

1	NERO
2	MARRONE
3	ROSSO
4	GRANCILO
5	GIALLO
6	VERDE
7	BLU
8	AZZURRO
9	VIOLA
0	BIANCO
1	BLACK
2	BROWN
3	RED
4	ORANGE
5	YELLOW
6	GREEN
7	BLUE
8	LIGHT BLUE
9	PINK
0	VIOLET
1	GREY
2	WHITE
3	INDIRON
4	ROUGE
5	ORANGE
6	JAUNE
7	VERT
8	BLEU CIEL
9	ROSE
0	ROSE
1	BLANC
2	SCHWARZ
3	ROT
4	ROT
5	ORANGE
6	GELB
7	GRUEN
8	BLAU
9	HELLBLAU
0	ROSA
1	LILLA
2	GRAU
3	WEISS
4	NEGRO
5	MARRON
6	ROJO
7	NARANJA
8	AMARILLO
9	VERDE
0	OSCURO
1	AZUL CLARO
2	ROSA
3	ROSA
4	GRIS
5	BLANCO



	MODELLO Colibrì Instant	GRUPPO SCHEMA ELETTRICO FUNZIONALE	DATA 22-04-00	FOGLIO 1/1	DISEGNATO BONACINA	CONTROLLATO <i>[Signature]</i>
						LEGENDA CODICE 608535600

The Manufacturer reserves the right to modify, without prior notice, the characteristics of the equipment described in this publication; and further declines to accept any responsibility for any inaccuracies contained in this publication which can be ascribed to printing and/or transcription errors.

All instructions, drawings, tables and information contained in this publication are confidential and can neither be reproduced completely or in part, nor be transmitted to third parties without the written permit of the Manufacturer, who has the sole ownership.

EDITION 12 00 CODE: H 155U 01



NECTA
VENDING SOLUTIONS SpA
Sede legale: Via Roma 24
24030 Valbrembo (BG) Italia

Telefono +39 035 606111
Fax +39 035 606460
Telex 300676 ZANIMD
Web: www.nectavending.com