



Service & Parts Manual

Rock-Ola *Nostalgic* Jukeboxes

CD-4 *Gazelle*



CD-8 *Bubblers*

CD-6 *Peacock*



Table of Contents

Section A	Jukebox Specifications	
Section B	Set-up and Preparation	
	Major Component Location	B - 2
	Unpacking the Phonograph	B - 3
	Power Up	B - 3
	Loading Program Pages	B - 4
	Loading Compact Discs	B - 5
	Repacking/Moving	B - 5
Section C	Connecting Speakers, Telephone Adaptor Kit, I.R. Remote Detector and Paging Microphone	
	External Speaker Connections	C - 2
	Speaker Loading	C - 2
	Connection Examples	C - 3
	Installation of the Telephone Adaptor Kit for Removable Volume Control	C - 6
	Installation of the I.R. Remote Detector and Harness Assembly	C - 7
	Connecting A Paging Microphone	C - 8
Section D	Amplifier Description and Operation	
	Amplifier Description	D - 2
	Indicator LED's	D - 3
	Signal Inputs and Outputs	D - 3
	Amplifier Feature Description	D - 4
	Setting The Amplifier	D - 4
Section E	Operation and Programming Overview	
	Normal Operation	E - 2
	Control Computer Buttons	E - 3
	Programming, Service and Diagnostics Features Overview	
	Suspend Mode	E - 4
	Service Mode	E - 4
	Setup Mode	E - 5
	Diagnostic and Error Reporting Features	E - 6
	Quick Find Reference Programming Chart	E - 7
	Quick Find Reference Programming Definitions	
	Disc Mapping	E - 8
	Page Options	E - 8
	Play Options	E - 9
	Auto Play	E - 9
	Free Play	E - 10
	Pricing	E - 11
	Set-up 1	E - 12
	Set-up 2	E - 13
	Set-up 3	E - 14

Accounting	E - 14
Popularity	E - 15
Disc Errors	E - 15
Remote Control.....	E - 16
Test Mode.....	E - 16
Auto test.....	E - 18
TCM Setup.....	E - 18
Amp Setup.....	E - 21

Quick Find Reference Programming Flow Charts

Set up Mode Flow Chart.....	E - 23
Disc Mapping.....	E - 24
Page Options.....	E - 26
Play Options.....	E - 27
Auto Play.....	E - 28
Free Play.....	E - 33
Pricing.....	E - 36
Set-up 1.....	E - 38
Set-up 2.....	E - 41
Set-up 3.....	E - 43
Accounting.....	E - 44
Popularity.....	E - 48
Disc Errors.....	E - 49
Remote Control.....	E - 51
Test Mode.....	E - 54
Auto test.....	E - 59
TCM Setup.....	E - 61
Amp Setup.....	E - 65

Section F

Routine Service

Accounting.....	F - 2
Popularity.....	F - 4
Disc Changing.....	F - 5
Appearance and Preventative Maintenance.....	F - 5
Checking For Errors.....	F - 6

Section G

Maintenance

Maintenance.....	G - 2
General Maintenance Considerations.....	G - 2
Preventative Maintenance.....	G - 2
Mechanical Adjustments	
Magazine Adjustments.....	G - 4
CD Player Adjustments.....	G - 5
Title Page Adjustments.....	G - 6
Coin Mechanism Cleaning.....	G - 6
Replacing Fluorescent Lamps.....	G - 6

Section H

Troubleshooting and Repair

Troubleshooting and Repair Overview.....	H - 2
Troubleshooting Charts	
Power and Start up Problems.....	H - 3
Credit Problems.....	H - 4

Play Problems.....	H - 4
Page Problems	H - 5
Fuse and LED Locations	
Power Supply Fuses.....	H - 6
Keyboard LEDs.....	H - 6
Digital Amplifier & Power Supply LEDs & Connections.....	H - 6
Block Diagrams	
Amplifier Block Diagram	H - 7
CPU Block Diagram.....	H - 8
CD Player Start-Up and Run Diagram	H - 9
Power Distribution Block Diagram	H - 10
Start up and Diagnostic Mode Operation.....	H - 11
Test Mode	H - 12
Viewing Error Codes	H - 12
Using Error Codes	
CPU (Input) Error Codes	H - 13
Keyboard Error Codes.....	H - 14
Mechanism Error Codes.....	H - 15
Page Unit Error Codes	H - 15
Running Tests	
CPU Tests	H - 16
Keyboard Test	H - 18
Display Test.....	H - 18
Pages Test.....	H - 19
Mechanism Tests.....	H - 19
Amplifier Troubleshooting	H - 21

Section I

Major Component Schematics

CPU.....	I - 2
Amplifier/Power Supply	I - 8
Audio Output Panel	I - 20
Keyboard/Display	I - 21
Removable Volume Control	I - 23
Crossover	I - 24
Transformer	I - 25
Lighting Wiring Diagram.....	I - 26
Primary Power Block Diagram	I - 27

Section J

Common Accessories (optional)

Section K

Parts Catalog