


No. 19705-A Power Distribution Panel Assembly

Part No. Description

1	17604	Control Circuit Transformer
2	19006	Miniature Outlet
3	17596	4 Prong Socket
4	19006	Miniature Outlet
5	PH-3722	4 Prong Socket
6	PH-3740	5 Prong Socket
7	19008	6 Prong Jones Socket
8	ST-4321	1.6 Amp. Fuse
9	ST-3090	3 Amp. Slo-Blo Fuse
10	19006	Miniature Outlet
11	PH-3523	3 Amp. Fuse
12	ST-3092	10 Amp. Fuse
13	19006	Miniature Socket



No. 19705-A Power Distribution Panel Assembly


Part No. Description

1	11555	Fuse Holder
2	17621	Power Rectifier
3	18859	Start Relay (D.C.)
4	18417	.01 MFD. 400 V. Condenser
5	15476	.002 MFD. 1200 V. Condenser

Additional Parts Listing

Part No. Description

1	ST-3046	Type #44 Bulb
2	ST-6028	Caster
3	ST-7379	Cash Door Lock
4	ST-7392	Rear Door Lock
5	ST-7394	Front Door Lock
6	12053	20 W. Fluorescent
7	13362	Master Line Switch
8	15159	Momentary Push Switch
9	17008	Needle Brush
10	17804	Brush Wire
11	17958	Leveling Bolt



Part No. Description

12	19726	10¢ and 3 for 25¢ Decal
13	19725	5¢ - 10¢ - 25¢ Decal
14	19724	5¢ - 10¢ - 6 for 25¢ Decal
15	18930	Cash Door Frame
16	18938	Cash Bag
17	19727	10¢ and 4 for 25¢ Decal
18	19292	15" Hi-Fi Speaker
19	19106-A	Volume Control Assembly
20	19614-A	Skid Front Casting Assem.(R.H.)
21	19615-A	Skid Front Casting Assem.(L.H.)
22	19172-A	Cash Door Assembly