
WRATE K	SERVICE MANUAL		Page No.	60/01/1
	ry From House Europe	- BERVICE MAINUAL	Issue No.	1
Machine Type KENCO 6GM BREWER			Document No.	SM/56
Section	on FAULT FINDING		Date	02/08/01



Measure across terminals.

Do not measure either terminal with respect to Earth.