

Smart Food Machine.

Re-Setting Failures

- 1/. Open door, machine will read M = Statistics.
- 2/. Press button 'C' once, machine will read Set Prices.
- 3/. Press button '0' five times, machine will read Present Failure.
- 4/. Press button 'E' once, machine will read Failure Display.
- 5/. Press button '0' once, machine will read Delete Failure.
- 6/. Press button 'E' twice.
- 7/. You have now reset the failures.
- 8/. Press button 'C, twice, machine will read M Statistics.
- 9/. You can now shut the machine door.