

# Snakky quick pricing guide

## Stage 1

- ❑ Power up the machine by inserting yellow key
  - ❑ Press mode button on processor board (Statistics Fill 1)
  - ❑ Press O button (Fill 2 individual price)
  - ❑ Press E button (Price band 0)
  - ❑ Press E button (Select number 11)  
Price 000.00
- 

## Stage 2

- ❑ Press E (Select number “11”)  
# Selection number flashes #
  - ❑ Enter the selection number to be priced, directly followed by the price required
- 

## Important

The price must be entered as a full 5 digits

After entering the last digit of the price, the price stops flashing

---

## Stage 3

- ❑ Press C button Price and amount both flash
- ❑ Press E button Saves price setting and moves to next selection

Proceed from stage 2 to price next selection, or-

- ❑ Press C button Exits pricing