

Assembly
and
Operation
of the



Q MULTIPLIER
MODEL GD-125




TABLE OF CONTENTS

Introduction,	2
Parts List,	3
Step-By-Step Assembly	
Chassis Assembly,	4
Function Switch Wiring,	6
Installation,	12
Alignment,	13
Operation,	15
In Case Of Difficulty,	16
Specifications,	16
Circuit Description,	17
Schematic, (fold-out from page),	19

HEATH COMPANY
BENTON HARBOR,
MICHIGAN

Copyright © 1965
Heath Company
All rights reserved

8/12/66

INTRODUCTION

The Heathkit Model GD-125 Q Multiplier is used with communications receivers to provide additional selectivity and signal rejection. Because its peak or null effect can be tuned across the receiver IF bandpass, the operation of the Q Multiplier is more flexible than that of a fixed frequency IF filter.


The Q Multiplier may also be used with a receiver which already has an IF filter, to obtain two simultaneous functions. For example, the IF filter could be set to peak the desired signal and the Q Multiplier used to null an adjacent signal.

When properly connected and adjusted, the Q Multiplier will not decrease receiver sensitivity.

In the peak function, an audible gain will be noted on CW signals, and a carrier gain will be noted on the S meter for phone signals. However, the audio will be attenuated slightly due to narrowing of the received sidebands.

The reduced sideband reception will tend to attenuate the higher audio frequencies. This is more than compensated for by the increased readability against the surrounding QRM.

NOTE: Refer to the "Kit Builders Guide" for complete information on unpacking, parts identification, tools, wiring, soldering, and step-by-step assembly procedures.



PARTS LIST

The numbers in parentheses are keyed to the numbers on the Parts Pictorial (fold-out from Page 3). The instructions in the Kit Builders Guide show you how to identify resistors and capacitors.

PART No.	PARTS Per Kit	DESCRIPTION	PART No.	PARTS Per Kit	DESCRIPTION
RESISTORS			Hardware (cont'd.)		
1/2 Watt			(15) 252-15	2	4-40 nut
(1) 1-9	1	1000 Ω (brown-black-red)	(16) 252-3	5	6-32 nut
1-11	1	1500 Ω (brown-green-red)	(17) 252-7	3	Control nut
1-13	2	2700 Ω (red-violet-red)	(18) 252-9	1	Push-on speednut
1-18	1	5600 Ω (green-blue-red)	(19) 253-10	3	Control flat washer
1-23	1	27 K Ω (red-violet-orange)	(20) 254-9	6	#4 lockwasher
1-25	1	47 K Ω (yellow-violet-orange)	(21) 254-1	7	#6 lockwasher
1-26	1	100 K Ω (brown-black-yellow)	(22) 259-1	1	#6 solder lug
1-29	1	220 K Ω (red-red-yellow)	(23) 254-4	2	Control lockwasher
1-37	2	2.2 megohm (red-red-green)	(24) 259-10	1	Control solder lug
			(25) 259-11	2	Spade lug
1 Watt			WIRE-SLEEVING		
(2) 1A-7	1	47 K Ω (yellow-violet-orange)	89-1	1	Line cord
			343-2	1	Coaxial cable
			344-59	1	Hookup wire
			346-1	1	Sleeving
CAPACITORS			MISCELLANEOUS		
(3) 20-42	1	510 $\mu\mu\text{f}$ mica	(26) 57-27	1	Silicon diode, 750 ma, 500 PIV
20-53	1	.0011 μfd mica (1100 $\mu\mu\text{f}$)	(27) 75-24	1	Line cord strain relief
20-54	1	.0033 μfd mica (3300 $\mu\mu\text{f}$)	(28) 205-254	1	Alignment tool blade
(4) 21-27	4	.005 μfd disc	261-4	4	Rubber feet
(5) 25-80	1	20-20 μfd electrolytic	411-26	1	12AX7 tube
(6) 26-28	1	100 $\mu\mu\text{f}$ variable	(29) 412-13	1	Neon lamp
CONTROLS-SWITCH-TRANSFORMER-COILS			(30) 431-51	1	2-lug terminal strip
(7) 10-7	2	5000 Ω control	(31) 431-55	1	6-lug terminal strip
(8) 63-288	1	4-position rotary switch	(32) 434-42	1	Phono socket
54-2	1	Power transformer	(33) 434-56	1	9-pin tube socket
(9) 40-67	1	1.5 - 3.0 mh coil	(34) 438-4	2	Phono plug
(10) 40-68	1	120-150 μh coil	462-140	1	Knob (large)
			462-159	3	Knob (small)
			(35) 100-M357	1	Pointer assembly
			90-M331F	1	Cabinet top shell
			90-M330P262	1	Cabinet base
HARDWARE			200-M453	1	Chassis
(11) 250-52	6	4-40 x 1/4" screw	490-5	1	Nut starter
(12) 250-89	5	6-32 x 3/8" screw	331-6		Solder
(13) 250-155	4	#6 sheet metal screw	597-308	1	Kit Builders Guide
(14) 250-15	1	8-32 setscrew	595-775	1	Manual
				1	Identification label

INSTALLATION

CONNECTION TO THE RECEIVER

To put the Q Multiplier in operation, connect a coaxial cable between your communications receiver and the phono socket on the rear of the Q Multiplier. Figure 1A shows how to install the phono plug on the coaxial cable. Connect the shield of this cable to chassis ground in the receiver. Connect the inner lead to the plate circuit of the mixer stage. See Figure 1, which shows the Q Multiplier connected in a typical mixer stage. A phono socket may be installed on the rear of your receiver or you may wish to use the two spade lugs supplied with this kit.




Figure 1

The connection from the mixer plate to the inner lead of the coaxial cable should be as short as possible, and isolated from other receiver circuits. If shielded wire is used for the connection between the coaxial cable and the mixer plate, the primary winding of the first IF transformer should be retuned. (Retune the transformer before attaching the Q Multiplier to the receiver.)




Figure 1A

This will compensate for the additional capacitance the shielded wire places across the transformer.

WARNING: Connecting the Q Multiplier to an AC-DC type of receiver, particularly the "hot chassis" type, may make the chassis and cabinet of the Q Multiplier "hot" also. To avoid this lethal shock hazard, connect the leads of an AC voltmeter between the Q Multiplier chassis and a good earth ground. If a reading of 117 volts is obtained, reverse the receiver's power plug in the power outlet. Then mark the plug and outlet to polarize them for future reference.

ALIGNMENT

- () A small rectangular steel blade is supplied with this kit. Refer to Figure 2. Then use long-nose pliers to insert this blade into the smaller hole in the plastic nut starter. When installed, the blade end should be flush with the end of the nut starter. This can now be used as an alignment tool.
- () For best results, the receiver IF strip should be in good alignment at the IF frequency. It would be well to check receiver alignment before proceeding.
- () If the receiver does not have an S meter, it is recommended that a voltmeter be connected between its AVC line and ground. This meter should be set to a negative DC range. It will then act as an S meter. For best results, this meter should have a negative DC range low enough to permit a center scale deflection of the meter when the receiver is tuned to a station.
- () Connect the Q Multiplier to the receiver. Then, with the Function switch in the OFF position, tune in a steady phone signal, or possibly a broadcast station. Be sure that the signal is centered in the IF bandpass. This can be noted by the greatest S meter reading, maximum audio signal, or by a maximum reading on the voltmeter (AVC voltage in the receiver).

Refer to Figure 3 for the location of the alignment points.

- () Place the cabinet top shell upside down on the top of the cabinet base. This will compensate for the capacitance added when the cabinet is installed later.




Figure 2

- () Tune coil L1 for the highest S meter reading or loudest signal (or maximum negative DC reading on the voltmeter). When adjusting this coil, you will notice two different points at which a peak can be obtained. Use the peak obtained with the coil slug midway in the coil, not the one where the slug protrudes from the bottom of the coil. This adjustment tunes out the reactance of the coaxial cable; it will not have to be changed later.




Figure 3

- () Rotate the NOTCH DEPTH and PEAK controls to their mid-point, and set the TUNING knob so the plates of the tuning capacitor are 50% meshed. Then, rotate the Function switch to the NULL position and allow the Q Multiplier to warm up. Be sure there are no components overheating before continuing.


NOTE: The next adjustment is critical; therefore, it is recommended that the procedure be followed carefully.

- () Now adjust coil L2 for a null on the S meter or minimum signal (or for the smallest amount of negative DC voltage on the voltmeter). This null will be extremely sharp. With a 455 kc IF, it will occur when the coil screw is between 1/8" and 1/4" above the coil mounting frame. Rock the adjustment back and forth over this point several times to make sure that the best null reading is obtained.

This completes the Alignment.

Refer to Pictorial 10 for the following steps.

- () Install a rubber foot in each corner of the cabinet base.



PICTORIAL 10

- () Install the cabinet top shell on the cabinet base with four #6 sheet metal screws.
- () Carefully peel away the backing paper from the blue and white identification label. Then press the label onto the rear of the cabinet base. Be sure to refer to the numbers on this label in any communications you have with the Heath Company about this kit.

OPERATION

OPERATING NOTES

The Q Multiplier is essentially a high Q resonant circuit that is tuned to the IF of your communications receiver. The Q Multiplier is aligned so that signals slightly removed from the IF bandpass will be bypassed to ground. Misalignment of the Q Multiplier will give the effect of deadening the receiver. Actually, due to its regenerative characteristic, the desired signal will be amplified and adjacent unwanted signals will be deadened (for Peak operation).

The Q Multiplier is extremely sensitive to tune, therefore the operator may have to practice for a while before he becomes proficient in its operation. Proper tuning is of the utmost importance. The Q Multiplier will appear to greatly amplify the sensitivity of the receiver when it is tuned and operated correctly.

CONTROL FUNCTIONS

The following paragraphs describe operation of the Q Multiplier in each position of the Function switch.

Off

In this position, the Q Multiplier has no effect and the receiver will operate in the usual manner.

Peak

By varying the PEAK control, the receiver selectivity can be changed from broad to extremely sharp. With the control counterclockwise, the bandpass will be quite broad and the receiver gain somewhat decreased. As the control is turned clockwise, the peak becomes narrower and the gain higher until the sharpest point is reached just below the point of oscillation.

Phone signals may lose some volume due to the loss of high frequency audio response.

With the Q Multiplier peaked, the TUNING setting can be changed to accentuate any signal within the receiver IF bandpass and attenuate all others. This is the main advantage that the Q Multiplier has over a filter. As the receiver does not have to be tuned to peak any particular signal within its bandpass, there is little danger in losing the desired signal.

Null

The NULL position is particularly good for removing heterodynes on phone signals or adjacent CW signals. It is extremely sharp and, as such, is very critical to tune. Besides nulling the interfering signal, it is equally easy to remove the desired signal. It probably will require some practice before this function of the Q Multiplier can be used to advantage.

It may help to remember that the Q Multiplier tunes toward the high end of the IF bandpass in a clockwise direction, providing the receiver local oscillator is higher in frequency than the incoming signal. A heterodyne higher in frequency than the desired signal would be removed by approaching it by counterclockwise rotation of the TUNING knob, and vice versa. When the undesired signal has been placed in the notch, adjust both the TUNING and NOTCH DEPTH controls for maximum null.

Broad

This position allows a higher gain than the PEAK position when a wider bandpass is desired. It also allows the Q Multiplier to be used as a BFO by advancing the PEAK control to just past the oscillation point.

IN CASE OF DIFFICULTY

NOTE: Refer to the Kit Builders Guide for Service and Warranty information.

1. Recheck the wiring. Trace each lead in colored pencil on the Pictorial as it is checked. It is frequently helpful to have a friend check your work. Someone who is not familiar with the unit may notice something consistently overlooked by the constructor.
2. It is interesting to note that about 90% of the kits that are returned for repair, do not function properly due to poor connections and soldering. Therefore, many troubles can be eliminated by reheating all connections to make sure that they are soldered as described in the Soldering section of the Kit Builders Guide.
3. Make sure that the tube lights up properly.
4. Check the tube with a tube tester or by substitution of a tube of the same type and known to be good.
5. Check the values of the component parts. Be sure that the proper part has been wired into the circuit, as shown in the pictorial diagrams and as called out in the wiring instructions.
6. Check for bits of solder, wire ends or other foreign matter which may be lodged in the wiring.
7. If, after careful checks, the trouble is still not located and a voltmeter is available, check voltage readings against those found on the Schematic Diagram. NOTE: All voltage readings were taken with an 11 megohm input vacuum tube voltmeter. Voltages may vary as much as 10% due to line voltage variations.
8. A review of the Circuit Description will prove helpful in indicating where to look for trouble.
9. Make sure the receiver that is being used with the Q Multiplier has an IF between 450 and 500 kc.

SPECIFICATIONS

Operating Frequency.	450 - 500 kc.
Switch Functions.	OFF, PEAK, NULL, BROAD.
Tube-Diode Complement.	1 - 12AX7 tube, multiplier, 1 - Silicon diode, rectifier.
Power Requirements.	105-125 volts AC, 50/60 cps, 4-1/2 watts.
Cabinet Size.	9-1/32" wide x 2-9/16" high x 3-5/8" deep.
Net Weight.	2-1/2 lbs.

CIRCUIT DESCRIPTION

Refer to the Schematic (fold-out from Page 19) while reading the following description.

CIRCUIT THEORY

The Q Multiplier, which is connected across the input IF transformer of your communications receiver, acts like a very high Q tuned circuit. And since all high Q circuits have a very sharp resonance point, the Q Multiplier can be used for either of the following purposes:

1. It can be used to peak a desired signal by performing like a very high Q parallel resonant circuit. See Figure 4. As the Q is increased, the side slopes of the resonant peak become steeper and steeper. Therefore, at the resonant frequency of the Q Multiplier, the desired signal "sees" a




Figure 4

very high impedance and passes on to the IF amplifier. All other frequencies "see" a relatively low impedance and are shunted to ground. The Tuning control on the Q Multiplier adjusts the resonant peak to any point in the IF bandpass.

2. It can be used to null out an unwanted signal by performing like a very high Q series resonant circuit. See Figure 5. Here, the unwanted signal "sees" a very low impedance and is shunted to ground by the Q Multiplier. All other signals see the normal high impedance and pass on through the receiver. The null point can be adjusted to any point in the IF bandpass, therefore a heterodyne adjacent to the desired signal can be dropped into the notch (null point) and eliminated.

CIRCUIT OPERATION

The Q Multiplier circuit is centered around coil L2 (in the plate circuit of tube V1B), which has a Q of 200 or more. The Q of this coil is amplified to approximately 4000 by the positive feedback that is coupled back to the grid of tube V1B through capacitor C9. The resonant frequency of the circuit is adjusted by capacitor C7.

The output signal, for Peak or Broad operation, is coupled through the Function switch, capacitor C1, and the coaxial cable to the communications receiver. The high Q that this circuit introduces into the receiver compares favorably with the Q of the quartz crystal in a crystal filter.

For Null operation, the output signal is coupled through lugs 7 and 9 of the Function switch, and through capacitor C4 to the grid of tube V1A. Tube V1A inverts the signal, making it 180 degrees out of phase with the IF response of the receiver. The inverted signal is then coupled through capacitors C3 and C1, and the coaxial cable, to the receiver where it causes a sharp null in the IF response.

Coil L1 is used to tune out the capacitance of the coaxial cable.

POWER SUPPLY

The line voltage is transformer coupled to half-wave rectifier diode D1. The rectified voltage is then filtered by a pi-network consisting of capacitors C10A and C10B, and resistor R9. Resistor R10 and the neon lamp make up the pilot lamp circuit. The pilot lamp indicates the presence of B+.





Figure 5



1. ALL RESISTORS ARE 1/2 WATT UNLESS MARKED OTHERWISE.
2. CAPACITOR VALUES LESS THAN 1 ARE IN μF , AND ABOVE 1 ARE IN $\mu\mu$, UNLESS MARKED OTHERWISE.
3. FUNCTION SWITCH SHOWN IN OFF POSITION.
4. VOLTAGE READINGS MAY VARY $\pm 10\%$.
5. ALL DC VOLTAGES ARE INDICATED IN ELLIPSES.