



CD-100F
LaserStar® V

*Compact Disc
Phonograph*

Field Service Manual
& Parts Catalog

Volume 2 of 2

CBA-2 Maintenance, Troubleshooting, Adjustments, Parts Catalog

PART NO. 21822637
FIRST EDITION

CD-100F

LaserStar® IV

Compact Disc Phonograph

Field Service Manual
And Parts Catalog

Volume 2



ROWE INTERNATIONAL INC.

1500 UNION AVE, SE
GRAND RAPIDS, MI 49507 - 1884
(616) 243-3633

Part No. 21822637
First Edition
First Printing March 1996

SECTION 4 — CBA-2 MAINTENANCE

System Description	4-1
Equipment Description	4-1
Transport	4-1
Logic Board	4-1
Bill Acceptor Transport/Stacker	4-1
Magnetic Head and Bill Pressure Roller	4-1
Anti Cheat Lever and V ₄ Sensor	4-2
Transport/Stacker Drive	4-2
Bill Acceptor Logic Board	4-2
Power and Status LED's	4-2
Reset Pushbutton	4-2
Functional Description	4-2
Power Up Sequence	4-2
Acceptor in Standby Mode (Ready to Accept Bills)	4-3
Problems That May Arise in Standby Mode	4-3
Actions Taken by the Bill Acceptor to Correct Problems	4-3
Bill Acceptance Mode	4-4
Routine Maintenance	4-11
Tools Required	4-11
Bill Jamming Checklist and Corrective Procedures	4-11
Cleaning & Lubrication	4-12
Mechanical Adjustments	4-13
Belt Adjustment	4-13
Gear Backlash Adjustment	4-14
Stacker Home Switch Adjustment	4-14
Magnetic Head Alignment	4-15
Removal and Replacement Procedures	4-15
Removing the Inlet	4-15
Removing & Re-Installing the Watershield	4-15
Removing & Re-Installing the Lower Harness and Cell Assembly	4-16
Troubleshooting	4-17

SECTION 5 — TROUBLESHOOTING

Introduction	5-1
Troubleshooting Topics	5-1
Replacing the CCC Eprom / Factory Default	5-2
Free Play	5-2
CD Module Functions	5-2
Digital Display Module	5-2
Title Rack - Keyboard Interface Module	5-2
CCC	5-2
Mechanism Control	5-3
CBA-2 Logic Board	5-3

SECTION 5 — TROUBLESHOOTING *(Continued)*

Sequence of Operation	5-3
CCC	5-4
Mechanism Control	5-4
CBA-2	5-4
Digital Display	5-4
Status Lamps	5-15
Main Power Supply LED's	5-15
Mechanism Control	5-15
Central Control Computer	5-16
Digital Display	5-16
CBA-2	5-16
Errors and Warnings	5-17
Basic Concepts	5-17
Errors (ERR)	5-17
Warnings (WARN)	5-17
Viewing the Errors and Warnings	5-17
Error and Warning Summary	5-20
Description of Errors/Warnings and Probable Causes	5-21
Clearing Errors/Warnings from Memory	5-27
Disc Conditions	5-28
Basic Concepts	5-28
Programmable Disc Condition Logging	5-28
Condition Log (Service Code 35)	5-28
Skip Cancel (Service Code 36)	5-28
Time Cancel (Service Code 37)	5-28
Factory Settings	5-28
Non-Programmable Disc Condition Logging	5-28
Logged Track Number equals 00	5-28
Logged CANCL and SKIP Equals 99	5-29
Logged CANCL equals 99 and SKIP equals 88	5-29
Logged CANCL equals 99 and SKIP equals 77	5-29
Viewing Disc Conditions	5-29
Clearing Disc Conditions from Memory	5-32
Troubleshooting Charts	5-33
Sound System Quick Check	5-44
No Sound - Both Channels	5-44
No Sound, Low Sound or Distorted Sound Right or Left Channel Only	5-44
Constant High Volume - Cannot Adjust	5-45
Excessive Hum	5-46
Components Lists	
Main Power Supply	5-52
Preamplifier Board	5-58
Amplifier Driver Board	5-68
Crossover Network	5-71
Display Assembly	5-76
Central Control Computer	5-85
Mechanism Control Board	5-103
Title Rack Interface Board	5-110

Table of Contents

SECTION 6 — MECHANICAL ADJUSTMENTS

Lubrication	6-1
Unscheduled Maintenance	6-1
Mechanism Maintenance And Adjustments	6-1
CD Player Mechanism	6-1
Cleaning the Laser Lens	6-1
CD Player Maintenance	6-1
Removing the Mechanism Control Unit	6-2
Removing the CD Player	6-3
Hold Down Assembly and Hold Down Plate Height	6-4
Service Check	6-4
Adjustment	6-4
Hold Down Plate Centering	6-5
Optical Switch Adjustment	6-5
Sprag Assembly	6-6
Adjustment	6-6
Sprag Assembly Removal	6-7
Disc Magazine and Gripper Bow Support	6-8
Adjustment	6-8
Magazine Belt Adjustment	6-8
Cam Switch	6-9
Adjustments	6-9
Cam Switch Check and Adjustment	6-9
Magazine Stopping Position Alignment	6-10
Adjustment	6-11
Title Page Assembly Adjustments	6-12
Removing the Title Page Assembly from the Phonograph	6-12
Switches	6-13
Page Removal	6-13
Assembly and Timing Check	6-13
Alignment	6-14
Door Spring Replacement	6-16
Glass Replacement	6-17

SECTION 7 — MISCELLANEOUS

CD-100F Specifications	7-1
General	7-1
Power Requirements	7-1
CD Player and Changer	7-1
Credit and Pricing System	7-1
Sound System	7-2
Transformer Package	7-2
Door Lighting	7-2
Fuses and Circuit Breakers	7-2, 3
Resistor Code Chart	7-4

SECTION 8 — PARTS CATALOG

CD-100F Code Sheet	8-2
Introduction	8-3
Catalog Description	8-3
Parts List Description	8-3
Ordering Replacement Parts	8-3
Parts Catalog	8-4
Accessory Equipment	8-38

FREQUENTLY USED FIGURES AND TABLES FOR VOLUME 2

CBA-2	
Block Diagram (<i>Figure 4-2</i>)	4-6, 7
Schematic (<i>Figure 4-3</i>)	4-8, 9
Troubleshooting Charts	
CBA-2 (<i>Table 4-2</i>)	4-18
Modular (<i>Table 5-2</i>)	5-33
Block Diagram, CD-100F (<i>Figure 5-1</i>)	5-8 thru 5-14
Wiring Harness Table	5-14
Main Power Supply	
Wiring Diagram (<i>Figure 5-7A</i>)	5-47
Schematic - Domestic (<i>Figure 5-7B</i>)	5-48
Preamplifier Schematic (<i>Figure 5-9A</i>)	5-54 thru 5-57
Amplifier Schematic (<i>Figure 5-10A</i>)	5-66, 67
Transformer	
Output Voltages (<i>Figure 5-11</i>)	5-72
Wiring Diagram (<i>Figure 5-12</i>)	5-73
Display Assembly Schematic (<i>Figure 5-13A</i>)	5-74, 75
Central Control Computer	
I/O Matrix (<i>Table 5-4</i>)	5-90
Schematic (<i>Figure 5-14A</i>)	5-78 thru 5-84
Mechanism Control	
Block Diagram (<i>Figure 5-15A</i>)	5-92, 93
Schematic (<i>Figure 5-15B</i>)	5-94 thru 5-102
Connecting Diagram (<i>Figure 6-1</i>)	6-2
Resistor Color Code (<i>Figure 7-2</i>)	7-4
Accessory Equipment (<i>Table 8-2</i>)	8-38